# MaxiDas_Scion_V3.31T Function List

NOTES:
- ● This function is supported.
- ○ This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

**As for special function please refer to the special function table.**

| System Name | Vehicle Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|---|---|---|---|---|---|---|---|
| SRS Airbag | ● | ● | ● | ※ | ○ | ○ | |
| BODY | ● | ● | ● | ※ | ○ | ※ | 0056 0057 |
| BODY2 | ● | ※ | ※ | ※ | ○ | ※ | |
| BODY3 | ● | ※ | ※ | ※ | ○ | ※ | |
| BODY4 | ● | ● | ● | ● | ○ | ● | |
| BODY5 | ● | ※ | ※ | ● | ○ | ● | |
| Immobiliser | ● | ● | ● | ● | ○ | ※ | 0023 0051 0052 0053 0027 0028 0007 |
| Tvss | ● | ● | ● | ● | ○ | ● | |
| Entry&Start | ● | ● | ● | ● | ○ | ● | 0014 0017 0027 0028 |
| Occupant Detection | ● | ● | ● | ● | ○ | | 0043 0018 0058 |
| D-SEAT SW | ● | ※ | ※ | ● | ○ | ※ | |
| AFS | ● | ● | ● | ● | ○ | ● | |
| Pre-Crash | ● | ● | ● | ● | ○ | ● | |
| D-Door Motor | ● | ● | ● | ● | ○ | ● | |
| Theft Deterrent | ● | ● | ● | ● | ○ | ● | 0044 |
| Air Conditioner | ● | ● | ● | ● | ○ | ● | |
| Combination Meter | ● | ※ | ※ | ● | ○ | ● | |
| Back Door | ● | ● | ● | ● | ○ | ● | 0009 |
| Driver Seat | ● | | | ● | ○ | ● | |
| Tilt&Telescopic | ● | ● | ● | ● | ● | ● | |
| Mirror | ● | | | ● | ○ | ● | |
| Gateway | ● | ● | ● | | ○ | | 0024 |
| Passenger Door | ● | ※ | ※ | ● | ○ | ● | |
| Rear left Door | ● | ● | ● | ● | ○ | ● | |
| Rear right door | ● | ● | ● | ● | ○ | ● | |
| Sliding Roof | ● | ※ | ※ | ● | ○ | ● | |
| Driver Door | ● | ※ | ※ | ● | ○ | ● | |
| Master Switch | ● | ● | ● | ● | ○ | ※ | |
| Rear Right Seat | ● | ※ | ※ | ● | ○ | ● | |
| Rear Left Seat | ● | ※ | ※ | ● | ○ | ● | |
| Rear Seat Switch | ● | | | ● | ○ | ○ | |

# MaxiDas_Scion_V3.31T Function List

NOTES:
- ● This function is supported.
- ○ This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

**As for special function please refer to the special function table.**

| System Name | Vehicle Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|---|---|---|---|---|---|---|---|
| Steering Pad Switch | ● | | | ● | ○ | ○ | |
| Clearance Sonar | ● | ● | ● | ● | ○ | ● | |
| Rain Sensor | ● | ※ | ※ | ● | ○ | ○ | |
| Wiper | ● | | | ● | ○ | ● | |
| Combination Switch | ● | | | ● | ○ | ○ | |
| Steering Lock | ● | ● | ● | ● | ○ | ● | 0017 0029 0030 0051 0052 |
| Passenger Seat | ● | | | ● | ○ | ● | |
| Retractable Hardtop | ● | ● | ● | ● | ○ | ○ | |
| Main Body | ● | ● | ● | ● | ○ | ● | 0056 0057 0024 |
| P-Door Motor | ● | ● | ● | ● | ○ | ● | |
| RL-Door Motor | ● | ● | ● | ● | ○ | ● | |
| RR-Door Motor | ● | ● | ● | ● | ○ | ● | |
| HV Gateway | ● | ● | ● | ● | ○ | ○ | 0024 |
| Night View | ● | ● | ● | ● | ○ | ● | 0008 |
| HL Autoleveling | ● | ● | ● | ● | ○ | ● | 0021 |
| ECM Gateway | ● | ● | ● | ● | ○ | ○ | 0024 |
| ECB Gateway | ● | ● | ● | ● | ○ | ○ | 0024 |
| WIL Gateway | ● | ● | ● | ● | ○ | ○ | 0024 |
| Center Console Switch | ● | | | ● | ○ | ● | |
| Rear Console Switch | ● | ● | ● | ● | ○ | ● | |
| Front Left Seat A/C | ● | ● | ● | ● | ○ | ● | |
| Front Right Seat A/C | ● | ● | ● | ● | ○ | ● | |
| Rear left Seat A/C | ● | ● | ● | ● | ○ | ● | |
| Rear Right Seat A/C | ● | ● | ● | ● | ○ | ● | |
| Electric Power Control | ● | ● | ● | ● | ● | ● | |
| Active Headrest R | ● | ● | ● | ● | ○ | ● | |
| Active Headrest L | ● | ● | ● | ● | ○ | ● | |
| Pre-Crash 2 | ● | ● | ● | ● | ※ | ○ | 0010 0011 0039 0040 |
| Accessory Gateway | ● | ● | ● | ● | ○ | ○ | |
| MIRROR R | ● | ※ | ※ | ● | ※ | ● | |
| MIRROR L | ● | ● | ● | ● | ● | ● | |

# MaxiDas_Scion_V3.31T Function List

**Autel**

NOTES:
- ● This function is supported.
- ○ This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

**As for special function please refer to the special function table.**

| System Name | Vehicle Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|---|---|---|---|---|---|---|---|
| Navigation System | ● | ● | ● |  | ○ | ○ |  |
| PM1 Gateway | ● | ● | ● | ● | ○ | ○ | 0024 |
| Charging Control | ● | ● | ● | ● | ○ | ● |  |
| Starting Control | ● | ● | ● | ● | ○ | ● |  |
| PM2 Gateway | ● | ● | ● | ● | ○ | ○ | 0024 |
| Remote Engine Starter | ● | ● | ● | ● | ○ | ○ |  |
| Gateway BEAN | ● | ● | ● |  | ○ | ○ |  |
| Gateway CAN | ● | ● | ● |  | ○ | ○ | 0024 |
| Back DoorPW | ● | ● | ● | ● | ○ | ● |  |
| Transmission Control | ● | ● | ● | ● | ● | ○ |  |
| Parking Assist Monitor System | ● | ● | ● | ● | ○ | ● |  |
| Power Source Control | ● | ● | ● | ● | ○ | ● |  |
| Engine | ● | ● | ● | ● | ※ | ● | 0055 0013 0019 0042 0048 0025 0037 0001 0015 0012 0016 0033 0034 0032 0025 0054 |
| ECT | ● | ● | ● | ● | ※ | ● | 0042 0013 002 0003 |
| ABS | ● | ● | ● | ● | ● | ● | 0005 0006 0042 0049 0026 0013 |
| EMPS | ● | ● | ● | ● | ● |  | 0004 0050 |
| Free-Tronic | ● | ● | ● | ● | ● | ● | 0006 0036 0038 |
| Air suspension | ● | ● | ● | ● | ○ | ● | 0020 |
| AHC | ● | ● | ● | ● | ○ | ● | 0020 |
| VGRS | ● | ● | ● | ● | ● | ○ | 0047 0004 |
| EMS | ● | ● | ● | ● | ○ | ● |  |
| Tire Pressure Monitor | ● | ● | ● | ● | ○ | ○ | 0022 |
| EHPS | ● | ● | ● | ● | ● | ○ |  |
| Four Wheel Drive | ● | ● | ● | ● | ○ | ● | 0042 |
| Stabilizer | ● | ● | ● | ● | ○ | ○ | 0045 |
| Intelligent Parking Assist | ● | ● | ● |  | ○ | ○ |  |
| Electric Parking Brake | ● | ● | ● | ● | ○ | ● | 0042 |
| Lane Keeping Assist | ● | ● | ● | ● | ● | ○ |  |
| Front Stabilizer | ● | ● | ● | ● | ○ | ● |  |
| Rear Stabilizer | ● | ● | ● | ● | ○ | ● |  |

# MaxiDas_Scion_V3.31T Function List

**NOTES:**
- ● This function is supported.
- ○ This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

**As for special function please refer to the special function table.**

| System Name | Vehicle Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|---|---|---|---|---|---|---|---|
| ENGINE AND ECT | ● | ● | ● | ● | ※ | ● | 0013 0042 0048 0025 0019 |
| Cruise Control | ● | ● | ● | ● | ○ | ○ | |
| ENGINE(LH Bank) | ● | ● | ● | ● | ● | ● | 0055 0013 0019 0042 0048 0025 0037 0001 0015 0012 0016 0033 0034 0032 0025 0054 |
| ENGINE(RH Bank) | ● | ● | ● | ● | ● | ● | 0055 0013 0019 0042 0048 0025 0037 0001 0015 0012 0016 0033 0034 0032 0025 0054 |
| HV Battery | ● | ● | ● | ● | ● | ● | 0024 0035 |
| Hybrid Control | ● | ● | ● | ● | ※ | ● | 0026 0024 0042 |
| Sequential M/T | ● | ● | ● | ● | ● | ● | 0036 |
| Multi-Mode M/T | ● | ● | ● | ● | ※ | ● | 0036 |
| Stop And Go | ● | ● | ● | ● | ● | ● | 0046 0018 0041 |
| Radar Cruise | ● | ● | ● | ● | ○ | ○ | 0008 0031 |
| Laser Cruise | ● | ● | ● | ● | ○ | ○ | 0008 0031 |
| E-ACM | ● | ● | ● | ● | ○ | ● | |
| Telematics | ● | ● | ● | ● | ○ | ○ | |
| PPS | ● | ● | ● | ● | ○ | ○ | 0004 0050 |
| Advanced Parking Guidance System | ● | ● | ● | ● | ○ | ○ | |
| FC | ● | ● | ● | ● | ○ | ● | |
| FCHV | ● | ● | ● | ● | ○ | ● | 0026 |
| EV | ● | ● | ● | ● | ● | ● | |
| Battery | ● | ● | ● | ● | ● | ● | |
| Front Right Door | ● | | | ● | ● | ● | |
| Front Left Door | ● | | | ● | ● | ● | |
| KDSS | ● | ● | ● | ● | ● | ● | |
| Telematics | ● | ● | ● | ● | ● | ● | |
| A/B | ● | ● | ● | ○ | ○ | ○ | |
| A/T | ● | ● | ● | ● | ○ | ● | |
| ABS | ● | ● | ● | ● | ○ | ● | |
| ABS/VSC | ● | ● | ● | ● | ○ | ● | |
| ABS-VSC | ● | ● | ● | ● | ○ | ● | |
| ABS-VSC-ARS | ● | ● | ● | ● | ○ | ● | |

# MaxiDas_Scion_V3.31T Function List

**Autel**

NOTES:
- ● This function is supported.　　※ This function may be supported, which depends on the actual condition of the vehicle.
- ○ This function is not supported.　▲ This function is the new feature in this version.

  **As for special function please refer to the special function table.**

| System Name | Vehicle Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|---|---|---|---|---|---|---|---|
| AMT | ● | ● | ● | ● | ○ | ○ | |
| ARS | ● | ● | ● | ● | ○ | ○ | |
| ASG | ● | ● | ● | ● | ○ | ● | |
| Bluetooth communication Mojeru | ● | ● | ● | ● | ○ | ● | |
| CAN bus gateway | ● | ● | ● | ○ | ○ | ○ | |
| CAN bus gateway V | ● | ● | ● | ○ | ○ | ○ | |
| CVT | ● | ● | ● | ● | ○ | ● | |
| DRS | ● | ● | ● | ● | ○ | ○ | |
| eco IDLE | ● | ● | ● | ● | ○ | ● | |
| ECT(SIL) | ● | ● | ● | ● | ○ | ● | |
| EFI | ● | ● | ● | ● | ○ | ● | |
| EPS | ● | ● | ● | ● | ○ | ○ | |
| FC | ● | ● | ● | ○ | ○ | ● | |
| FCHV | ● | ● | ● | ○ | ○ | ● | |
| HV | ● | ● | ● | ● | ○ | ● | |
| ITC | ● | ● | ● | ● | ○ | ● | |
| KFS | ● | ● | ● | ※ | ○ | ※ | |
| RL seat headrest ACT | ● | ● | ● | ● | ○ | ● | |
| ACT RR seat headrest | ● | ● | ● | ● | ○ | ● | |
| Pre-crash seat back seat RL | ● | ● | ● | ● | ○ | ● | |
| Pre-crash seat back seat RR | ● | ● | ● | ● | ○ | ● | |
| VGRS | ● | ● | ● | ● | ○ | ○ | |
| Active rear wing | ● | ● | ● | ● | ○ | ● | |
| Engine 2 | ● | ● | ● | ● | ○ | ● | |
| Grille shutter | ● | ● | ● | ● | ○ | ● | |
| Cruise Control 2 | ● | | | ● | ○ | ○ | |
| Stop & Go | ● | ● | ● | ● | ○ | ● | |
| Diagnostics recorder | ● | ● | ● | ○ | ○ | ○ | |
| Panoramic View Monitor | ● | ● | ● | ● | ○ | ● | |
| Slave blind spot monitor | ● | ● | ● | ● | ○ | ○ | |

# MaxiDas_Scion_V3.31T Function List

NOTES:
- ● This function is supported.
- ○ This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

**As for special function please refer to the special function table.**

| System Name | Vehicle Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|---|---|---|---|---|---|---|---|
| Blind Spot Monitor Master | ● | ● | ● | ● | ○ | ○ | |
| Plug-in control | ● | ● | ● | ● | ○ | ○ | |
| Body / gateway | ● | ● | ● | ● | ○ | ● | |
| Multi-bus gateway | ● | ● | ● | ○ | ○ | ○ | |
| No.1 multi-bus monitoring | ● | ● | ● | ○ | ○ | ○ | |
| No.2 multi-bus monitoring | ● | ● | ● | ○ | ○ | ○ | |
| The motor-generator | ● | ● | ● | ● | ○ | ○ | |
| Remote Security | ● | ● | ● | ● | ○ | ● | |
| Lane Keeping Assist | ● | ● | ● | ※ | ○ | ○ | |
| Vehicle control | ● | ● | ● | ● | ○ | ● | |
| PKB electric | ● | ● | ● | ● | ○ | ● | |
| Movable pedal | ● | ● | ● | ● | ○ | ● | |

# Special_Function

| FuncNo | Function | FuncNo2 | Function3 |
|--------|----------|---------|-----------|
| 0001 | A/F Sensor Compensation Reset | 0030 | Key Number Registration |
| 0002 | A/T Code Registration | 0031 | Laser/Radar Cruise Initialization |
| 0003 | A/T Code Reset | 0032 | Learning Values Confirmation |
| 0004 | Abonormal Operation History | 0033 | Learning Values Save |
| 0005 | ABS History | 0034 | Learning Values Write |
| 0006 | Air Bleeding | 0035 | Onboard Equalizing Charge |
| 0007 | Auto Registration Closure | 0036 | Parts Exchange |
| 0008 | Beam Axis Adjustment | 0037 | Pilot Quantity Learning Values Reset |
| 0009 | Camera Angle Adjustment | 0038 | Pressure Release |
| 0010 | Camera Axis Adjust | 0039 | Rear Beam Axis Adjustment |
| 0011 | Camera/Target Position memory | 0040 | Rear Radar Sensor Check |
| 0012 | Catalyst Record Clear | 0041 | Reset A/C Information |
| 0013 | Check Mode | 0042 | Reset Memory |
| 0014 | Communication Check(Key Diag Mode) | 0043 | Sensitivity Check |
| 0015 | Crank Time Compensation Reset | 0044 | Servomotor Initialization |
| 0016 | DPF Deterioration Record Clear | 0045 | Stabilizer System Check |
| 0017 | ECU Communication ID Registration | 0046 | Starter exchange |
| 0018 | ECU Exchange | 0047 | Steering Angle Adjust |
| 0019 | Electric Throttle Learning | 0048 | Supply Pump Initialization |
| 0020 | HEIGHT OFFSET | 0049 | Test Mode |
| 0021 | Height Sensor Initialization | 0050 | Torque Sensor Adjustment |
| 0022 | ID Registration | 0051 | Transponder Code Erasure |
| 0023 | Immobiliser Code Reset | 0052 | Transponder code Registration |
| 0024 | Initialization | 0053 | Transponder Code Registration(IDS) |
| 0025 | Injector Compensation | 0054 | Vehicle Mileage Write |
| 0026 | Inspection Mode | 0055 | VIN |
| 0027 | Key Code Erasure | 0056 | Wireless Code Erasure |
| 0028 | Key Code Registration | 0057 | Wireless Code Registration |
| 0029 | Key Number Change | 0058 | Zero Point Calibration |