

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(All MY05)	2.3L	DURATEC-HE / I4	2005	4X4	●	●	●	●	○
(All MY05)	2.3L	DURATEC-HE / I4	2005	ABS	●	●	●	●	0008
(All MY05)	2.3L	DURATEC-HE / I4	2005	GEM	●	●	●	●	000A 000F
(All MY05)	2.3L	DURATEC-HE / I4	2005	IC	●	●	●	●	○
(All MY05)	2.3L	DURATEC-HE / I4	2005	PAM	●	●	●	●	○
(All MY05)	2.3L	DURATEC-HE / I4	2005	PCM	●	●	●	●	0009 0023 0025 00C5
(All MY05)	2.3L	DURATEC-HE / I4	2005	RCM	●	●	●	●	000C
(All MY05)	3.0L	4V	2005	4X4	●	●	●	●	○
(All MY05)	3.0L	4V	2005	ABS	●	●	●	●	0008
(All MY05)	3.0L	4V	2005	GEM	●	●	●	●	000A 000F
(All MY05)	3.0L	4V	2005	IC	●	●	●	●	0005
(All MY05)	3.0L	4V	2005	PAM	●	●	●	●	○
(All MY05)	3.0L	4V	2005	PCM	●	●	●	●	0009 0023 0025 00C5
(All MY05)	3.0L	4V	2005	RCM	●	●	●	●	000C
AEROSTAR	3.0L	Other	1996 - 1997	PCM	●	●	●	●	0023 0025
AEROSTAR	4.0L	Other	1996 - 1997	PCM	●	●	●	●	0023 0025
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		ABS	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		ACM	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		APIM	●	●	●	●	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		BCMii	●	●	●	●	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		DDM	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		FCDIM	●	●	●	●	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		FDSM	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		GPSM	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		GWM	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		HVAC	●	●	●	●	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		IPC	●	●	●	●	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		PCM	●	●	●	●	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		PDM	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		PSCM	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		RCM	●	●	●	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		RFA	●	●	●	○	○
B-Max	1.25L	DURATEC 16V	2008	ABS	●	●	●	●	○
B-Max	1.25L	DURATEC 16V	2008	ACM	●	●	●	●	○
B-Max	1.25L	DURATEC 16V	2008	BCMii	●	●	●	●	○
B-Max	1.25L	DURATEC 16V	2008	FCDIM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
B-Max	1. 25L	DURATEC 16V	2008	HVAC	●	●	●	●	○
B-Max	1. 25L	DURATEC 16V	2008	IPC	●	●	●	●	0009
B-Max	1. 25L	DURATEC 16V	2008	PCM	●	●	●	●	○
B-Max	1. 25L	DURATEC 16V	2008	PSCM	●	●	●	●	○
B-Max	1. 25L	DURATEC 16V	2008	RCM	●	●	●	●	○
B-Max	1. 25L	DURATEC 16V	2008	RFA	●	●	●	●	○
B-Max	1. 25L	DURATEC 16V	2008	SRM	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	ABS	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	ACM	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	BCMii	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	FCDIM	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	HVAC	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	IPC	●	●	●	●	0009
B-Max	1. 4L	DURATEC 16V	2008	PCM	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	PSCM	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	RCM	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	RFA	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	SRM	●	●	●	●	○
B-Max	1. 4L	DURATEC 16V	2008	TCM	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●	●	0009
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	●	0099 009A 00B4 00BC
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●	●	○
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	●	●	●	●	○
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection		ABS	●	●	●	○	○
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection		ACM	●	●	●	○	○
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection		APIM	●	●	●	●	○
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection		BCMii	●	●	●	●	○
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection		DDM	●	●	●	○	○
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection		FCDIM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		FDSM	●	●	●	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		GPSM	●	●	●	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		GWM	●	●	●	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		HVAC	●	●	●	●	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		IPC	●	●	●	●	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		PCM	●	●	●	●	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		PDM	●	●	●	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		PSCM	●	●	●	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		RCM	●	●	●	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		RFA	●	●	●	○	○
B-Max	1.6L	DURATEC VCT	2008	ABS	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	ACM	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	BCMii	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	FCDIM	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	HVAC	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	IPC	●	●	●	●	0009
B-Max	1.6L	DURATEC VCT	2008	PCM	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	PSCM	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	RCM	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	RFA	●	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008	SRM	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●	●	0009
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	●	0090 0092 0098 0099 00AA 00B0 00B1
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	●	●	●	●	○
B-Max	1.6L	TDCi ECO II		ABS	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		ACM	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		APIM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
B-Max	1.6L	TDCi ECO II		BCMii	●	●	●	●	○
B-Max	1.6L	TDCi ECO II		DDM	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		FCDIM	●	●	●	●	○
B-Max	1.6L	TDCi ECO II		FDSM	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		GPSM	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		GWM	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		HVAC	●	●	●	●	○
B-Max	1.6L	TDCi ECO II		IPC	●	●	●	●	○
B-Max	1.6L	TDCi ECO II		PCM	●	●	●	●	○
B-Max	1.6L	TDCi ECO II		PDM	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		PSCM	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		RCM	●	●	●	○	○
B-Max	1.6L	TDCi ECO II		RFA	●	●	●	○	○
BT-50 / Ranger	2.2L	F2	2007	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	2.2L	F2	2007	PCM	●	●	●	●	○
BT-50 / Ranger	2.2L	F2	2007	RCM	●	●	●	●	○
BT-50 / Ranger	2.5L	L5	2012	ABS	●	●	●	●	○
BT-50 / Ranger	2.5L	L5	2012	PCM	●	●	●	○	○
BT-50 / Ranger	2.5L	WL	2007	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	2.5L	WL	2007	PCM	●	●	●	●	○
BT-50 / Ranger	2.5L	WL	2007	RCM	●	●	●	●	○
BT-50 / Ranger	2.5L	WL-CD	2007	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	2.5L	WL-CD	2007	PCM	●	●	●	●	○
BT-50 / Ranger	2.5L	WL-CD	2007	RCM	●	●	●	●	○
BT-50 / Ranger	2.5L	WL-CD	2007	TCM	●	●	●	●	○
BT-50 / Ranger	2.6L	G6	2007	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	2.6L	G6	2007	PCM	●	●	●	●	○
BT-50 / Ranger	2.6L	G6	2007	RCM	●	●	●	●	○
BT-50 / Ranger	3.0L	WE-CD	2007	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	3.0L	WE-CD	2007	PCM	●	●	●	●	○
BT-50 / Ranger	3.0L	WE-CD	2007	RCM	●	●	●	●	○
BT-50 / Ranger	3.0L	WE-CD	2007	TCM	●	●	●	●	○
BT-50 / Ranger	4.0L	V6 SOHC	2007	ABS/TCS	●	●	●	●	0008
BT-50 / Ranger	4.0L	V6 SOHC	2007	ESOF	●	●	●	●	○
BT-50 / Ranger	4.0L	V6 SOHC	2007	PCM	●	●	●	●	0023
BT-50 / Ranger	4.0L	V6 SOHC	2007	RCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Cougar	2.0L	Zetec	1998 - 2002	ABS/TCS	●	●	●	●	0008
Cougar	2.0L	Zetec	1998 - 2002	CSM	●	●	●	●	○
Cougar	2.0L	Zetec	1998 - 2002	HEC	●	●	●	●	○
Cougar	2.0L	Zetec	1998 - 2002	IAB	●	●	●	●	○
Cougar	2.0L	Zetec	1998 - 2002	PCM	●	●	●	●	0023 0025 0009
Cougar	2.5L	Duratec-VE	1998 - 2002	ABS/TCS	●	●	●	●	0008
Cougar	2.5L	Duratec-VE	1998 - 2002	CSM	●	●	●	●	○
Cougar	2.5L	Duratec-VE	1998 - 2002	HEC	●	●	●	●	○
Cougar	2.5L	Duratec-VE	1998 - 2002	IAB	●	●	●	●	○
Cougar	2.5L	Duratec-VE	1998 - 2002	PCM	●	●	●	●	0023 0025 0009
Cougar	2.5L	Duratec-VE	2001	ABS	●	●	●	●	○
Cougar	2.5L	Duratec-VE	2001	IC	●	●	●	●	○
Cougar	2.5L	Duratec-VE	2001	MC	●	●	●	●	○
Cougar	2.5L	Duratec-VE	2001	REM	●	●	●	●	○
Cougar	3.8L	Other	1996 - 1997	ABS/TCS	●	●	●	●	○
Cougar	3.8L	Other	1996 - 1997	HEC	●	●	●	●	○
Cougar	3.8L	Other	1996 - 1997	PCM	●	●	●	●	0023 0025
Cougar	4.6L	2V	1994 - 1997	ABS/TCS	●	●	●	●	○
Cougar	4.6L	2V	1994 - 1997	HEC	●	●	●	●	○
Cougar	4.6L	2V	1994 - 1997	PCM	●	●	●	●	0023 0025
Crown Victoria	4.6L	2V	1995 - 1997	DSM	●	●	●	●	○
Crown Victoria	4.6L	2V	1995 - 2004	ABS/TCS	●	●	●	●	0008
Crown Victoria	4.6L	2V	1995 - 2007	EATC	●	●	●	●	○
Crown Victoria	4.6L	2V	1995 - 2011	DDM	●	●	●	●	000F 000A 0042 0005
Crown Victoria	4.6L	2V	1995 - 2011	LCM	●	●	●	●	○
Crown Victoria	4.6L	2V	1995 - 2011	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033 0009
Crown Victoria	4.6L	2V	1996 - 1997	IAB	●	●	●	●	○
Crown Victoria	4.6L	2V	1998 - 2000	ECS	●	●	●	●	○
Crown Victoria	4.6L	2V	1998 - 2002	PATS	●	●	●	●	0009
Crown Victoria	4.6L	2V	2000 - 2011	RCM	●	●	●	●	000C
Crown Victoria	4.6L	2V	2003 - 2006	RASM	●	●	●	●	0013
Crown Victoria	4.6L	2V	2003 - 2006	VAPS	●	●	●	●	○
Crown Victoria	4.6L	2V	2004 - 2010	MC	●	●	●	●	○
Crown Victoria	4.6L	2V	2005 - 2011	ABS	●	●	●	●	0008
Crown Victoria	4.6L	2V	2005 - 2011	FSSM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Crown Victoria	4. 6L	2V	2006 - 2011	IC	●	●	●	●	0005
Crown Victoria	4. 6L	2V	2007 - 2011	VDM	●	●	●	●	0005
Crown Victoria	4. 6L	2V	2008 - 2011	HVAC	●	●	●	●	○
Crown Victoria	4. 6L	2V NGV	1996 - 1997	DSM	●	●	●	●	○
Crown Victoria	4. 6L	2V NGV	1996 - 1997	IAB	●	●	●	●	○
Crown Victoria	4. 6L	2V NGV	1996 - 2000	ABS/TCS	●	●	●	●	0008
Crown Victoria	4. 6L	2V NGV	1996 - 2000	DDM	●	●	●	●	000F 000A
Crown Victoria	4. 6L	2V NGV	1996 - 2000	FIM	●	●	●	●	○
Crown Victoria	4. 6L	2V NGV	1996 - 2000	LCM	●	●	●	●	○
Crown Victoria	4. 6L	2V NGV	1996 - 2000	PCM	●	●	●	●	0023 0010 0028 0031
Crown Victoria	4. 6L	2V NGV	1998 - 2000	EATC	●	●	●	●	○
Crown Victoria	4. 6L	2V NGV	1998 - 2000	ECS	●	●	●	●	○
Crown Victoria	4. 6L	2V NGV	1998 - 2000	PATS	●	●	●	●	0009
Crown Victoria	4. 6L	2V NGV	2000	RCM	●	●	●	●	○
Crown Victoria	4. 6L	0ther	1995	ABS/TCS	●	●	●	●	0008
Crown Victoria	4. 6L	0ther	1995	PCM	●	●	●	●	0023 0025
E-Series	4. 2L	0ther	1997 - 2003	ABS/TCS	●	●	●	●	0008
E-Series	4. 2L	0ther	1997 - 2003	ECS	●	●	●	●	○
E-Series	4. 2L	0ther	1997 - 2003	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
E-Series	4. 6L	2V	2003	ECS	●	●	●	●	○
E-Series	4. 6L	2V	2003 - 2007	ABS/TCS	●	●	●	●	0008 001B
E-Series	4. 6L	2V	2003 - 2013	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
E-Series	4. 6L	2V	2004 - 2006	RAP	●	●	●	●	000A 000F
E-Series	4. 6L	2V	2004 - 2008	IC	●	●	●	●	0005 0009
E-Series	4. 6L	2V	2004 - 2013	RCM	●	●	●	●	○
E-Series	4. 6L	2V	2006 - 2013	ABS	●	●	●	●	0008 0012
E-Series	4. 6L	2V	2007 - 2008	VSM	●	●	●	●	000A 0042
E-Series	4. 6L	2V	2007 - 2013	PAM	●	●	●	●	○
E-Series	4. 6L	2V	2009 - 2011	GEM / SJB	●	●	●	●	000A 0042
E-Series	4. 6L	2V	2009 - 2013	ACM	●	●	●	●	0017 0018
E-Series	4. 6L	2V	2009 - 2013	IPC	●	●	●	●	○
E-Series	4. 6L	2V	2009 - 2013	TBC	●	●	●	●	○
E-Series	4. 6L	2V	2010 - 2013	APIM	●	●	●	●	0019
E-Series	4. 6L	2V	2010 - 2013	GPSM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
E-Series	4. 6L	2V	2010 - 2013	SDARS	●	●	●	●	○
E-Series	4. 6L	Other	1997 - 2002	ABS/TCS	●	●	●	●	0008
E-Series	4. 6L	Other	1997 - 2002	ECS	●	●	●	●	○
E-Series	4. 6L	Other	1997 - 2002	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
E-Series	4. 9L	GFP	1996	ABS/TCS	●	●	●	●	0008
E-Series	4. 9L	GFP	1996	PCM	●	●	●	●	0023
E-Series	4. 9L	Other	1996	ABS/TCS	●	●	●	●	0008
E-Series	4. 9L	Other	1996	PCM	●	●	●	●	0023 0025
E-Series	5. 0L	Other	1996	ABS/TCS	●	●	●	●	0008
E-Series	5. 0L	Other	1996	PCM	●	●	●	●	0023 0025
E-Series	5. 4L	2V	2004	AFCM	●	●	●	●	○
E-Series	5. 4L	2V	2004 - 2006	RAP	●	●	●	●	000A 000F
E-Series	5. 4L	2V	2004 - 2007	ABS/TCS	●	●	●	●	0008 001B
E-Series	5. 4L	2V	2004 - 2008	IC	●	●	●	●	0005 0009
E-Series	5. 4L	2V	2004 - 2013	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
E-Series	5. 4L	2V	2004 - 2013	RCM	●	●	●	●	0005
E-Series	5. 4L	2V	2006 - 2013	ABS	●	●	●	●	0008 0012
E-Series	5. 4L	2V	2007 - 2008	VSM	●	●	●	●	000A 0042
E-Series	5. 4L	2V	2007 - 2013	PAM	●	●	●	●	○
E-Series	5. 4L	2V	2009 - 2012	GEM / SJB	●	●	●	●	000A 0042
E-Series	5. 4L	2V	2009 - 2013	ACM	●	●	●	●	○
E-Series	5. 4L	2V	2009 - 2013	IPC	●	●	●	●	○
E-Series	5. 4L	2V	2009 - 2013	TBC	●	●	●	●	○
E-Series	5. 4L	2V	2010 - 2013	APIM	●	●	●	●	○
E-Series	5. 4L	2V	2010 - 2013	GPSM	●	●	●	○	○
E-Series	5. 4L	2V	2010 - 2013	SDARS	●	●	●	●	○
E-Series	5. 4L	BIF	1999	ABS/TCS	●	●	●	●	0008
E-Series	5. 4L	BIF	1999	AFCM	●	●	●	●	○
E-Series	5. 4L	BIF	1999	ECS	●	●	●	●	○
E-Series	5. 4L	BIF	1999	PCM	●	●	●	●	0023
E-Series	5. 4L	NGV	1997 - 2000	ABS/TCS	●	●	●	●	0008
E-Series	5. 4L	NGV	1997 - 2000	ECS	●	●	●	●	○
E-Series	5. 4L	NGV	1997 - 2000	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
E-Series	5.4L	NGV	1998 - 2000	FIM	●	●	●	●	○
E-Series	5.4L	Other	1997 - 2003	ABS/TCS	●	●	●	●	0008
E-Series	5.4L	Other	1997 - 2003	ECS	●	●	●	●	○
E-Series	5.4L	Other	1997 - 2003	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
E-Series	5.8L	Other	1996	ABS/TCS	●	●	●	●	0008
E-Series	5.8L	Other	1996	PCM	●	●	●	●	0023 0025
E-Series	6.0L	Direct Injection - Turbo	2004 - 2006	RAP	●	●	●	●	000A 000F
E-Series	6.0L	Direct Injection - Turbo	2004 - 2007	ABS/TCS	●	●	●	●	0008 001B
E-Series	6.0L	Direct Injection - Turbo	2004 - 2008	IC	●	●	●	●	0005 0009
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	PCM	●	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	RCM	●	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	TCM	●	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2006 - 2010	ABS	●	●	●	●	0008 0012 0005
E-Series	6.0L	Direct Injection - Turbo	2007 - 2008	VSM	●	●	●	●	000A 0042
E-Series	6.0L	Direct Injection - Turbo	2007 - 2010	PAM	●	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	ACM	●	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	GEM / SJB	●	●	●	●	000A 0042
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	IPC	●	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	TBC	●	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2010	APIM	●	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2010	GPSM	●	●	●	○	○
E-Series	6.0L	Direct Injection - Turbo	2010	SDARS	●	●	●	●	○
E-Series	6.8L	2V	2004 - 2006	RAP	●	●	●	●	000A 000F
E-Series	6.8L	2V	2004 - 2007	ABS/TCS	●	●	●	●	0008 001B
E-Series	6.8L	2V	2004 - 2008	IC	●	●	●	●	0009
E-Series	6.8L	2V	2004 - 2012	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
E-Series	6.8L	2V	2004 - 2012	RCM	●	●	●	●	○
E-Series	6.8L	2V	2006 - 2012	ABS	●	●	●	●	0008 0012 0005
E-Series	6.8L	2V	2007 - 2008	VSM	●	●	●	●	000A 0042
E-Series	6.8L	2V	2007 - 2012	PAM	●	●	●	●	○
E-Series	6.8L	2V	2009 - 2012	ACM	●	●	●	●	0017 0018
E-Series	6.8L	2V	2009 - 2012	GEM / SJB	●	●	●	●	000A 0042
E-Series	6.8L	2V	2009 - 2012	IPC	●	●	●	●	○
E-Series	6.8L	2V	2009 - 2012	TBC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
E-Series	6. 8L	2V	2010 - 2012	APIM	●	●	●	●	0019
E-Series	6. 8L	2V	2010 - 2012	GPSM	●	●	●	○	○
E-Series	6. 8L	2V	2010 - 2012	SDARS	●	●	●	●	○
E-Series	6. 8L	Other	1997 - 2003	ABS/TCS	●	●	●	●	0008
E-Series	6. 8L	Other	1997 - 2003	ECS	●	●	●	●	○
E-Series	6. 8L	Other	1997 - 2003	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
E-Series	7. 3L	Direct Injection - Turbo	1995 - 2003	ABS/TCS	●	●	●	●	0008
E-Series	7. 3L	Direct Injection - Turbo	1995 - 2003	PCM	●	●	●	●	0025 0010 0028 0031
E-Series	7. 3L	Direct Injection - Turbo	1997 - 2003	ECS	●	●	●	●	○
E-Series	7. 5L	Other	1996	ABS/TCS	●	●	●	●	0008
E-Series	7. 5L	Other	1996	PCM	●	●	●	●	0023 0025
E-Series	Other	Other	2012	ABS	●	●	●	●	○
E-Series	Other	Other	2012	ACM	●	●	●	●	○
E-Series	Other	Other	2012	APIM	●	●	●	●	○
E-Series	Other	Other	2012	GEM / SJB	●	●	●	●	0042
E-Series	Other	Other	2012	GPSM	●	●	●	●	○
E-Series	Other	Other	2012	IPC	●	●	●	●	○
E-Series	Other	Other	2012	PAM	●	●	●	●	○
E-Series	Other	Other	2012	PCM	●	●	●	●	○
E-Series	Other	Other	2012	RCM	●	●	●	●	○
E-Series	Other	Other	2012	SDARS	●	●	●	●	○
E-Series	Other	Other	2012	TBC	●	●	●	●	○
E-Series Shuttle Bus	6. 8L	H2ICE	2006	ABS/TCS	●	●	●	●	○
E-Series Shuttle Bus	6. 8L	H2ICE	2006	AFCM	●	●	●	●	○
E-Series Shuttle Bus	6. 8L	H2ICE	2006	EMM	●	●	●	●	○
E-Series Shuttle Bus	6. 8L	H2ICE	2006	IC	●	●	●	●	○
E-Series Shuttle Bus	6. 8L	H2ICE	2006	PCM	●	●	●	●	0023
E-Series Shuttle Bus	6. 8L	H2ICE	2006	RCM	●	●	●	●	○
EcoSport	1. 6L	FFV	2003	ABS/TCS	●	●	●	●	0008 000B
EcoSport	1. 6L	FFV	2003	GEM	●	●	●	●	○
EcoSport	1. 6L	FFV	2003	IC	●	●	●	●	○
EcoSport	1. 6L	FFV	2003	PCM	●	●	●	●	0009 0025
EcoSport	1. 6L	FFV	2003	RCM	●	●	●	●	○
EcoSport	1. 6L	FFV	2003	RKE	●	●	●	●	000A
EcoSport	2. 0L	DURATEC-HE / I4	2006	ABS/TCS	●	●	●	●	0008 000B

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
EcoSport	2.0L	DURATEC-HE / I4	2006	GEM	●	●	●	●	○
EcoSport	2.0L	DURATEC-HE / I4	2006	IC	●	●	●	●	○
EcoSport	2.0L	DURATEC-HE / I4	2006	PCM	●	●	●	●	0009 0025
EcoSport	2.0L	DURATEC-HE / I4	2006	RCM	●	●	●	●	○
EcoSport	2.0L	DURATEC-HE / I4	2006	RKE	●	●	●	●	000A
Escort	1.3L	Endura-E	1995 - 1998	ABS	●	●	●	●	○
Escort	1.3L	Endura-E	1995 - 1998	ABS/TCS	●	●	●	●	○
Escort	1.3L	Endura-E	1995 - 1998	CSM	●	●	●	●	○
Escort	1.3L	Endura-E	1995 - 1998	HEC	●	●	●	●	○
Escort	1.3L	Endura-E	1995 - 1998	PATS	●	●	●	●	○
Escort	1.3L	Endura-E	1995 - 1998	PCM	●	●	●	●	0023 0025
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	ABS/TCS	●	●	●	●	○
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	CSM	●	●	●	●	○
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	HEC	●	●	●	●	○
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	PATS	●	●	●	●	○
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	PCM	●	●	●	●	○
Escort	1.4L	1.4 PT-E SFI	1995 - 1998	ABS	●	●	●	●	○
Escort	1.6L	PT-E	Other	ABS/TCS	●	●	●	●	○
Escort	1.6L	PT-E	Other	CSM	●	●	●	●	○
Escort	1.6L	PT-E	Other	HEC	●	●	●	●	○
Escort	1.6L	PT-E	Other	PATS	●	●	●	●	○
Escort	1.6L	PT-E	Other	PCM	●	●	●	●	○
Escort	1.6L	Zetec	1993 - 1997	PCM	●	●	●	●	0025
Escort	1.6L	Zetec	1993 - 1998	ABS/TCS	●	●	●	●	○
Escort	1.6L	Zetec	1993 - 1998	CSM	●	●	●	●	○
Escort	1.6L	Zetec	1993 - 1998	HEC	●	●	●	●	○
Escort	1.6L	Zetec	1993 - 1998	PATS	●	●	●	●	○
Escort	1.6L	Zetec	1995 - 1998	ABS	●	●	●	●	○
Escort	1.6L	Zetec Rocam	2000	ABS/TCS	●	●	●	●	○
Escort	1.6L	Zetec Rocam	2000	CSM	●	●	●	●	○
Escort	1.6L	Zetec Rocam	2000	HEC	●	●	●	●	○
Escort	1.6L	Zetec Rocam	2000	PATS	●	●	●	●	○
Escort	1.6L	Zetec Rocam	2000	PCM	●	●	●	●	0023 0025
Escort	1.8L	Endura-DE	1996 -	ABS/TCS	●	●	●	●	○
Escort	1.8L	Endura-DE	1996 -	CSM	●	●	●	●	○
Escort	1.8L	Endura-DE	1996 -	HEC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escort	1. 8L	Endura-DE	1996 -	PATS	●	●	●	●	○
Escort	1. 8L	Endura-DE	1996 -	PCM	●	●	●	●	○
Escort	1. 8L	Endura-DE	1997	ABS	●	●	●	●	○
Escort	1. 8L	Other	1996	ABS/TCS	●	●	●	●	○
Escort	1. 8L	Other	1996	CSM	●	●	●	●	○
Escort	1. 8L	Other	1996	HEC	●	●	●	●	○
Escort	1. 8L	Other	1996	PATS	●	●	●	●	○
Escort	1. 8L	Other	1996	PCM	●	●	●	●	○
Escort	1. 8L	Zetec	1992 - 1996	PCM	●	●	●	●	0025
Escort	1. 8L	Zetec	1992 - 1998	ABS/TCS	●	●	●	●	○
Escort	1. 8L	Zetec	1992 - 1998	CSM	●	●	●	●	○
Escort	1. 8L	Zetec	1992 - 1998	HEC	●	●	●	●	○
Escort	1. 8L	Zetec	1992 - 1998	PATS	●	●	●	●	○
Escort	1. 8L	Zetec	1995 - 1998	ABS	●	●	●	●	○
Escort	1. 9L	Other	1996	ABS/TCS	●	●	●	●	○
Escort	1. 9L	Other	1996	PATS	●	●	●	●	○
Escort	1. 9L	Other	1996	PCM	●	●	●	●	0023 0025
Escort	2. 0L	DOHC Cosworth	1994 - 1995	ABS/TCS	●	●	●	●	○
Escort	2. 0L	DOHC Cosworth	1994 - 1995	PATS	●	●	●	●	○
Escort	2. 0L	DOHC Cosworth	1994 - 1995	PCM	●	●	●	●	○
Escort	2. 0L	DOHC Cosworth	1995	ABS	●	●	●	●	○
Escort	2. 0L	SPI	1997 - 2002	ABS/TCS	●	●	●	●	0008
Escort	2. 0L	SPI	1997 - 2002	PATS	●	●	●	●	○
Escort	2. 0L	SPI	1997 - 2002	PCM	●	●	●	●	0023 0025
Escort	2. 0L	SPI	1997 - 2002	RAP	●	●	●	●	000A
Escort	2. 0L	SPI	1998 - 1999	ABS	●	●	●	●	0008
Escort	2. 0L	SPI	1998 - 2002	ECS	●	●	●	●	○
Escort	2. 0L	Zetec	1998 - 1999	ABS	●	●	●	●	0008
Escort	2. 0L	Zetec	1998 - 2003	ABS/TCS	●	●	●	●	0008
Escort	2. 0L	Zetec	1998 - 2003	ECS	●	●	●	●	○
Escort	2. 0L	Zetec	1998 - 2003	PATS	●	●	●	●	○
Escort	2. 0L	Zetec	1998 - 2003	PCM	●	●	●	●	0023 0025
Escort	2. 0L	Zetec	1998 - 2003	RAP	●	●	●	●	000A
Excursion	5. 4L	2V	2004	ECS	●	●	●	●	○
Excursion	5. 4L	2V	2004 - 2005	ABS/TCS	●	●	●	●	0008
Excursion	5. 4L	2V	2004 - 2005	DSM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Excursion	5. 4L	2V	2004 - 2005	EATC	●	●	●	●	○
Excursion	5. 4L	2V	2004 - 2005	GEM	●	●	●	●	○
Excursion	5. 4L	2V	2004 - 2005	HEC	●	●	●	●	○
Excursion	5. 4L	2V	2004 - 2005	OTC	●	●	●	●	○
Excursion	5. 4L	2V	2004 - 2005	PAM	●	●	●	●	○
Excursion	5. 4L	2V	2004 - 2005	PATS	●	●	●	●	0009
Excursion	5. 4L	2V	2004 - 2005	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Excursion	5. 4L	2V	2004 - 2005	VSM	●	●	●	●	000A 000F
Excursion	5. 4L	2V	2005	RCM	●	●	●	●	○
Excursion	5. 4L	Other	2000	MC	●	●	●	●	○
Excursion	5. 4L	Other	2000 - 2003	ABS/TCS	●	●	●	●	0008
Excursion	5. 4L	Other	2000 - 2003	ECS	●	●	●	●	○
Excursion	5. 4L	Other	2000 - 2003	GEM	●	●	●	●	000F
Excursion	5. 4L	Other	2000 - 2003	PAM	●	●	●	●	○
Excursion	5. 4L	Other	2000 - 2003	PATS	●	●	●	●	0009
Excursion	5. 4L	Other	2000 - 2003	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Excursion	5. 4L	Other	2002	CSM	●	●	●	●	000A 000F
Excursion	5. 4L	Other	2002 - 2003	DSM	●	●	●	●	○
Excursion	5. 4L	Other	2002 - 2003	EATC	●	●	●	●	○
Excursion	5. 4L	Other	2002 - 2003	HEC	●	●	●	●	○
Excursion	5. 4L	Other	2002 - 2003	OTC	●	●	●	●	○
Excursion	5. 4L	Other	2003	FOH	●	●	●	●	○
Excursion	5. 4L	Other	2003	VSM	●	●	●	●	000A 000F
Excursion	6. 0L	Direct Injection - Turbo	2003	FOH	●	●	●	●	○
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2004	ECS	●	●	●	●	○
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2005	ABS/TCS	●	●	●	●	0008
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2005	DSM	●	●	●	●	○
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2005	EATC	●	●	●	●	○
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2005	GEM	●	●	●	●	○
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2005	HEC	●	●	●	●	○
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2005	OTC	●	●	●	●	○
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2005	PAM	●	●	●	●	○
Excursion	6. 0L	Direct Injection - Turbo	2003 - 2005	PATS	●	●	●	●	0009

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	TCM	●	●	●	●	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	VSM	●	●	●	●	000A 000F
Excursion	6.0L	Direct Injection - Turbo	2005	RCM	●	●	●	●	○
Excursion	6.8L	2V	2004	ECS	●	●	●	●	○
Excursion	6.8L	2V	2004 - 2005	ABS/TCS	●	●	●	●	0008
Excursion	6.8L	2V	2004 - 2005	DSM	●	●	●	●	○
Excursion	6.8L	2V	2004 - 2005	EATC	●	●	●	●	○
Excursion	6.8L	2V	2004 - 2005	GEM	●	●	●	●	○
Excursion	6.8L	2V	2004 - 2005	HEC	●	●	●	●	○
Excursion	6.8L	2V	2004 - 2005	OTC	●	●	●	●	○
Excursion	6.8L	2V	2004 - 2005	PAM	●	●	●	●	○
Excursion	6.8L	2V	2004 - 2005	PATS	●	●	●	●	0009
Excursion	6.8L	2V	2004 - 2005	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Excursion	6.8L	2V	2004 - 2005	VSM	●	●	●	●	000A 000F
Excursion	6.8L	2V	2005	RCM	●	●	●	●	○
Excursion	6.8L	Other	2000	MC	●	●	●	●	○
Excursion	6.8L	Other	2000 - 2003	ABS/TCS	●	●	●	●	0008
Excursion	6.8L	Other	2000 - 2003	ECS	●	●	●	●	○
Excursion	6.8L	Other	2000 - 2003	GEM	●	●	●	●	000F
Excursion	6.8L	Other	2000 - 2003	PAM	●	●	●	●	○
Excursion	6.8L	Other	2000 - 2003	PATS	●	●	●	●	0009
Excursion	6.8L	Other	2000 - 2003	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Excursion	6.8L	Other	2002	CSM	●	●	●	●	000A 000F
Excursion	6.8L	Other	2002 - 2003	DSM	●	●	●	●	○
Excursion	6.8L	Other	2002 - 2003	EATC	●	●	●	●	○
Excursion	6.8L	Other	2002 - 2003	HEC	●	●	●	●	○
Excursion	6.8L	Other	2002 - 2003	OTC	●	●	●	●	○
Excursion	6.8L	Other	2003	FOH	●	●	●	●	○
Excursion	6.8L	Other	2003	VSM	●	●	●	●	000A 000F
Excursion	7.3L	Direct Injection - Turbo	2000	MC	●	●	●	●	○
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	ABS/TCS	●	●	●	●	0008
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	ECS	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	GEM	●	●	●	●	000F
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PAM	●	●	●	●	○
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PATS	●	●	●	●	0009
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PCM	●	●	●	●	0010 0025 0028 0031
Excursion	7.3L	Direct Injection - Turbo	2002	CSM	●	●	●	●	000A 000F
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	DSM	●	●	●	●	○
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	EATC	●	●	●	●	○
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	HEC	●	●	●	●	○
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	OTC	●	●	●	●	○
Excursion	7.3L	Direct Injection - Turbo	2003	FOH	●	●	●	●	○
Excursion	7.3L	Direct Injection - Turbo	2003	VSM	●	●	●	●	000A 000F
Expedition	4.6L	2V	2003 - 2004	4X4	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	ABS/TCS	●	●	●	●	0008 0012
Expedition	4.6L	2V	2003 - 2004	DCSM	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	DSM	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	EATC	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	HEC	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	PAM	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033 0033
Expedition	4.6L	2V	2003 - 2004	PCSM	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	RCM	●	●	●	●	000C
Expedition	4.6L	2V	2003 - 2004	TPM	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	VDM	●	●	●	●	○
Expedition	4.6L	2V	2003 - 2004	VSM	●	●	●	●	000A 000F
Expedition	4.6L	Other	1997 - 1998	IAB	●	●	●	●	○
Expedition	4.6L	Other	1997 - 1998	PATS	●	●	●	●	0009
Expedition	4.6L	Other	1997 - 2000	4WAS	●	●	●	●	000E
Expedition	4.6L	Other	1997 - 2000	ABS/TCS	●	●	●	●	0008
Expedition	4.6L	Other	1997 - 2000	GEM	●	●	●	●	○
Expedition	4.6L	Other	1997 - 2000	PCM	●	●	●	●	0023 0025
Expedition	4.6L	Other	1997 - 2000	RAP	●	●	●	●	000A 000F
Expedition	4.6L	Other	1998	RCC	●	●	●	●	○
Expedition	4.6L	Other	1999 - 2000	EATC	●	●	●	●	○
Expedition	4.6L	Other	1999 - 2000	HEC	●	●	●	●	0009
Expedition	4.6L	Other	1999 - 2000	RCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Expedition	4. 6L	Other	2000	DSM	●	●	●	●	○
Expedition	4. 6L	Other	2000	PAM	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	4X4	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	ABS/TCS	●	●	●	●	0008 0012
Expedition	5. 4L	2V	2003 - 2004	DCSM	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	DSM	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	EATC	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	HEC	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	PAM	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033 0033
Expedition	5. 4L	2V	2003 - 2004	PCSM	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	RCM	●	●	●	●	000C
Expedition	5. 4L	2V	2003 - 2004	TPM	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	VDM	●	●	●	●	○
Expedition	5. 4L	2V	2003 - 2004	VSM	●	●	●	●	000A 000F
Expedition	5. 4L	3V	2005 - 2006	VSM	●	●	●	●	000A 000F
Expedition	5. 4L	3V	2005 - 2007	EATC	●	●	●	●	○
Expedition	5. 4L	3V	2005 - 2010	4X4	●	●	●	●	○
Expedition	5. 4L	3V	2005 - 2012	ABS	●	●	●	●	0012 0008 0005
Expedition	5. 4L	3V	2005 - 2012	DCSM	●	●	●	●	○
Expedition	5. 4L	3V	2005 - 2012	DSM	●	●	●	●	0005
Expedition	5. 4L	3V	2005 - 2012	IC	●	●	●	●	0009 0005
Expedition	5. 4L	3V	2005 - 2012	PAM	●	●	●	●	0005
Expedition	5. 4L	3V	2005 - 2012	PCM	●	●	●	●	0009
Expedition	5. 4L	3V	2005 - 2012	RCM	●	●	●	●	000C 0005
Expedition	5. 4L	3V	2005 - 2012	VDM	●	●	●	●	000E 0013 0014
Expedition	5. 4L	3V	2007	GEM	●	●	●	●	○
Expedition	5. 4L	3V	2007 - 2011	TCM	●	●	●	●	0025
Expedition	5. 4L	3V	2007 - 2012	ACM	●	●	●	●	0005 0016 0017 0018
Expedition	5. 4L	3V	2007 - 2012	DSP	●	●	●	●	○
Expedition	5. 4L	3V	2007 - 2012	LTM	●	●	●	●	○
Expedition	5. 4L	3V	2007 - 2012	RCU	●	●	●	●	○
Expedition	5. 4L	3V	2007 - 2012	RETM	●	●	●	●	0005 0018
Expedition	5. 4L	3V	2007 - 2012	SDARS	●	●	●	●	0005
Expedition	5. 4L	3V	2008 - 2012	GEM / SJB	●	●	●	●	000A 000F 0042

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.
 As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Expedition	5.4L	3V	2008 - 2012	HVAC	●	●	●	●	○
Expedition	5.4L	3V	2008 - 2012	PRB	●	●	●	●	○
Expedition	5.4L	3V	2009 - 2012	APIM	●	●	●	●	○
Expedition	5.4L	3V	2010 - 2012	GPSM	●	●	●	○	○
Expedition	5.4L	3V	2010 - 2012	TCCM	●	●	●	●	○
Expedition	5.4L	Other	1997 - 1998	IAB	●	●	●	●	○
Expedition	5.4L	Other	1997 - 1998	PATS	●	●	●	●	0009
Expedition	5.4L	Other	1997 - 2000	4WAS	●	●	●	●	000E
Expedition	5.4L	Other	1997 - 2000	ABS/TCS	●	●	●	●	0008
Expedition	5.4L	Other	1997 - 2000	GEM	●	●	●	●	○
Expedition	5.4L	Other	1997 - 2000	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
Expedition	5.4L	Other	1997 - 2000	RAP	●	●	●	●	000A 000F
Expedition	5.4L	Other	1998	RCC	●	●	●	●	○
Expedition	5.4L	Other	1999 - 2000	EATC	●	●	●	●	○
Expedition	5.4L	Other	1999 - 2000	HEC	●	●	●	●	0009
Expedition	5.4L	Other	1999 - 2000	RCM	●	●	●	●	○
Expedition	5.4L	Other	2000	DSM	●	●	●	●	○
Expedition	5.4L	Other	2000	PAM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	TPM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ABS	●	●	●	●	0008 0012
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ACM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	APIM	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ATCM	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	BCM#1	●	●	●	○	000A 000F 0042
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	C-CM	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	CLM#1	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DCSM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DSM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DSP	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCDIM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCIM	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FLM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	GPSM	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HSWM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HUD	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HVAC	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPC	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	LTM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	OCSM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PAM	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PSCM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RCM	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RFA	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RLCM-A	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SCCM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SOD-L	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SOD-R	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	TCM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	●	●	●	●	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●	●	0008 0012
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	ATCM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●	○	000A 000F 0042
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	CLM#1	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	DCSM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FLM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	LTM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●	●	0023 0025
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RFA	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RLCM-A	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	●	●	●	●	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	●	●	●	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2012	TPM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	ABS	●	●	●	●	0008 0012
Explorer	3.5L	TiVCT	2011 - 2013	ACM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	APIM	●	●	●	○	○
Explorer	3.5L	TiVCT	2011 - 2013	ATCM	●	●	●	○	○
Explorer	3.5L	TiVCT	2011 - 2013	BCM#1	●	●	●	○	000A 000F 0042
Explorer	3.5L	TiVCT	2011 - 2013	C-CM	●	●	●	○	○
Explorer	3.5L	TiVCT	2011 - 2013	CLM#1	●	●	●	○	○
Explorer	3.5L	TiVCT	2011 - 2013	DCSM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	DSM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	DSP	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	FCDIM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	FCIM	●	●	●	○	○
Explorer	3.5L	TiVCT	2011 - 2013	FLM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	GPSM	●	●	●	○	○
Explorer	3.5L	TiVCT	2011 - 2013	HSWM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	HUD	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	HVAC	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	IPC	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	LTM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	OCSM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	PAM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Explorer	3.5L	TiVCT	2011 - 2013	PCM	●	●	●	●	0023 0025
Explorer	3.5L	TiVCT	2011 - 2013	PSCM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	RCM	●	●	●	○	○
Explorer	3.5L	TiVCT	2011 - 2013	RFA	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	RLCM-A	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	SCCM	●	●	●	●	○
Explorer	3.5L	TiVCT	2011 - 2013	SOD-L	●	●	●	○	○
Explorer	3.5L	TiVCT	2011 - 2013	SOD-R	●	●	●	●	○
Explorer	3.5L	TiVCT	2013	GFM	●	●	●	●	○
Explorer	3.5L	TiVCT	2013	IPM-A	●	●	●	○	○
Explorer	3.5L	TiVCT	2013	RTM	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	ABS	●	●	●	●	0008 0012
Explorer	3.7L	TiVCT	2013	ACM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	APIM	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	ATCM	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	BCM#1	●	●	●	○	000A 000F 0042
Explorer	3.7L	TiVCT	2013	C-CM	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	CLM#1	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	DCSM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	DSM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	DSP	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	FCDIM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	FCIM	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	FLM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	GFM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	GPSM	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	HSWM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	HUD	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	HVAC	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	IPC	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	IPM-A	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	LTM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	OCSM	●	●	●	●	○
Explorer	3.7L	TiVCT	2013	PAM	●	●	●	○	○
Explorer	3.7L	TiVCT	2013	PCM	●	●	●	●	0023 0025
Explorer	3.7L	TiVCT	2013	PSCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Explorer	3. 7L	TiVCT	2013	RCM	●	●	●	○	○
Explorer	3. 7L	TiVCT	2013	RFA	●	●	●	●	○
Explorer	3. 7L	TiVCT	2013	RLCM-A	●	●	●	●	○
Explorer	3. 7L	TiVCT	2013	RTM	●	●	●	○	○
Explorer	3. 7L	TiVCT	2013	SCCM	●	●	●	●	○
Explorer	3. 7L	TiVCT	2013	SOD-L	●	●	●	○	○
Explorer	3. 7L	TiVCT	2013	SOD-R	●	●	●	●	○
Explorer	4. 0L	2V	2006 - 2007	EATC	●	●	●	●	○
Explorer	4. 0L	2V	2006 - 2007	GEM	●	●	●	●	000A 000F
Explorer	4. 0L	2V	2006 - 2010	4X4	●	●	●	●	○
Explorer	4. 0L	2V	2006 - 2010	ABS	●	●	●	●	0008 0012 0005
Explorer	4. 0L	2V	2006 - 2010	ACM	●	●	●	●	0005
Explorer	4. 0L	2V	2006 - 2010	DSM	●	●	●	●	0005
Explorer	4. 0L	2V	2006 - 2010	IC	●	●	●	●	0009 0005
Explorer	4. 0L	2V	2006 - 2010	OCSM	●	●	●	○	000C 0015
Explorer	4. 0L	2V	2006 - 2010	PAM	●	●	●	●	○
Explorer	4. 0L	2V	2006 - 2010	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033 00C6
Explorer	4. 0L	2V	2006 - 2010	PRB	●	●	●	●	○
Explorer	4. 0L	2V	2006 - 2010	RCM	●	●	●	●	0005
Explorer	4. 0L	2V	2006 - 2010	RETM	●	●	●	●	○
Explorer	4. 0L	2V	2006 - 2010	SDARS	●	●	●	●	0005
Explorer	4. 0L	2V	2008 - 2010	APIM	●	●	●	●	○
Explorer	4. 0L	2V	2008 - 2010	GEM / SJB	●	●	●	●	0005 000A 000F 0042
Explorer	4. 0L	2V	2008 - 2010	HVAC	●	●	●	●	0005
Explorer	4. 0L	2V	2010	GPSM	●	●	●	○	○
Explorer	4. 0L	Other	1996 - 1998	IAB	●	●	●	●	○
Explorer	4. 0L	Other	1996 - 2000	ABS/TCS	●	●	●	●	0008
Explorer	4. 0L	Other	1996 - 2000	ARC	●	●	●	●	○
Explorer	4. 0L	Other	1996 - 2000	EATC	●	●	●	●	○
Explorer	4. 0L	Other	1996 - 2000	GEM	●	●	●	●	○
Explorer	4. 0L	Other	1996 - 2000	PCM	●	●	●	●	0023 0025
Explorer	4. 0L	Other	1996 - 2000	RAP	●	●	●	●	000F 000A
Explorer	4. 0L	Other	1998 - 2000	DSM	●	●	●	●	○
Explorer	4. 0L	Other	1998 - 2000	PAM	●	●	●	●	○
Explorer	4. 0L	Other	1998 - 2000	PATS	●	●	●	●	0009

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Explorer	4.0L	Other	1999 - 2000	RCM	●	●	●	●	○
Explorer	4.0L	V6 OHV	1996 - 1998	IAB	●	●	●	●	○
Explorer	4.0L	V6 OHV	1996 - 1999	ABS/TCS	●	●	●	●	0008
Explorer	4.0L	V6 OHV	1996 - 1999	ARC	●	●	●	●	○
Explorer	4.0L	V6 OHV	1996 - 1999	EATC	●	●	●	●	○
Explorer	4.0L	V6 OHV	1996 - 1999	GEM	●	●	●	●	○
Explorer	4.0L	V6 OHV	1996 - 1999	PCM	●	●	●	●	0023 0025
Explorer	4.0L	V6 OHV	1996 - 1999	RAP	●	●	●	●	000F 000A
Explorer	4.0L	V6 OHV	1998 - 1999	DSM	●	●	●	●	○
Explorer	4.0L	V6 OHV	1998 - 1999	PAM	●	●	●	●	○
Explorer	4.0L	V6 OHV	1998 - 1999	PATS	●	●	●	●	0009
Explorer	4.0L	V6 OHV	1999	RCM	●	●	●	●	○
Explorer	4.0L	V6 SOHC	1997 - 1998	IAB	●	●	●	●	○
Explorer	4.0L	V6 SOHC	1997 - 2000	ARC	●	●	●	●	000E
Explorer	4.0L	V6 SOHC	1997 - 2000	RAP	●	●	●	●	000A 000F
Explorer	4.0L	V6 SOHC	1997 - 2002	GEM	●	●	●	●	○
Explorer	4.0L	V6 SOHC	1997 - 2003	ABS/TCS	●	●	●	●	0008 0012
Explorer	4.0L	V6 SOHC	1997 - 2005	EATC	●	●	●	●	0005
Explorer	4.0L	V6 SOHC	1997 - 2005	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033 0009 00C6
Explorer	4.0L	V6 SOHC	1998 - 2000	PATS	●	●	●	●	0009
Explorer	4.0L	V6 SOHC	1998 - 2005	DSM	●	●	●	●	○
Explorer	4.0L	V6 SOHC	1998 - 2005	PAM	●	●	●	●	○
Explorer	4.0L	V6 SOHC	1999	MC	●	●	●	●	○
Explorer	4.0L	V6 SOHC	1999 - 2005	RCM	●	●	●	●	000C
Explorer	4.0L	V6 SOHC	2002	CSM	●	●	●	●	000F
Explorer	4.0L	V6 SOHC	2002 - 2003	HEC	●	●	●	●	○
Explorer	4.0L	V6 SOHC	2002 - 2005	4X4	●	●	●	●	○
Explorer	4.0L	V6 SOHC	2002 - 2005	IC	●	●	●	●	0005
Explorer	4.0L	V6 SOHC	2002 - 2005	TPM	●	●	●	●	0005
Explorer	4.0L	V6 SOHC	2003 - 2005	VSM	●	●	●	●	000A 000F
Explorer	4.0L	V6 SOHC	2004 - 2005	ABS	●	●	●	●	0008 0012 0005
Explorer	4.6L	2V	2002	CSM	●	●	●	●	000F
Explorer	4.6L	2V	2002	GEM	●	●	●	●	○
Explorer	4.6L	2V	2002 - 2003	ABS/TCS	●	●	●	●	0008 0012
Explorer	4.6L	2V	2002 - 2003	HEC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Explorer	4. 6L	2V	2002 - 2005	4X4	●	●	●	●	○
Explorer	4. 6L	2V	2002 - 2005	DSM	●	●	●	●	○
Explorer	4. 6L	2V	2002 - 2005	EATC	●	●	●	●	0005
Explorer	4. 6L	2V	2002 - 2005	IC	●	●	●	●	0005
Explorer	4. 6L	2V	2002 - 2005	PAM	●	●	●	●	○
Explorer	4. 6L	2V	2002 - 2005	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033 00C6
Explorer	4. 6L	2V	2002 - 2005	RCM	●	●	●	●	000C
Explorer	4. 6L	2V	2002 - 2005	TPM	●	●	●	●	0005
Explorer	4. 6L	2V	2003 - 2005	VSM	●	●	●	●	000A 000F
Explorer	4. 6L	2V	2004 - 2005	ABS	●	●	●	●	0008 0012
Explorer	4. 6L	3V	2006 - 2007	EATC	●	●	●	●	0005
Explorer	4. 6L	3V	2006 - 2007	GEM	●	●	●	●	0005 000A 000F
Explorer	4. 6L	3V	2006 - 2010	4X4	●	●	●	●	○
Explorer	4. 6L	3V	2006 - 2010	ABS	●	●	●	●	0005 0008 0012
Explorer	4. 6L	3V	2006 - 2010	ACM	●	●	●	●	0005
Explorer	4. 6L	3V	2006 - 2010	DSM	●	●	●	●	0005
Explorer	4. 6L	3V	2006 - 2010	IC	●	●	●	●	0009 0005
Explorer	4. 6L	3V	2006 - 2010	OCSM	●	●	●	○	000C 0015
Explorer	4. 6L	3V	2006 - 2010	PAM	●	●	●	●	0005
Explorer	4. 6L	3V	2006 - 2010	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033 00C5 00C6
Explorer	4. 6L	3V	2006 - 2010	PRB	●	●	●	●	○
Explorer	4. 6L	3V	2006 - 2010	RCM	●	●	●	●	0005
Explorer	4. 6L	3V	2006 - 2010	RETM	●	●	●	●	0005
Explorer	4. 6L	3V	2006 - 2010	SDARS	●	●	●	●	0005
Explorer	4. 6L	3V	2006 - 2010	TCM	●	●	●	●	0025
Explorer	4. 6L	3V	2008 - 2010	APIM	●	●	●	●	○
Explorer	4. 6L	3V	2008 - 2010	GEM / SJB	●	●	●	●	000A 000F 0042 0005
Explorer	4. 6L	3V	2008 - 2010	HVAC	●	●	●	●	0005
Explorer	4. 6L	3V	2010	GPSM	●	●	●	○	○
Explorer	5. 0L	Other	1996 - 1998	IAB	●	●	●	●	○
Explorer	5. 0L	Other	1996 - 2000	ABS/TCS	●	●	●	●	0008
Explorer	5. 0L	Other	1996 - 2000	EATC	●	●	●	●	○
Explorer	5. 0L	Other	1996 - 2000	GEM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Explorer	5.0L	Other	1996 - 2000	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
Explorer	5.0L	Other	1996 - 2000	RAP	●	●	●	●	000F 000A
Explorer	5.0L	Other	1997 - 2000	ARC	●	●	●	●	000E
Explorer	5.0L	Other	1998 - 2000	DSM	●	●	●	●	○
Explorer	5.0L	Other	1998 - 2000	PAM	●	●	●	●	○
Explorer	5.0L	Other	1998 - 2000	PATS	●	●	●	●	0009
Explorer	5.0L	Other	1999 - 2000	RCM	●	●	●	●	○
Explorer Sport	4.0L	V6 SOHC	2000	PATS	●	●	●	●	0009
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	4X4	●	●	●	●	○
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	ABS/TCS	●	●	●	●	0008
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	GEM	●	●	●	●	○
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	PCM	●	●	●	●	0023 0025 0009 0010 0028 0031 0033
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	RAP	●	●	●	●	000A 000F
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	RCM	●	●	●	●	000C
Explorer SportTrac	4.0L	2V	2007	EATC	●	●	●	●	○
Explorer SportTrac	4.0L	2V	2007	GEM	●	●	●	●	000A 000F
Explorer SportTrac	4.0L	2V	2007 - 2010	4X4	●	●	●	●	○
Explorer SportTrac	4.0L	2V	2007 - 2010	ABS	●	●	●	●	0008 0012
Explorer SportTrac	4.0L	2V	2007 - 2010	ACM	●	●	●	●	○
Explorer SportTrac	4.0L	2V	2007 - 2010	IC	●	●	●	●	0009 0005
Explorer SportTrac	4.0L	2V	2007 - 2010	OCSM	●	●	●	○	000C 0015
Explorer SportTrac	4.0L	2V	2007 - 2010	PAM	●	●	●	●	○
Explorer SportTrac	4.0L	2V	2007 - 2010	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033 00C6
Explorer SportTrac	4.0L	2V	2007 - 2010	RCM	●	●	●	●	0005
Explorer SportTrac	4.0L	2V	2007 - 2010	RETM	●	●	●	●	○
Explorer SportTrac	4.0L	2V	2007 - 2010	SDARS	●	●	●	●	0005
Explorer SportTrac	4.0L	2V	2008 - 2010	APIM	●	●	●	●	○
Explorer SportTrac	4.0L	2V	2008 - 2010	GEM / SJB	●	●	●	●	0005 000A 000F 0042
Explorer SportTrac	4.0L	2V	2008 - 2010	HVAC	●	●	●	●	0005
Explorer SportTrac	4.0L	2V	2010	GPSM	●	●	●	○	○
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2003	GEM	●	●	●	●	○
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	4X4	●	●	●	●	○
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	ABS/TCS	●	●	●	●	0008

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	PCM	●	●	●	●	0023 0025 0009 0010 0028 0031 0033
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	RAP	●	●	●	●	000A 000F
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	RCM	●	●	●	●	000C
Explorer SportTrac	4.0L	V6 SOHC	2004 - 2005	HEC	●	●	●	●	○
Explorer SportTrac	4.6L	3V	2007	EATC	●	●	●	●	0005
Explorer SportTrac	4.6L	3V	2007	GEM	●	●	●	●	0005 000A 000F
Explorer SportTrac	4.6L	3V	2007 - 2010	4X4	●	●	●	●	○
Explorer SportTrac	4.6L	3V	2007 - 2010	ABS	●	●	●	●	0008 0012
Explorer SportTrac	4.6L	3V	2007 - 2010	ACM	●	●	●	●	0005
Explorer SportTrac	4.6L	3V	2007 - 2010	IC	●	●	●	●	0009 0005
Explorer SportTrac	4.6L	3V	2007 - 2010	OCSM	●	●	●	○	000C 0015
Explorer SportTrac	4.6L	3V	2007 - 2010	PAM	●	●	●	●	0005
Explorer SportTrac	4.6L	3V	2007 - 2010	PCM	●	●	●	●	0010 0023 0028 0031 0033 00C5 00C6
Explorer SportTrac	4.6L	3V	2007 - 2010	RCM	●	●	●	●	0005
Explorer SportTrac	4.6L	3V	2007 - 2010	RETM	●	●	●	●	0005
Explorer SportTrac	4.6L	3V	2007 - 2010	SDARS	●	●	●	●	0005
Explorer SportTrac	4.6L	3V	2007 - 2010	TCM	●	●	●	●	0025
Explorer SportTrac	4.6L	3V	2008 - 2010	APIM	●	●	●	●	○
Explorer SportTrac	4.6L	3V	2008 - 2010	GEM / SJB	●	●	●	●	000A 000F 0042 0005
Explorer SportTrac	4.6L	3V	2008 - 2010	HVAC	●	●	●	●	0005
Explorer SportTrac	4.6L	3V	2010	GPSM	●	●	●	○	○
F-250 Light Duty	4.2L	Other	1999	ABS/TCS	●	●	●	●	0008
F-250 Light Duty	4.2L	Other	1999	GEM	●	●	●	●	○
F-250 Light Duty	4.2L	Other	1999	IC	●	●	●	●	0009
F-250 Light Duty	4.2L	Other	1999	PCM	●	●	●	●	0023 0025
F-250 Light Duty	4.2L	Other	1999	RAP	●	●	●	●	000A 000F
F-250 Light Duty	4.2L	Other	1999	RCM	●	●	●	●	○
F-250 Light Duty	4.6L	Other	1997 - 1998	IAB	●	●	●	●	○
F-250 Light Duty	4.6L	Other	1997 - 2000	ABS/TCS	●	●	●	●	0008
F-250 Light Duty	4.6L	Other	1997 - 2000	GEM	●	●	●	●	○
F-250 Light Duty	4.6L	Other	1997 - 2000	PCM	●	●	●	●	0023 0025
F-250 Light Duty	4.6L	Other	1997 - 2000	RAP	●	●	●	●	000A
F-250 Light Duty	4.6L	Other	1999 - 2000	IC	●	●	●	●	0009
F-250 Light Duty	4.6L	Other	1999 - 2000	RCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
F-250 Light Duty	5.4L	BIF	1998	IAB	●	●	●	●	○
F-250 Light Duty	5.4L	BIF	1998 - 1999	ABS/TCS	●	●	●	●	0008
F-250 Light Duty	5.4L	BIF	1998 - 1999	AFCM	●	●	●	●	○
F-250 Light Duty	5.4L	BIF	1998 - 1999	GEM	●	●	●	●	○
F-250 Light Duty	5.4L	BIF	1998 - 1999	PCM	●	●	●	●	0023
F-250 Light Duty	5.4L	BIF	1998 - 1999	RAP	●	●	●	●	000A 000F
F-250 Light Duty	5.4L	BIF	1999	IC	●	●	●	●	0009
F-250 Light Duty	5.4L	BIF	1999	RCM	●	●	●	●	○
F-250 Light Duty	5.4L	NGV	1997 - 1998	IAB	●	●	●	●	○
F-250 Light Duty	5.4L	NGV	1997 - 2000	ABS/TCS	●	●	●	●	0008
F-250 Light Duty	5.4L	NGV	1997 - 2000	FIM	●	●	●	●	○
F-250 Light Duty	5.4L	NGV	1997 - 2000	GEM	●	●	●	●	○
F-250 Light Duty	5.4L	NGV	1997 - 2000	PCM	●	●	●	●	0023
F-250 Light Duty	5.4L	NGV	1997 - 2000	RAP	●	●	●	●	000A 000F
F-250 Light Duty	5.4L	NGV	1999 - 2000	IC	●	●	●	●	0009
F-250 Light Duty	5.4L	NGV	1999 - 2000	RCM	●	●	●	●	○
F-250 Light Duty	5.4L	Other	1997 - 1998	IAB	●	●	●	●	○
F-250 Light Duty	5.4L	Other	1997 - 2000	ABS/TCS	●	●	●	●	0008
F-250 Light Duty	5.4L	Other	1997 - 2000	GEM	●	●	●	●	○
F-250 Light Duty	5.4L	Other	1997 - 2000	PCM	●	●	●	●	0023 0025
F-250 Light Duty	5.4L	Other	1997 - 2000	RAP	●	●	●	●	000A 000F
F-250 Light Duty	5.4L	Other	1999 - 2000	IC	●	●	●	●	0009
F-250 Light Duty	5.4L	Other	1999 - 2000	RCM	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	FOH	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	GEM	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	HEC	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	OTC	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PAM	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PATS	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PCM	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	RCM	●	●	●	●	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	VSM	●	●	●	●	000A 000F
F-Series Super Duty	4.2L	Other	2001	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	4.2L	Other	2001	ECS	●	●	●	●	○
F-Series Super Duty	4.2L	Other	2001	GEM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
F-Series Super Duty	4. 2L	Other	2001	OTC	●	●	●	●	○
F-Series Super Duty	4. 2L	Other	2001	PAM	●	●	●	●	○
F-Series Super Duty	4. 2L	Other	2001	PCM	●	●	●	●	0023 0025
F-Series Super Duty	4. 2L	Other	2001	RCM	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2004	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	5. 4L	2V	2004	HEC	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2004	OTC	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2004	PATS	●	●	●	●	0009
F-Series Super Duty	5. 4L	2V	2004 - 2006	GEM	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2004 - 2006	VSM	●	●	●	●	000A 000F
F-Series Super Duty	5. 4L	2V	2004 - 2008	PAM	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2004 - 2008	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
F-Series Super Duty	5. 4L	2V	2004 - 2008	RCM	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2005 - 2006	EATC	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2005 - 2008	ABS	●	●	●	●	0008
F-Series Super Duty	5. 4L	2V	2005 - 2008	IC	●	●	●	●	0009
F-Series Super Duty	5. 4L	2V	2005 - 2008	TBC	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2008	4X4	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2008	ACM	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2008	DSM	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2008	GEM / SJB	●	●	●	●	000A 000F 0042
F-Series Super Duty	5. 4L	2V	2008	HVAC	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2008	RETM	●	●	●	●	○
F-Series Super Duty	5. 4L	2V	2008	SDARS	●	●	●	●	○
F-Series Super Duty	5. 4L	3V	2005 - 2007	EATC	●	●	●	●	○
F-Series Super Duty	5. 4L	3V	2005 - 2007	GEM	●	●	●	●	○
F-Series Super Duty	5. 4L	3V	2005 - 2007	VSM	●	●	●	●	000A 000F
F-Series Super Duty	5. 4L	3V	2005 - 2010	ABS	●	●	●	●	0008
F-Series Super Duty	5. 4L	3V	2005 - 2010	IC	●	●	●	●	0009
F-Series Super Duty	5. 4L	3V	2005 - 2010	PAM	●	●	●	●	○
F-Series Super Duty	5. 4L	3V	2005 - 2010	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033 00C5
F-Series Super Duty	5. 4L	3V	2005 - 2010	RCM	●	●	●	●	○
F-Series Super Duty	5. 4L	3V	2005 - 2010	TBC	●	●	●	●	○
F-Series Super Duty	5. 4L	3V	2008 - 2010	4X4	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
F-Series Super Duty	5.4L	3V	2008 - 2010	ACM	●	●	●	●	○
F-Series Super Duty	5.4L	3V	2008 - 2010	DSM	●	●	●	●	○
F-Series Super Duty	5.4L	3V	2008 - 2010	GEM / SJB	●	●	●	●	000A 000F 0042
F-Series Super Duty	5.4L	3V	2008 - 2010	HVAC	●	●	●	●	○
F-Series Super Duty	5.4L	3V	2008 - 2010	RETM	●	●	●	●	○
F-Series Super Duty	5.4L	3V	2008 - 2010	SDARS	●	●	●	●	○
F-Series Super Duty	5.4L	3V	2009 - 2010	APIM	●	●	●	●	○
F-Series Super Duty	5.4L	3V	2010	GPSM	●	●	●	○	○
F-Series Super Duty	5.4L	BIF	1999	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	5.4L	BIF	1999	AFCM	●	●	●	●	○
F-Series Super Duty	5.4L	BIF	1999	ECS	●	●	●	●	○
F-Series Super Duty	5.4L	BIF	1999	GEM	●	●	●	●	○
F-Series Super Duty	5.4L	BIF	1999	OTC	●	●	●	●	○
F-Series Super Duty	5.4L	BIF	1999	PCM	●	●	●	●	0023
F-Series Super Duty	5.4L	Other	1999 - 2001	ECS	●	●	●	●	○
F-Series Super Duty	5.4L	Other	1999 - 2003	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	5.4L	Other	1999 - 2003	GEM	●	●	●	●	○
F-Series Super Duty	5.4L	Other	1999 - 2003	OTC	●	●	●	●	○
F-Series Super Duty	5.4L	Other	1999 - 2003	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
F-Series Super Duty	5.4L	Other	2000 - 2003	PATS	●	●	●	●	0009
F-Series Super Duty	5.4L	Other	2001 - 2003	PAM	●	●	●	●	○
F-Series Super Duty	5.4L	Other	2001 - 2003	RCM	●	●	●	●	○
F-Series Super Duty	5.4L	Other	2002	CSM	●	●	●	●	000A 000F
F-Series Super Duty	5.4L	Other	2002 - 2003	HEC	●	●	●	●	○
F-Series Super Duty	5.4L	Other	2003	FOH	●	●	●	●	○
F-Series Super Duty	5.4L	Other	2003	VSM	●	●	●	●	000A 000F
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	FOH	●	●	●	●	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	HEC	●	●	●	●	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	OTC	●	●	●	●	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	PATS	●	●	●	●	0009
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	GEM	●	●	●	●	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	PAM	●	●	●	●	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	PCM	●	●	●	●	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	RCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.
 As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	TCM	●	●	●	●	0010 0028 0031 0033
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	VSM	●	●	●	●	000A 000F
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	ABS	●	●	●	●	0008
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	EATC	●	●	●	●	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	IC	●	●	●	●	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	TBC	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011	APIM	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011	GPSM	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	ABS	●	●	●	●	0008
F-Series Super Duty	6.2L	2V	2011 - 2012	ACM	●	●	●	○	○
F-Series Super Duty	6.2L	2V	2011 - 2012	BCM#1	●	●	●	●	000A 000F 0042
F-Series Super Duty	6.2L	2V	2011 - 2012	DCSM	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	DSM	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	HVAC	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	IPC	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	PAM	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
F-Series Super Duty	6.2L	2V	2011 - 2012	RCM	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	SCCM	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	SDARS	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	TBC	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	TCCM	●	●	●	●	○
F-Series Super Duty	6.2L	2V	2011 - 2012	TPM	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	4X4	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	ABS	●	●	●	●	0005 0008
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	ACM	●	●	●	●	0005
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	AHCM	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	CDIM	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	DSM	●	●	●	●	0005
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	GEM / SJB	●	●	●	●	0042
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	HVAC	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	IC	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	PAM	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	PCM	●	●	●	●	0023 0025 0047 0048 00A2 00A3

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	RCM	●	●	●	●	0005
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	RETM	●	●	●	●	0005
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	SDARS	●	●	●	●	0005
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	TBC	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	TCM	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2009 - 2010	APIM	●	●	●	●	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2010	GPSM	●	●	●	○	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	AHCM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	APIM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	CDIM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	GPCM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	GPSM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	NOx#1	●	●	●	○	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	ABS	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	ACM	●	●	●	○	0005
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	BCM#1	●	●	●	●	000A 000F 0042
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	DCSM	●	●	●	●	0005
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	DSM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	HVAC	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	IPC	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	PAM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	RCM	●	●	●	●	0005
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	SCCM	●	●	●	●	0005
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	SDARS	●	●	●	●	0005
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	TBC	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	TCCM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	TPM	●	●	●	●	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2013	PCM	●	●	●	●	0009 0058 0059 0091 0093 0095 009B 009C 009D 009E 009F 00A0
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2013	TCM	●	●	●	●	0025
F-Series Super Duty	6.8L	2V	2004	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	6.8L	2V	2004	HEC	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2004	OTC	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2004	PATS	●	●	●	●	0009
F-Series Super Duty	6.8L	2V	2004 - 2007	GEM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
F-Series Super Duty	6.8L	2V	2004 - 2007	VSM	●	●	●	●	000A 000F
F-Series Super Duty	6.8L	2V	2004 - 2008	PAM	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2004 - 2008	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
F-Series Super Duty	6.8L	2V	2004 - 2008	RCM	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2005 - 2007	EATC	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2005 - 2008	ABS	●	●	●	●	0008
F-Series Super Duty	6.8L	2V	2005 - 2008	IC	●	●	●	●	0009
F-Series Super Duty	6.8L	2V	2005 - 2008	TBC	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2008	4X4	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2008	ACM	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2008	DSM	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2008	GEM / SJB	●	●	●	●	000A 000F 0042
F-Series Super Duty	6.8L	2V	2008	HVAC	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2008	RETM	●	●	●	●	○
F-Series Super Duty	6.8L	2V	2008	SDARS	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2005 - 2007	EATC	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2005 - 2007	GEM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2005 - 2007	VSM	●	●	●	●	000A 000F
F-Series Super Duty	6.8L	3V	2005 - 2010	IC	●	●	●	●	0009
F-Series Super Duty	6.8L	3V	2005 - 2012	ABS	●	●	●	●	0008
F-Series Super Duty	6.8L	3V	2005 - 2012	PAM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2005 - 2012	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033 00C5 0009
F-Series Super Duty	6.8L	3V	2005 - 2012	RCM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2005 - 2012	TBC	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2008 - 2010	4X4	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2008 - 2010	GEM / SJB	●	●	●	●	000A 000F 0042
F-Series Super Duty	6.8L	3V	2008 - 2010	RETM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2008 - 2011	SDARS	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2008 - 2012	ACM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2008 - 2012	DSM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2008 - 2012	HVAC	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2009 - 2012	APIM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2010 - 2012	GPSM	●	●	●	○	○
F-Series Super Duty	6.8L	3V	2011 - 2012	BCM#1	●	●	●	●	000A 000F 0042

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
F-Series Super Duty	6.8L	3V	2011 - 2012	DCSM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2011 - 2012	IPC	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2011 - 2012	SCCM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2011 - 2012	TCCM	●	●	●	●	○
F-Series Super Duty	6.8L	3V	2011 - 2012	TPM	●	●	●	●	○
F-Series Super Duty	6.8L	Other	1999 - 2001	ECS	●	●	●	●	○
F-Series Super Duty	6.8L	Other	1999 - 2003	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	6.8L	Other	1999 - 2003	GEM	●	●	●	●	○
F-Series Super Duty	6.8L	Other	1999 - 2003	OTC	●	●	●	●	○
F-Series Super Duty	6.8L	Other	1999 - 2003	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
F-Series Super Duty	6.8L	Other	2000 - 2001	AFCM	●	●	●	●	○
F-Series Super Duty	6.8L	Other	2000 - 2003	PATS	●	●	●	●	0009
F-Series Super Duty	6.8L	Other	2001 - 2003	PAM	●	●	●	●	○
F-Series Super Duty	6.8L	Other	2001 - 2003	RCM	●	●	●	●	○
F-Series Super Duty	6.8L	Other	2002	CSM	●	●	●	●	000A 000F
F-Series Super Duty	6.8L	Other	2002 - 2003	HEC	●	●	●	●	○
F-Series Super Duty	6.8L	Other	2003	FOH	●	●	●	●	○
F-Series Super Duty	6.8L	Other	2003	VSM	●	●	●	●	000A 000F
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2001	ECS	●	●	●	●	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	ABS/TCS	●	●	●	●	0008
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	GEM	●	●	●	●	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	OTC	●	●	●	●	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	PCM	●	●	●	●	0025 0010 0028 0031
F-Series Super Duty	7.3L	Direct Injection - Turbo	2000 - 2003	PATS	●	●	●	●	0009
F-Series Super Duty	7.3L	Direct Injection - Turbo	2001 - 2003	PAM	●	●	●	●	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	2001 - 2003	RCM	●	●	●	●	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	2002	CSM	●	●	●	●	000A 000F
F-Series Super Duty	7.3L	Direct Injection - Turbo	2002 - 2003	HEC	●	●	●	●	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	2003	FOH	●	●	●	●	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	2003	VSM	●	●	●	●	000A 000F
FORD GT	5.4L	4V	2005 - 2006	ABS/TCS	●	●	●	●	0008
FORD GT	5.4L	4V	2005 - 2006	AFCM	●	●	●	●	○
FORD GT	5.4L	4V	2005 - 2006	GEM	●	●	●	●	000A
FORD GT	5.4L	4V	2005 - 2006	IC	●	●	●	●	○
FORD GT	5.4L	4V	2005 - 2006	PATS	●	●	●	●	0009

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
FORD GT	5. 4L	4V	2005 - 2006	PCM	●	●	●	●	0023 0025
FORD GT	5. 4L	4V	2005 - 2006	RCM	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta	1. 25L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2002 - 2008	PCM	●	●	●	●	0009 0025
Fiesta	1. 25L	DURATEC 16V	2002 - 2008	RCM	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2006 - 2008	ACM	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2006 - 2008	SRM	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2008	ABS	●	●	●	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1. 25L	DURATEC 16V	2008	BCMii	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2008	FCDIM	●	●	●	●	0000
Fiesta	1. 25L	DURATEC 16V	2008	HVAC	●	●	●	●	○
Fiesta	1. 25L	DURATEC 16V	2008	IPC	●	●	●	●	0009
Fiesta	1. 25L	DURATEC 16V	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1. 25L	DURATEC 16V	2008	RFA	●	●	●	○	○
Fiesta	1. 3L	BZ	2008	ABS	●	●	●	○	002B 002C 0054 00D9
Fiesta	1. 3L	BZ	2008	ACM	●	●	●	●	○
Fiesta	1. 3L	BZ	2008	BCMii	●	●	●	●	○
Fiesta	1. 3L	BZ	2008	FCDIM	●	●	●	●	○
Fiesta	1. 3L	BZ	2008	HVAC	●	●	●	●	○
Fiesta	1. 3L	BZ	2008	IPC	●	●	●	●	0009
Fiesta	1. 3L	BZ	2008	PCM	●	●	●	●	○
Fiesta	1. 3L	BZ	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1. 3L	BZ	2008	RCM	●	●	●	○	○
Fiesta	1. 3L	BZ	2008	RFA	●	●	●	○	○
Fiesta	1. 3L	BZ	2008	SRM	●	●	●	○	○
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	GEM	●	●	●	●	○
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	IC	●	●	●	●	○
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	RCM	●	●	●	●	○
Fiesta	1. 3L	DURATEC 8V	2006	ACM	●	●	●	●	○
Fiesta	1. 3L	DURATEC 8V	2006	EATC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta	1.3L	DURATEC 8V	2006	SRM	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta	1.4L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2002 - 2006	TCM	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2002 - 2008	PCM	●	●	●	●	0009 0025
Fiesta	1.4L	DURATEC 16V	2002 - 2008	RCM	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2006 - 2008	ACM	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2006 - 2008	SRM	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2008	ABS	●	●	●	○	00E8
Fiesta	1.4L	DURATEC 16V	2008	BCMii	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2008	FCDIM	●	●	●	●	0000
Fiesta	1.4L	DURATEC 16V	2008	HVAC	●	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2008	IPC	●	●	●	●	0009
Fiesta	1.4L	DURATEC 16V	2008	PSCM	●	●	●	○	○
Fiesta	1.4L	DURATEC 16V	2008	RFA	●	●	●	○	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	●	●	●	●	0009
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	ACM	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	SRM	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●	●	0000
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●	●	0009
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●	○	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	●	●	●	○	002B 0054 00D9 00DB 00E8

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	BCMii	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FCDIM	●	●	●	●	0000
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HVAC	●	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IPC	●	●	●	●	0009
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●	○	0090 0092 0098 0099 009A 00AF 00B0 00B1 00B2 00B8 00B9 00BD
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	●	●	●	○	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RFA	●	●	●	○	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	●	●	●	○	○
Fiesta	1.5L	BZ	2008	ABS	●	●	●	○	002B 002C 0054 00D9
Fiesta	1.5L	BZ	2008	ACM	●	●	●	●	○
Fiesta	1.5L	BZ	2008	BCMii	●	●	●	●	○
Fiesta	1.5L	BZ	2008	FCDIM	●	●	●	●	○
Fiesta	1.5L	BZ	2008	HVAC	●	●	●	●	○
Fiesta	1.5L	BZ	2008	IPC	●	●	●	●	0009
Fiesta	1.5L	BZ	2008	PCM	●	●	●	●	○
Fiesta	1.5L	BZ	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1.5L	BZ	2008	RCM	●	●	●	○	○
Fiesta	1.5L	BZ	2008	RFA	●	●	●	○	○
Fiesta	1.5L	BZ	2008	SRM	●	●	●	○	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	●	●	●	●	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●	●	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●	●	0000

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●	●	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●	●	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	○	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	●	●	●	○	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●	○	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	●	●	●	○	○
Fiesta	1.5L	TiVCT	2008	ABS	●	●	●	○	○
Fiesta	1.5L	TiVCT	2008	ACM	●	●	●	●	○
Fiesta	1.5L	TiVCT	2008	BCMii	●	●	●	●	○
Fiesta	1.5L	TiVCT	2008	FCDIM	●	●	●	●	○
Fiesta	1.5L	TiVCT	2008	HVAC	●	●	●	●	○
Fiesta	1.5L	TiVCT	2008	IPC	●	●	●	●	0009
Fiesta	1.5L	TiVCT	2008	PCM	●	●	●	●	○
Fiesta	1.5L	TiVCT	2008	PSCM	●	●	●	○	○
Fiesta	1.5L	TiVCT	2008	RCM	●	●	●	○	○
Fiesta	1.5L	TiVCT	2008	RFA	●	●	●	○	○
Fiesta	1.5L	TiVCT	2008	SRM	●	●	●	○	○
Fiesta	1.6L	DURATEC 16V	2002	TCM	●	●	●	●	○
Fiesta	1.6L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta	1.6L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fiesta	1.6L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fiesta	1.6L	DURATEC 16V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fiesta	1.6L	DURATEC 16V	2002 - 2006	RCM	●	●	●	●	○
Fiesta	1.6L	DURATEC 16V	2006	ACM	●	●	●	●	○
Fiesta	1.6L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fiesta	1.6L	DURATEC 16V	2006	SRM	●	●	●	●	○
Fiesta	1.6L	DURATEC VCT	2008	ABS	●	●	●	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.6L	DURATEC VCT	2008	ACM	●	●	●	●	○
Fiesta	1.6L	DURATEC VCT	2008	BCMii	●	●	●	●	○
Fiesta	1.6L	DURATEC VCT	2008	FCDIM	●	●	●	●	0000
Fiesta	1.6L	DURATEC VCT	2008	HVAC	●	●	●	●	○
Fiesta	1.6L	DURATEC VCT	2008	IPC	●	●	●	●	0009
Fiesta	1.6L	DURATEC VCT	2008	PCM	●	●	●	●	0025 00BC
Fiesta	1.6L	DURATEC VCT	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta	1.6L	DURATEC VCT	2008	RCM	●	●	●	○	○
Fiesta	1.6L	DURATEC VCT	2008	RFA	●	●	●	○	○
Fiesta	1.6L	DURATEC VCT	2008	SRM	●	●	●	○	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	●	●	●	●	0009 0092 0096 0097 0099 009A 00AD 00AE 0090 0098 00AA 00B0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	ACM	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	SRM	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●	●	0000
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●	●	0009
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●	○	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	●	●	●	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	BCMii	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FCDIM	●	●	●	●	0000
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HVAC	●	●	●	●	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IPC	●	●	●	●	0009
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●	○	0090 0092 0098 0099 009A 00AF 00B0 00B1 00B2 00B8 00B9 00BD

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	●	●	●	○	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RFA	●	●	●	○	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	●	●	●	○	○
Fiesta	1.6L	Sigma	2011 - 2012	ABS	●	●	●	●	0008 0012
Fiesta	1.6L	Sigma	2011 - 2012	ACM	●	●	●	○	○
Fiesta	1.6L	Sigma	2011 - 2012	APIM	●	●	●	●	○
Fiesta	1.6L	Sigma	2011 - 2012	BCM#1	●	●	●	●	○
Fiesta	1.6L	Sigma	2011 - 2012	FCDIM	●	●	●	●	○
Fiesta	1.6L	Sigma	2011 - 2012	GPSM	●	●	●	○	○
Fiesta	1.6L	Sigma	2011 - 2012	IPC	●	●	●	●	○
Fiesta	1.6L	Sigma	2011 - 2012	OCSM	●	●	●	○	000C
Fiesta	1.6L	Sigma	2011 - 2012	PCM	●	●	●	●	0009 0025
Fiesta	1.6L	Sigma	2011 - 2012	PSCM	●	●	●	○	00CB 00CC
Fiesta	1.6L	Sigma	2011 - 2012	RCM	●	●	●	○	○
Fiesta	1.6L	Sigma	2011 - 2012	RFA	●	●	●	○	○
Fiesta	1.6L	Sigma	2011 - 2012	TBM	●	●	●	●	○
Fiesta	1.6L	Sigma	2011 - 2012	TCM	●	●	●	●	○
Fiesta	1.6L	Sigma	2011 - 2012	VSM	●	●	●	●	0042
Fiesta	1.6L	TDCi ECO II	2008	ABS	●	●	●	○	002B 002C 0054 00D9
Fiesta	1.6L	TDCi ECO II	2008	ACM	●	●	●	●	○
Fiesta	1.6L	TDCi ECO II	2008	BCMii	●	●	●	●	○
Fiesta	1.6L	TDCi ECO II	2008	FCDIM	●	●	●	●	○
Fiesta	1.6L	TDCi ECO II	2008	HVAC	●	●	●	●	○
Fiesta	1.6L	TDCi ECO II	2008	IPC	●	●	●	●	○
Fiesta	1.6L	TDCi ECO II	2008	PCM	●	●	●	●	○
Fiesta	1.6L	TDCi ECO II	2008	PSCM	●	●	●	○	00D7 00D8 00DA 00DC
Fiesta	1.6L	TDCi ECO II	2008	RCM	●	●	●	○	○
Fiesta	1.6L	TDCi ECO II	2008	RFA	●	●	●	○	○
Fiesta	1.6L	TDCi ECO II	2008	SRM	●	●	●	○	○
Fiesta	1.6L	TiVCT	2008	BCMii	●	●	●	●	○
Fiesta	1.6L	TiVCT	2008	HVAC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta	1.6L	TiVCT	2008	SRM	●	●	●	○	○
Fiesta	1.6L	TiVCT	2008 - 2013	ABS	●	●	●	●	0012
Fiesta	1.6L	TiVCT	2008 - 2013	ACM	●	●	●	○	○
Fiesta	1.6L	TiVCT	2008 - 2013	FCDIM	●	●	●	●	○
Fiesta	1.6L	TiVCT	2008 - 2013	IPC	●	●	●	●	0009
Fiesta	1.6L	TiVCT	2008 - 2013	PCM	●	●	●	●	0009 0023
Fiesta	1.6L	TiVCT	2008 - 2013	PSCM	●	●	●	○	00CB 00CC
Fiesta	1.6L	TiVCT	2008 - 2013	RCM	●	●	●	○	○
Fiesta	1.6L	TiVCT	2008 - 2013	RFA	●	●	●	○	000A
Fiesta	1.6L	TiVCT	2008 - 2013	TCM	●	●	●	●	○
Fiesta	1.6L	TiVCT	2011 - 2013	APIM	●	●	●	●	○
Fiesta	1.6L	TiVCT	2011 - 2013	BCM#1	●	●	●	●	○
Fiesta	1.6L	TiVCT	2011 - 2013	GPSM	●	●	●	○	○
Fiesta	1.6L	TiVCT	2011 - 2013	OCSM	●	●	●	○	000C
Fiesta	1.6L	TiVCT	2011 - 2013	VSM	●	●	●	●	0042
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●	●	0008
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	GEM	●	●	●	●	○
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	IC	●	●	●	●	○
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	●	0009
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●	●	○
Fiesta / Ikon	1.4L	DURATEC 16V	2006	ABS/TCS	●	●	●	●	0008
Fiesta / Ikon	1.4L	DURATEC 16V	2006	GEM	●	●	●	●	○
Fiesta / Ikon	1.4L	DURATEC 16V	2006	IC	●	●	●	●	○
Fiesta / Ikon	1.4L	DURATEC 16V	2006	PCM	●	●	●	●	0009 0025
Fiesta / Ikon	1.4L	DURATEC 16V	2006	RCM	●	●	●	●	○
Fiesta / Ikon	1.6L	DURATEC 16V	2006	ABS/TCS	●	●	●	●	0008
Fiesta / Ikon	1.6L	DURATEC 16V	2006	GEM	●	●	●	●	○
Fiesta / Ikon	1.6L	DURATEC 16V	2006	IC	●	●	●	●	○
Fiesta / Ikon	1.6L	DURATEC 16V	2006	PCM	●	●	●	●	0009 0025
Fiesta / Ikon	1.6L	DURATEC 16V	2006	RCM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996 - 1999	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996 - 1999	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996 - 1999	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996 - 1999	PCM	●	●	●	●	0025 0023
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999	ABS/TCS	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 - 2000	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 - 2000	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 - 2000	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 - 2000	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 - 2000	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1999 - 2000	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000	PATS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 - 1999	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 - 1999	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 - 1999	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 - 1999	PCM	●	●	●	●	0023 0025 0009
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 - 1996	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 - 1996	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 - 1996	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000	PCM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996 - 1999	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996 - 1999	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996 - 1999	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996 - 1999	PCM	●	●	●	●	0023 0025 0009
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001	HEC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001	PATS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001	PCM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000	PCM	●	●	●	●	0009 0023 0025
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	FIP	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	PATS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	PCM	●	●	●	●	0009
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996 -	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996 -	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996 -	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996 -	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996 -	PATS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996 -	PCM	○	○	●	○	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 - 1994	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 - 1994	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 - 1994	HEC	●	●	●	●	○
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	RCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta 3-Door	1. 25L	DURATEC 16V	2006	ACM	●	●	●	●	○
Fiesta 3-Door	1. 25L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fiesta 3-Door	1. 25L	DURATEC 16V	2006	SRM	●	●	●	●	○
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	GEM	●	●	●	●	○
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	IC	●	●	●	●	○
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	RCM	●	●	●	●	○
Fiesta 3-Door	1. 3L	DURATEC 8V	2006	ACM	●	●	●	●	○
Fiesta 3-Door	1. 3L	DURATEC 8V	2006	EATC	●	●	●	●	○
Fiesta 3-Door	1. 3L	DURATEC 8V	2006	SRM	●	●	●	●	○
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	RCM	●	●	●	●	○
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	TCM	●	●	●	●	○
Fiesta 3-Door	1. 4L	DURATEC 16V	2006	ACM	●	●	●	●	○
Fiesta 3-Door	1. 4L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fiesta 3-Door	1. 4L	DURATEC 16V	2006	SRM	●	●	●	●	○
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●	●	○
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●	●	○
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●	●	0009
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	●	●	●	●	○
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	●	●	●	●	○
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●	●	○
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Fiesta 3-Door	1. 6L	DURATEC 16V	2002	TCM	●	●	●	●	○
Fiesta 3-Door	1. 6L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008
Fiesta 3-Door	1. 6L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fiesta 3-Door	1. 6L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fiesta 3-Door	1. 6L	DURATEC 16V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fiesta 3-Door	1. 6L	DURATEC 16V	2002 - 2006	RCM	●	●	●	●	○
Fiesta 3-Door	1. 6L	DURATEC 16V	2006	ACM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta 3-Door	1.6L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fiesta 3-Door	1.6L	DURATEC 16V	2006	SRM	●	●	●	●	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	●	●	●	●	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●	●	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●	●	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●	●	0009 0092 0096 0097 0099 009A 00AD 00AE
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	●	●	●	●	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●	●	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	GEM	●	●	●	●	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	IC	●	●	●	●	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	PCM	●	●	●	●	0009 0025
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	RCM	●	●	●	●	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	ACM	●	●	●	●	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	EATC	●	●	●	●	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	SRM	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	●	●	●	○	002B 002C 0053 00D9
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	●	●	●	●	0009
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDSM	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	●	●	●	○	00DC 00DF 00E0 00E1
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	●	●	●	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003	RL DCU	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003	RR DCU	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2007	GDM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2007	NAV	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	ABS	●	●	●	●	0008 0029 002A 002C 00DD 00DE 00E8
Focus	1.4L	DURATEC 16V	2003 - 2008	ACM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	CDP	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	D DCU	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	EATC	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	FFH	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	GEM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	HCM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	IC	●	●	●	●	0009
Focus	1.4L	DURATEC 16V	2003 - 2008	PAM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	PCM	●	●	●	●	0025
Focus	1.4L	DURATEC 16V	2003 - 2008	P DCU	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	RCM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	RETM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	RKE	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2003 - 2008	SRM	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2008	CMR	●	●	●	●	○
Focus	1.4L	DURATEC 16V	2008	EPS	●	●	●	○	○
Focus	1.4L	Zetec-SE	1999	CSM	●	●	●	●	○
Focus	1.4L	Zetec-SE	1999	CTM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1. 4L	Zetec-SE	1999 - 2002	ABS/TCS	●	●	●	●	0008 0012
Focus	1. 4L	Zetec-SE	1999 - 2002	ECS	●	●	●	●	○
Focus	1. 4L	Zetec-SE	1999 - 2002	HEC	●	●	●	●	○
Focus	1. 4L	Zetec-SE	1999 - 2002	MC	●	●	●	●	○
Focus	1. 4L	Zetec-SE	1999 - 2002	PATS	●	●	●	○	○
Focus	1. 4L	Zetec-SE	1999 - 2002	PCM	●	●	●	●	0009 0023 0025
Focus	1. 4L	Zetec-SE	2002	EATC	●	●	●	●	○
Focus	1. 4L	Zetec-SE	2002	GEM	●	●	●	●	○
Focus	1. 4L	Zetec-SE	2002	HCM	●	●	●	●	○
Focus	1. 4L	Zetec-SE	2002	RCM	●	●	●	●	○
Focus	1. 6L	BZ	2005	ABS	●	●	●	●	0012 0029 002A 002C
Focus	1. 6L	BZ	2005	D DCU	●	●	●	●	○
Focus	1. 6L	BZ	2005	EATC	●	●	●	●	○
Focus	1. 6L	BZ	2005	GEM	●	●	●	●	○
Focus	1. 6L	BZ	2005	HCM	●	●	●	●	○
Focus	1. 6L	BZ	2005	IC	●	●	●	●	0009
Focus	1. 6L	BZ	2005	PAM	●	●	●	●	○
Focus	1. 6L	BZ	2005	PCM	●	●	●	●	○
Focus	1. 6L	BZ	2005	P DCU	●	●	●	●	○
Focus	1. 6L	BZ	2005	RCM	●	●	●	●	○
Focus	1. 6L	BZ	2005	RL DCU	●	●	●	●	○
Focus	1. 6L	BZ	2005	RR DCU	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003	RL DCU	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003	RR DCU	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2007	GDM	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2007	NAV	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2008	ABS	●	●	●	●	0008 0029 002A 002C 00DD 00DE 00E8 002B
Focus	1. 6L	DURATEC 16V	2003 - 2008	ACM	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2008	CDP	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2008	D DCU	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2008	EATC	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2008	FFH	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2008	GEM	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2008	HCM	●	●	●	●	○
Focus	1. 6L	DURATEC 16V	2003 - 2008	IC	●	●	●	●	0009

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.6L	DURATEC 16V	2003 - 2008	PAM	●	●	●	●	○
Focus	1.6L	DURATEC 16V	2003 - 2008	PCM	●	●	●	●	0025
Focus	1.6L	DURATEC 16V	2003 - 2008	P DCU	●	●	●	●	○
Focus	1.6L	DURATEC 16V	2003 - 2008	RCM	●	●	●	●	○
Focus	1.6L	DURATEC 16V	2003 - 2008	RETM	●	●	●	●	○
Focus	1.6L	DURATEC 16V	2003 - 2008	RKE	●	●	●	●	○
Focus	1.6L	DURATEC 16V	2003 - 2008	SRM	●	●	●	●	○
Focus	1.6L	DURATEC 16V	2006	FTCM	●	●	●	●	○
Focus	1.6L	DURATEC 16V	2007	TCM	●	●	●	●	0070 00C5
Focus	1.6L	DURATEC 16V	2008	CMR	●	●	●	●	○
Focus	1.6L	DURATEC 16V	2008	EPS	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2003	RL DCU	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003	RR DCU	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2007	GDM	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2007	NAV	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2008	CDP	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2008	D DCU	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2008	EATC	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2008	FFH	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2008	GEM	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2008	IC	●	●	●	●	0009
Focus	1.6L	DURATEC VCT	2003 - 2008	P DCU	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2008	RETM	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2008	RKE	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2011	ABS	●	●	●	○	0008 0029 002A 002C 002B 00DD 00DE
Focus	1.6L	DURATEC VCT	2003 - 2011	ACM	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2011	HCM	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2003 - 2011	PAM	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2003 - 2011	PCM	●	●	●	●	0025
Focus	1.6L	DURATEC VCT	2003 - 2011	RCM	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 - 2011	SRM	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2008	CMR	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2008	EPS	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	AHCM	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	APIM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.6L	DURATEC VCT	2011	BCMii	●	●	●	●	0009
Focus	1.6L	DURATEC VCT	2011	DDM	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	DSP	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	FCDIM	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	FCIM	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2011	HVAC	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	IPC	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2011	IPM-A	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	IPM-B	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	PDM	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	PSCM	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2011	RFA	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	SASM	●	●	●	○	○
Focus	1.6L	DURATEC VCT	2011	SOD-L	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2011	SOD-R	●	●	●	●	○
Focus	1.6L	DURATEC VCT	2011	TRM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003	RL DCU	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003	RR DCU	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D DCU	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EATC	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FACM	●	●	●	●	006B 0094 00A1
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FFH	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	GEM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	●	●	●	●	0009
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P DCU	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RETM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ABS	●	●	●	●	0008 0029 002A 002B 002C 00E8 00DD 00DE
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ACM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	HCM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PAM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PCM	●	●	●	●	0090 0092 0096 0097 0098 0099 009A 00B1 00B7 00B9 00BC 00BD
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	RCM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	SRM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	APIM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●	●	0009
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DSP	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCIM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●	●	0120
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	●	●	●	●	0008 0029 002A 002C 00DD 00DE 00E8
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CDP	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CMR	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	D_DCU	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EATC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.
 As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EPS	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FFH	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	GEM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HCM	●	●	●	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IC	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PAM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	P_DCU	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RETM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RKE	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	●	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	TCM	●	●	●	●	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	ABS	●	●	●	○	002B 002C 0053 00D9
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	ACM	●	●	●	●	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	AHCM	●	●	●	○	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	APIM	●	●	●	●	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	BCMii	●	●	●	●	0009
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	DDM	●	●	●	○	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	DSP	●	●	●	○	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	FCDIM	●	●	●	○	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	FCIM	●	●	●	●	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	HCM	●	●	●	○	○
Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	HVAC	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	●	●	●	●	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	●	●	●	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	●	●	●	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	●	●	●	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	●	●	●	●	00DC 00DF 00E0 00E1
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	●	●	●	●	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	●	●	●	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	●	●	●	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●	●	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●	●	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●	●	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●	●	○
Focus	1.6L	FFV	2007 - 2009	ABS/TCS	●	●	●	●	0012 0008
Focus	1.6L	FFV	2007 - 2010	GEM	●	●	●	●	○
Focus	1.6L	FFV	2007 - 2010	IC	●	●	●	●	0009
Focus	1.6L	FFV	2007 - 2010	PCM	●	●	●	●	0009 0025
Focus	1.6L	FFV	2007 - 2010	RCM	●	●	●	●	○
Focus	1.6L	FFV	2009	MC	●	●	●	●	○
Focus	1.6L	FFV	2009 - 2010	EATC	●	●	●	●	○
Focus	1.6L	FFV	2009 - 2010	HCM	●	●	●	●	○
Focus	1.6L	FFV	2010	ABS	●	●	●	●	0008 0029 002A 002C 0053 00DD 00DE
Focus	1.6L	FFV	2010	ACM	●	●	●	●	○
Focus	1.6L	FFV	2010	D_DCU	●	●	●	●	○
Focus	1.6L	FFV	2010	EPS	●	●	●	○	○
Focus	1.6L	FFV	2010	PAM	●	●	●	●	○
Focus	1.6L	FFV	2010	P_DCU	●	●	●	●	○
Focus	1.6L	FFV	2010	RKE	●	●	●	●	○
Focus	1.6L	FFV	2010	SRM	●	●	●	●	○
Focus	1.6L	FFV	2010	TBM	●	●	●	●	○
Focus	1.6L	FFV	2010	TCM	●	●	●	●	0070 00C5
Focus	1.6L	OHC	2009	ABS/TCS	●	●	●	●	0012
Focus	1.6L	OHC	2009	EATC	●	●	●	●	○
Focus	1.6L	OHC	2009	GEM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1. 6L	OHC	2009	HCM	●	●	●	●	○
Focus	1. 6L	OHC	2009	IC	●	●	●	●	○
Focus	1. 6L	OHC	2009	MC	●	●	●	●	○
Focus	1. 6L	OHC	2009	PCM	●	●	●	●	0009 0025
Focus	1. 6L	OHC	2009	RCM	●	●	●	●	○
Focus	1. 6L	Sigma	2010	ABS	●	●	●	●	0008 0029 002A 002C 0053 00DD 00DE
Focus	1. 6L	Sigma	2010	ACM	●	●	●	●	○
Focus	1. 6L	Sigma	2010	D DCU	●	●	●	●	○
Focus	1. 6L	Sigma	2010	EATC	●	●	●	●	○
Focus	1. 6L	Sigma	2010	EPS	●	●	●	○	○
Focus	1. 6L	Sigma	2010	GEM	●	●	●	●	○
Focus	1. 6L	Sigma	2010	HCM	●	●	●	○	○
Focus	1. 6L	Sigma	2010	IC	●	●	●	●	0009
Focus	1. 6L	Sigma	2010	PAM	●	●	●	●	○
Focus	1. 6L	Sigma	2010	PCM	●	●	●	●	0025
Focus	1. 6L	Sigma	2010	P DCU	●	●	●	●	○
Focus	1. 6L	Sigma	2010	RCM	●	●	●	●	○
Focus	1. 6L	Sigma	2010	RKE	●	●	●	●	○
Focus	1. 6L	Sigma	2010	SRM	●	●	●	●	○
Focus	1. 6L	Sigma	2010	TBM	●	●	●	●	○
Focus	1. 6L	Sigma	2010	TCM	●	●	●	●	0070 00C5
Focus	1. 6L	TDCi ECO III	2011	ABS	●	●	●	○	002B 002C 0053 00D9
Focus	1. 6L	TDCi ECO III	2011	ACM	●	●	●	●	○
Focus	1. 6L	TDCi ECO III	2011	AHCM	●	●	●	○	○
Focus	1. 6L	TDCi ECO III	2011	APIM	●	●	●	●	○
Focus	1. 6L	TDCi ECO III	2011	BCMii	●	●	●	●	0009
Focus	1. 6L	TDCi ECO III	2011	CCMii	●	●	●	●	○
Focus	1. 6L	TDCi ECO III	2011	DDM	●	●	●	○	○
Focus	1. 6L	TDCi ECO III	2011	DSP	●	●	●	○	○
Focus	1. 6L	TDCi ECO III	2011	FCDIM	●	●	●	●	○
Focus	1. 6L	TDCi ECO III	2011	FCIM	●	●	●	●	○
Focus	1. 6L	TDCi ECO III	2011	FDSM	●	●	●	○	○
Focus	1. 6L	TDCi ECO III	2011	HCM	●	●	●	○	○
Focus	1. 6L	TDCi ECO III	2011	HVAC	●	●	●	○	○
Focus	1. 6L	TDCi ECO III	2011	IPC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.6L	TDCi ECO III	2011	IPM-A	●	●	●	○	○
Focus	1.6L	TDCi ECO III	2011	IPM-B	●	●	●	○	○
Focus	1.6L	TDCi ECO III	2011	PAM	●	●	●	○	○
Focus	1.6L	TDCi ECO III	2011	PCM	●	●	●	●	○
Focus	1.6L	TDCi ECO III	2011	PDM	●	●	●	○	○
Focus	1.6L	TDCi ECO III	2011	PSCM	●	●	●	○	00DC 00DF 00E0 00E1
Focus	1.6L	TDCi ECO III	2011	RCM	●	●	●	●	○
Focus	1.6L	TDCi ECO III	2011	RFA	●	●	●	○	○
Focus	1.6L	TDCi ECO III	2011	SASM	●	●	●	○	○
Focus	1.6L	TDCi ECO III	2011	SOD-L	●	●	●	●	○
Focus	1.6L	TDCi ECO III	2011	SOD-R	●	●	●	●	○
Focus	1.6L	TDCi ECO III	2011	SRM	●	●	●	●	○
Focus	1.6L	TDCi ECO III	2011	TRM	●	●	●	●	○
Focus	1.6L	Zetec	1999	CSM	●	●	●	●	○
Focus	1.6L	Zetec	1999	CTM	●	●	●	●	○
Focus	1.6L	Zetec	1999	PATS	●	●	●	○	○
Focus	1.6L	Zetec	1999 - 2002	ABS/TCS	●	●	●	●	0008 0012
Focus	1.6L	Zetec	1999 - 2002	ECS	●	●	●	●	○
Focus	1.6L	Zetec	1999 - 2002	HEC	●	●	●	●	○
Focus	1.6L	Zetec	1999 - 2002	PCM	●	●	●	●	0009 0023 0025
Focus	1.6L	Zetec	2002	EATC	●	●	●	●	○
Focus	1.6L	Zetec	2002	GEM	●	●	●	●	○
Focus	1.6L	Zetec	2002	HCM	●	●	●	●	○
Focus	1.6L	Zetec	2002	MC	●	●	●	●	○
Focus	1.6L	Zetec	2002	RCM	●	●	●	●	○
Focus	1.6L	Zetec Rocam	2002	ABS/TCS	●	●	●	●	0008 0012
Focus	1.6L	Zetec Rocam	2002	EATC	●	●	●	●	○
Focus	1.6L	Zetec Rocam	2002	ECS	●	●	●	●	○
Focus	1.6L	Zetec Rocam	2002	GEM	●	●	●	●	○
Focus	1.6L	Zetec Rocam	2002	HCM	●	●	●	●	○
Focus	1.6L	Zetec Rocam	2002	HEC	●	●	●	●	○
Focus	1.6L	Zetec Rocam	2002	MC	●	●	●	●	○
Focus	1.6L	Zetec Rocam	2002	PCM	●	●	●	●	0009 0023 0025
Focus	1.6L	Zetec Rocam	2002	RCM	●	●	●	●	○
Focus	1.6L	Zetec-SE	1999	CSM	●	●	●	●	○
Focus	1.6L	Zetec-SE	1999	CTM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.6L	Zetec-SE	1999 - 2002	ABS/TCS	●	●	●	●	0008 0012
Focus	1.6L	Zetec-SE	1999 - 2002	ECS	●	●	●	●	○
Focus	1.6L	Zetec-SE	1999 - 2002	HEC	●	●	●	●	○
Focus	1.6L	Zetec-SE	1999 - 2002	MC	●	●	●	●	○
Focus	1.6L	Zetec-SE	1999 - 2002	PATS	●	●	●	○	○
Focus	1.6L	Zetec-SE	1999 - 2002	PCM	●	●	●	●	0023 0025 0009
Focus	1.6L	Zetec-SE	2002	EATC	●	●	●	●	○
Focus	1.6L	Zetec-SE	2002	GEM	●	●	●	●	○
Focus	1.6L	Zetec-SE	2002	HCM	●	●	●	●	○
Focus	1.6L	Zetec-SE	2002	RCM	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2005	RL DCU	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2005	RR DCU	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2007	GDM	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2007	NAV	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2007	TCM	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	ABS	●	●	●	●	0008 0029 002A 002B 002C 00E8 00DD 00DE 0005 0012 0054
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	ACM	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	CDP	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	D DCU	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	EATC	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	EPS	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	FFH	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	GEM	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	HCM	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	IC	●	●	●	●	0009 0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	PAM	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	PCM	●	●	●	●	0025
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	P DCU	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	RCM	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	RETM	●	●	●	●	0005
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	RKE	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	SRM	●	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2008	CMR	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001	CTM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ABS/TCS	●	●	●	●	0008 0012
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ECS	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	HEC	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ICU	○	○	●	○	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	MC	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2008	FFH	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2008	PCM	●	●	●	●	0009 0092 0092 006F
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	HCM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003	RL DCU	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003	RR DCU	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	ABS	●	●	●	●	0008 0029 002A 002B 002C 00E8 00DD 00DE
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	ACM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D DCU	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	●	●	●	●	0009
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	PAM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P DCU	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RETM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	SRM	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	FACM	●	●	●	●	006B
Focus	1.8L	Endura DI	1999	CSM	●	●	●	●	○
Focus	1.8L	Endura DI	1999	CTM	●	●	●	●	○
Focus	1.8L	Endura DI	1999 - 2002	ABS/TCS	●	●	●	●	0008 0012
Focus	1.8L	Endura DI	1999 - 2002	ECS	●	●	●	●	○
Focus	1.8L	Endura DI	1999 - 2002	FFH	●	●	●	●	○
Focus	1.8L	Endura DI	1999 - 2002	FIP	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	1.8L	Endura DI	1999 - 2002	HEC	●	●	●	●	○
Focus	1.8L	Endura DI	1999 - 2002	MC	●	●	●	●	○
Focus	1.8L	Endura DI	1999 - 2002	PATS	●	●	●	○	○
Focus	1.8L	Endura DI	1999 - 2002	PCM	●	●	●	●	0009
Focus	1.8L	Endura DI	2002	EATC	●	●	●	●	○
Focus	1.8L	Endura DI	2002	GEM	●	●	●	●	○
Focus	1.8L	Endura DI	2002	HCM	●	●	●	●	○
Focus	1.8L	Endura DI	2002	RCM	●	●	●	●	○
Focus	1.8L	Zetec	1999	CSM	●	●	●	●	○
Focus	1.8L	Zetec	1999	CTM	●	●	●	●	○
Focus	1.8L	Zetec	1999	PATS	●	●	●	○	○
Focus	1.8L	Zetec	1999 - 2002	ABS/TCS	●	●	●	●	0008 0012
Focus	1.8L	Zetec	1999 - 2002	ECS	●	●	●	●	○
Focus	1.8L	Zetec	1999 - 2002	HEC	●	●	●	●	○
Focus	1.8L	Zetec	1999 - 2002	MC	●	●	●	●	○
Focus	1.8L	Zetec	1999 - 2002	PCM	●	●	●	●	0009 0023 0025
Focus	1.8L	Zetec	2002	AFCM	●	●	●	●	○
Focus	1.8L	Zetec	2002	EATC	●	●	●	●	○
Focus	1.8L	Zetec	2002	GEM	●	●	●	●	○
Focus	1.8L	Zetec	2002	HCM	●	●	●	●	○
Focus	1.8L	Zetec	2002	RCM	●	●	●	●	○
Focus	2.0L	DURATEC 16V	2005	ABS/TCS	●	●	●	●	0008 0012
Focus	2.0L	DURATEC 16V	2005	EATC	●	●	●	●	○
Focus	2.0L	DURATEC 16V	2005	GEM	●	●	●	●	○
Focus	2.0L	DURATEC 16V	2005	HCM	●	●	●	●	○
Focus	2.0L	DURATEC 16V	2005	IC	●	●	●	●	○
Focus	2.0L	DURATEC 16V	2005	MC	●	●	●	●	○
Focus	2.0L	DURATEC 16V	2005	PCM	●	●	●	●	0009 0023 0025
Focus	2.0L	DURATEC 16V	2005	RCM	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003	RL DCU	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003	RR DCU	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2007	GDM	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2007	NAV	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	CDP	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	D DCU	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	EATC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	EPS	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	FFH	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	GEM	●	●	●	●	000A
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	HCM	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	PAM	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	P DCU	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	RETM	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	RKE	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	SRM	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	ABS	●	●	●	●	0008 0012 0029 002A 002B 002C 00DD 00DE
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	ACM	●	●	●	●	0005
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	IC	●	●	●	●	0009 0005
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	PCM	●	●	●	●	0009 0023 0025 00C5
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	RCM	●	●	●	●	000C 0005
Focus	2.0L	DURATEC-HE / I4	2006	FTCM	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2008	CMR	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2008	SDARS	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	APIM	●	●	●	○	○
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	FCIM	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	FDIM	●	●	●	●	0005
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	GEM / SJB	●	●	●	●	000A 000F 0042
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	HVAC	●	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	OCSM	●	●	●	○	000C
Focus	2.0L	DURATEC-HE / I4	2010 - 2011	GPSM	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2005	RL DCU	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2005	RR DCU	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D DCU	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EATC	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FACM	●	●	●	●	006B 0094 00A1
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FFH	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	GEM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	●	●	●	●	0009
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P DCU	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RETM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ABS	●	●	●	○	00E8 0008 0029 002A 002B 002C 00DD 00DE
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ACM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	HCM	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PAM	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PCM	●	●	●	○	0092 0098 0099 009A 00A4 00B0 00B1 00B3 00B7 00B8 00B9 00BC 00BF 00C1 0090 00AB
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	RCM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	SRM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006	FTCM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008 - 2011	TCM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	APIM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●	●	0009
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DSP	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCIM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	●	●	●	●	0009
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDSM	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ABS	●	●	●	○	002B 002C 0053 00D9
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ACM	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	APIM	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DDM	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DSP	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCDIM	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCIM	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HVAC	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ICM#1	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPC	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPM-B	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PAM	●	●	○	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PCM	●	●	●	●	0023 0025
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PDM	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PSCM	●	●	●	○	00CB 00CC 00DC 00DF 00E0 00E1
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RCM	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RFA	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SASM	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPMS	●	●	●	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●	●	○
Focus	2.0L	FFV	2010	ABS	●	●	●	●	0008 0029 002A 002C 0053 00DD 00DE
Focus	2.0L	FFV	2010	ACM	●	●	●	●	○
Focus	2.0L	FFV	2010	D DCU	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	2.0L	FFV	2010	EATC	●	●	●	●	○
Focus	2.0L	FFV	2010	EPS	●	●	●	○	○
Focus	2.0L	FFV	2010	GEM	●	●	●	●	○
Focus	2.0L	FFV	2010	HCM	●	●	●	○	○
Focus	2.0L	FFV	2010	IC	●	●	●	●	0009
Focus	2.0L	FFV	2010	PAM	●	●	●	●	○
Focus	2.0L	FFV	2010	PCM	●	●	●	●	0025
Focus	2.0L	FFV	2010	P_DCU	●	●	●	●	○
Focus	2.0L	FFV	2010	RCM	●	●	●	●	○
Focus	2.0L	FFV	2010	RKE	●	●	●	●	○
Focus	2.0L	FFV	2010	SRM	●	●	●	●	○
Focus	2.0L	FFV	2010	TBM	●	●	●	●	○
Focus	2.0L	FFV	2010	TCM	●	●	●	●	0070 00C5
Focus	2.0L	Gasoline Direct injection	2011	AHCM	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011	BCMii	●	●	●	●	0009
Focus	2.0L	Gasoline Direct injection	2011	HCM	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011	IPM-A	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011	SOD-L	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2011	SOD-R	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2011	SRM	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2011	TRM	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	ABS	●	●	●	○	0012
Focus	2.0L	Gasoline Direct injection	2011 - 2012	ACM	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	APIM	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	DDM	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	DSP	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	FCDIM	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	FCIM	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	HVAC	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	IPC	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	IPM-B	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	PAM	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	PCM	●	●	●	●	0025 0023
Focus	2.0L	Gasoline Direct injection	2011 - 2012	PDM	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	PSCM	●	●	●	●	00CB 00CC
Focus	2.0L	Gasoline Direct injection	2011 - 2012	RCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	2.0L	Gasoline Direct injection	2011 - 2012	RFA	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	SASM	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2011 - 2012	TCM	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2012	BCM#1	●	●	●	●	○
Focus	2.0L	Gasoline Direct injection	2012	GPSM	●	●	●	○	○
Focus	2.0L	Gasoline Direct injection	2012	OCSM	●	●	●	●	○
Focus	2.0L	SPI	2000	CSM	●	●	●	●	○
Focus	2.0L	SPI	2000	CTM	●	●	●	●	000A
Focus	2.0L	SPI	2000 - 2002	ECS	●	●	●	●	○
Focus	2.0L	SPI	2000 - 2004	ABS/TCS	●	●	●	●	0008 0012
Focus	2.0L	SPI	2000 - 2004	HEC	●	●	●	●	○
Focus	2.0L	SPI	2000 - 2004	PCM	●	●	●	●	0009 0023 0025
Focus	2.0L	SPI	2002	EATC	●	●	●	●	○
Focus	2.0L	SPI	2002	HCM	●	●	●	●	○
Focus	2.0L	SPI	2002	MC	●	●	●	●	○
Focus	2.0L	SPI	2002 - 2004	GEM	●	●	●	●	000A
Focus	2.0L	SPI	2002 - 2004	RCM	●	●	●	●	○
Focus	2.0L	ZETEC ST	2002	EATC	●	●	●	●	○
Focus	2.0L	ZETEC ST	2002	ECS	●	●	●	●	○
Focus	2.0L	ZETEC ST	2002	HCM	●	●	●	●	○
Focus	2.0L	ZETEC ST	2002	MC	●	●	●	●	○
Focus	2.0L	ZETEC ST	2002 - 2004	ABS/TCS	●	●	●	●	0008 0012
Focus	2.0L	ZETEC ST	2002 - 2004	GEM	●	●	●	●	000A
Focus	2.0L	ZETEC ST	2002 - 2004	HEC	●	●	●	●	○
Focus	2.0L	ZETEC ST	2002 - 2004	PCM	●	●	●	●	0009 0025
Focus	2.0L	ZETEC ST	2002 - 2004	RCM	●	●	●	●	○
Focus	2.0L	Zetec	1999	PATS	●	●	●	○	○
Focus	2.0L	Zetec	1999 - 2000	CSM	●	●	●	●	○
Focus	2.0L	Zetec	1999 - 2000	CTM	●	●	●	●	000A
Focus	2.0L	Zetec	1999 - 2002	ECS	●	●	●	●	○
Focus	2.0L	Zetec	1999 - 2002	MC	●	●	●	●	○
Focus	2.0L	Zetec	1999 - 2004	ABS/TCS	●	●	●	●	0008 0012
Focus	2.0L	Zetec	1999 - 2004	HEC	●	●	●	●	○
Focus	2.0L	Zetec	1999 - 2004	PCM	●	●	●	●	0009 0023 0025
Focus	2.0L	Zetec	2002	EATC	●	●	●	●	○
Focus	2.0L	Zetec	2002	HCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	2.0L	Zetec	2002 - 2004	GEM	●	●	●	●	000A
Focus	2.0L	Zetec	2002 - 2004	RCM	●	●	●	●	○
Focus	2.3L	DURATEC-HE / I4	2003 - 2004	ABS/TCS	●	●	●	●	0008 0012
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	GEM	●	●	●	●	000A
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	IC	●	●	●	●	○
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	PCM	●	●	●	●	0009 0023 0025
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	RCM	●	●	●	●	000C
Focus	2.3L	DURATEC-HE / I4	2004	HEC	●	●	●	●	○
Focus	2.3L	DURATEC-HE / I4	2005 - 2007	ABS	●	●	●	●	0008 0012
Focus	2.5L	Duratec RS	2008	ABS	●	●	●	●	00E8
Focus	2.5L	Duratec RS	2008	ACM	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	CDP	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	CMR	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	D_DCU	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	EATC	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	EPS	●	●	●	○	○
Focus	2.5L	Duratec RS	2008	FFH	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	GEM	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	HCM	●	●	●	○	○
Focus	2.5L	Duratec RS	2008	IC	●	●	●	●	0009
Focus	2.5L	Duratec RS	2008	MC	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	PAM	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	PCM	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	P_DCU	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	RCM	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	RETM	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	RKE	●	●	●	●	○
Focus	2.5L	Duratec RS	2008	SRM	●	●	●	●	○
Focus	2.5L	I5	2003	RL_DCU	●	●	●	●	○
Focus	2.5L	I5	2003	RR_DCU	●	●	●	●	○
Focus	2.5L	I5	2003 - 2007	GDM	●	●	●	●	○
Focus	2.5L	I5	2003 - 2007	NAV	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	ABS	●	●	●	●	0029 002A 00DD 00DE 0008 002C
Focus	2.5L	I5	2003 - 2008	ACM	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	CDP	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	2.5L	I5	2003 - 2008	D DCU	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	EATC	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	EPS	●	●	●	○	○
Focus	2.5L	I5	2003 - 2008	FFH	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	GEM	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	HCM	●	●	●	○	○
Focus	2.5L	I5	2003 - 2008	IC	●	●	●	●	0009
Focus	2.5L	I5	2003 - 2008	MC	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	PAM	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	PCM	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	P DCU	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	RCM	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	RETM	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	RKE	●	●	●	●	○
Focus	2.5L	I5	2003 - 2008	SRM	●	●	●	●	○
Focus	2.5L	I5	2008	CMR	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	ABS	●	●	●	○	0012
Focus	23kWh	Battery Electric Vehicle	2012	ACCM#2	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	ACM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	APIM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	BCCM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	BCM#1	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	BECM	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	DCDC	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	DDM	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	DSP	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	FCDIM	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	FCIM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	GFM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	GPSM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	GWM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	HVAC	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	IPC	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	IPM-B	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	OCSM	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	PAM	●	●	○	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus	23kWh	Battery Electric Vehicle	2012	PCM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	PDM	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	PSCM	●	●	●	●	○
Focus	23kWh	Battery Electric Vehicle	2012	RCM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	RFA	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	SASM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	TCM	●	●	●	○	○
Focus	23kWh	Battery Electric Vehicle	2012	TCU#1	●	●	●	○	○
Focus	Other	Other	2013	ABS	●	●	●	○	○
Focus	Other	Other	2013	ACM	●	●	●	●	○
Focus	Other	Other	2013	APIM	●	●	●	●	○
Focus	Other	Other	2013	BCM#1	●	●	●	●	○
Focus	Other	Other	2013	DDM	●	●	●	●	○
Focus	Other	Other	2013	DSP	●	●	●	○	○
Focus	Other	Other	2013	FCDIM	●	●	●	●	○
Focus	Other	Other	2013	FCIM	●	●	●	●	○
Focus	Other	Other	2013	GPSM	●	●	●	○	○
Focus	Other	Other	2013	HVAC	●	●	●	●	○
Focus	Other	Other	2013	IPC	●	●	●	●	○
Focus	Other	Other	2013	IPM-B	●	●	●	○	○
Focus	Other	Other	2013	OCSM	●	●	●	●	○
Focus	Other	Other	2013	PAM	●	●	○	○	○
Focus	Other	Other	2013	PDM	●	●	●	●	○
Focus	Other	Other	2013	PSCM	●	●	●	○	00CB 00CC
Focus	Other	Other	2013	RCM	●	●	●	○	○
Focus	Other	Other	2013	RFA	●	●	●	○	○
Focus	Other	Other	2013	SASM	●	●	●	○	○
Focus C-MAX	1.4L	DURATEC 16V	2002	RL DCU	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002	RR DCU	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	ABS	●	●	●	●	0008 0029 002A 002C 00DD 00DE 002B 00E8
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	ACM	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	CDP	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	D DCU	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	EATC	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	EPB	●	●	●	●	001F

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	FFH	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	GDM	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	GEM	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	HCM	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	IC	●	●	●	●	0009
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	NAV	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	PAM	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	PCM	●	●	●	●	0025
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	P DCU	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RCM	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RETM	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RKE	●	●	●	●	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	SRM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002	RL DCU	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002	RR DCU	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	EPB	●	●	●	●	001F
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	GDM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	NAV	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	ABS	●	●	●	●	0008 0029 002A 002C 00DD 00DE 002B 00E8
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	ACM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	CDP	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	D DCU	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	EATC	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	FFH	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	GEM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	HCM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	IC	●	●	●	●	0009
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	PAM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	PCM	●	●	●	●	0025
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	P DCU	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RCM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RETM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RKE	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	SRM	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC 16V	2008	CMR	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus C-MAX	1. 6L	DURATEC 16V	2008	EPS	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2002	RL DCU	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002	RR DCU	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2007	EPB	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2007	GDM	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2007	NAV	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	CDP	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	D DCU	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	EATC	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	FFH	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	GEM	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	IC	●	●	●	●	0009
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	P DCU	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	RETM	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2008	RKE	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2011	ABS	●	●	●	○	002B 002C 0053 00D9 00DB 0008 0029 002A
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2011	ACM	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2011	HCM	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2011	PAM	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2011	PCM	●	●	●	●	0025
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2011	RCM	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 - 2011	SRM	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2008	CMR	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2008	EPS	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	AHCM	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	BCMii	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	DDM	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	FCDIM	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	HVAC	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	IPC	●	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	IPM-A	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	IPM-B	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	PDM	●	●	●	○	○
Focus C-MAX	1. 6L	DURATEC VCT	2011	PSCM	●	●	●	●	00DC
Focus C-MAX	1. 6L	DURATEC VCT	2011	RFA	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus C-MAX	1.6L	DURATEC VCT	2011	RGTm	●	●	●	●	○
Focus C-MAX	1.6L	DURATEC VCT	2011	SASM	●	●	●	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	SOD-L	●	●	●	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	SOD-R	●	●	●	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	TRM	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002	RL DCU	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002	RR DCU	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	●	●	●	●	001F
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	TCM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D DCU	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FACM	●	●	●	●	006B 0094 00A1
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	●	●	●	●	0009
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P DCU	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ABS	●	●	●	●	0008 0029 002A 002B 002C 00E8 00DD 00DE 0053 00D9 00DB
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ACM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	HCM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PAM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	●	●	●	●	0090 0092 0096 0097 0098 0099 009A 00B1 00B3 00B9 00BC 00BD
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RCM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	SRM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●	●	00DC 00DF 00E0 00E1
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●	●	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	●	●	●	○	002B 002C 0053 00D9
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	●	●	●	●	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	●	●	●	●	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	●	●	●	●	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	●	●	●	●	00DC 00DF 00E0 00E1
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	●	●	●	●	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RGTM	●	●	●	●	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●	○	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002	RL DCU	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002	RR DCU	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	EPB	●	●	●	●	001F
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	GDM	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	NAV	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	TCM	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	ABS	●	●	●	●	0008 0029 002A 002B 002C 00E8 00DD 00DE
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	ACM	●	●	●	●	0005
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	CDP	●	●	●	●	0005
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	D DCU	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	EATC	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	EPS	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	FFH	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	GEM	●	●	●	●	0005
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	HCM	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	IC	●	●	●	●	0009
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	PAM	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	PCM	●	●	●	●	0025
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	P DCU	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RCM	●	●	●	●	0005
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RETM	●	●	●	●	0005
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RKE	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	SRM	●	●	●	●	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2008	CMR	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	RL DCU	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	RR DCU	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	●	●	●	●	001F
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	ABS	●	●	●	●	0008 0029 002A 002B 002C 00E8 00DD 00DE
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	ACM	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D DCU	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	HCM	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	●	●	●	●	0009
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PAM	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	●	●	●	●	006F 00B4
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P DCU	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	SRM	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●	●	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	FACM	●	●	●	●	006B
Focus C-MAX	2.0L	DURATEC-HE / I4	2002	RL DCU	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002	RR DCU	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	EPB	●	●	●	●	001F
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	GDM	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	NAV	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	ABS	●	●	●	●	0008 0029 002A 002B 002C 00DD 00DE 00E8
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	ACM	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	CDP	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	D DCU	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	EATC	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	EPS	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	FFH	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	GEM	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	HCM	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	IC	●	●	●	●	0009
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	PAM	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	PCM	●	●	●	●	0025
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	P DCU	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RCM	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RETM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RKE	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	SRM	●	●	●	●	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2008	CMR	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002	RL DCU	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002	RR DCU	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	●	●	●	●	001F
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D DCU	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FACM	●	●	●	●	006B 0094 00A1
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	●	●	●	●	0009
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P DCU	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ABS	●	●	●	○	002B 002C 0053 00D9 00DB 00E8 0008 0029 002A 00DD 00DE
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ACM	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	HCM	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PAM	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	●	●	●	○	0092 0098 0099 009A 00A4 00B0 00B1 00B3 00B7 00B8 00B9 00BC 00BF 00C1 0090 00AB
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RCM	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	SRM	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008 - 2011	TCM	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●	●	00DC
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●	●	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●	○	○
Fusion	1.25L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fusion	1.25L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fusion	1.25L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fusion	1.25L	DURATEC 16V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fusion	1.25L	DURATEC 16V	2002 - 2006	RCM	●	●	●	●	○
Fusion	1.25L	DURATEC 16V	2006	ACM	●	●	●	●	○
Fusion	1.25L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fusion	1.25L	DURATEC 16V	2006	SRM	●	●	●	●	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fusion	1.4L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fusion	1.4L	DURATEC 16V	2002 - 2006	RCM	●	●	●	●	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	TCM	●	●	●	●	○
Fusion	1.4L	DURATEC 16V	2006	ACM	●	●	●	●	○
Fusion	1.4L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fusion	1.4L	DURATEC 16V	2006	SRM	●	●	●	●	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●	●	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●	●	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●	●	0009
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	●	●	●	●	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●	●	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Fusion	1.6L	DURATEC 16V	2002	TCM	●	●	●	●	○
Fusion	1.6L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●	●	0008
Fusion	1.6L	DURATEC 16V	2002 - 2006	GEM	●	●	●	●	○
Fusion	1.6L	DURATEC 16V	2002 - 2006	IC	●	●	●	●	○
Fusion	1.6L	DURATEC 16V	2002 - 2006	PCM	●	●	●	●	0009 0025
Fusion	1.6L	DURATEC 16V	2002 - 2006	RCM	●	●	●	●	○
Fusion	1.6L	DURATEC 16V	2006	ACM	●	●	●	●	○
Fusion	1.6L	DURATEC 16V	2006	EATC	●	●	●	●	○
Fusion	1.6L	DURATEC 16V	2006	SRM	●	●	●	●	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●	●	0008 0012
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	●	●	●	●	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●	●	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●	●	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●	●	0009 0092 0096 0097 0099 009A 00AD 00AE
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	●	●	●	●	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●	●	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●	●	000F
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DACM-C	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	●	●	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	●	●	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●	●	0023 0025
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-E	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-G	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-H	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	●	●	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●	●	000F
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DACM-C	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	●	●	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	●	●	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●	●	0023 0025
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTm	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-E	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-G	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-H	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	●	●	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	ABS	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	ACCM#2	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	ACM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	APIM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	BCM#1	●	●	●	●	000F
Fusion	2.0L	HEV / ATKINSON 4V	2013	BECM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	C-CM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DACM-C	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DCDC	●	●	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DDM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DSM	●	●	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DSP	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	FCDIM	●	●	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	FCIM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	GFM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	GPSP	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	2.0L	HEV / ATKINSON 4V	2013	GWM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	HCM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	HSWM	●	●	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	HUD	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	IPC	●	●	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	IPM-A	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	OCSM	●	●	●	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	PAM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	PCM	●	●	●	●	0025
Fusion	2.0L	HEV / ATKINSON 4V	2013	PDM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	PSCM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RACM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RCM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RGTM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RTM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCCM	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-E	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-G	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-H	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOBDM-C	●	●	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOD-L	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOD-R	●	●	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	VDM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	ABS	●	●	●	○	○
Fusion	2.0L	PHEV	2013	ACM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	APIM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	BCM#1	●	●	●	●	000F
Fusion	2.0L	PHEV	2013	C-CM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	DACM-C	●	●	●	○	○
Fusion	2.0L	PHEV	2013	DDM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	DSM	●	●	●	●	○
Fusion	2.0L	PHEV	2013	DSP	●	●	●	○	○
Fusion	2.0L	PHEV	2013	FCDIM	●	●	●	●	○
Fusion	2.0L	PHEV	2013	FCIM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	GFM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	GPSM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	2.0L	PHEV	2013	GWM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	HCM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	HSWM	●	●	●	●	○
Fusion	2.0L	PHEV	2013	HUD	●	●	●	○	○
Fusion	2.0L	PHEV	2013	IPC	●	●	●	●	○
Fusion	2.0L	PHEV	2013	IPM-A	●	●	●	○	○
Fusion	2.0L	PHEV	2013	OCSM	●	●	●	○	○
Fusion	2.0L	PHEV	2013	PAM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	PCM	●	●	●	●	0023 0025
Fusion	2.0L	PHEV	2013	PDM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	PSCM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	RACM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	RCM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	RGTM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	RTM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	SCCM	●	●	○	○	○
Fusion	2.0L	PHEV	2013	SCM-E	●	●	○	○	○
Fusion	2.0L	PHEV	2013	SCM-G	●	●	○	○	○
Fusion	2.0L	PHEV	2013	SCM-H	●	●	○	○	○
Fusion	2.0L	PHEV	2013	SOBDM-C	●	●	○	○	○
Fusion	2.0L	PHEV	2013	SOD-L	●	●	○	○	○
Fusion	2.0L	PHEV	2013	SOD-R	●	●	○	○	○
Fusion	2.0L	PHEV	2013	VDM	●	●	○	○	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2007	EATC	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2007	GEM	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	ABS	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	ACM	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	IC	●	●	●	●	0005 0009
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	OCSM	●	●	●	○	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	PCM	●	●	●	●	0023
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	RCM	●	●	●	●	0005
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	TBM	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	TCM	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2007 - 2009	4X4	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2007 - 2009	SDARS	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	APIM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	GEM / SJB	●	●	●	●	0042
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	HVAC	●	●	●	●	○
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	PAM	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	4X4	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	ABS	●	●	●	●	0012
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	ACM	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	APIM	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	DSP	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	FCIM	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	FDIM	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	GEM / SJB	●	●	●	●	000A 000F 0042
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	GPSM	●	●	●	○	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	HVAC	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	IPC	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	OCSM	●	●	●	●	000C 0015
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PAM	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PCM	●	●	●	●	0009 0025
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PSCM	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	RCM	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	SOD-L	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	SOD-R	●	●	●	●	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	TBM	●	●	●	○	0000 00D2
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	4X4	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ABS	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACCM#2	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACM	●	●	●	●	0005
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	APIM	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	BECM	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	DCDC	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	DSP	●	●	●	●	0005
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	FCIM	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	FDIM	●	●	●	●	0005
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	GEM / SJB	●	●	●	●	000A 000F 0042
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	GPSM	●	●	●	○	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	HVAC	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	IPC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	OCSM	●	●	●	●	000C 0015
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PAM	●	●	●	●	0005
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PSCM	●	●	●	●	0005
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	RCM	●	●	●	●	0005
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	SOD-L	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	SOD-R	●	●	●	●	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	TBM	●	●	●	○	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	TCM	●	●	●	●	○
Fusion	2.5L	IVCT	2013	ABS	●	●	●	○	○
Fusion	2.5L	IVCT	2013	ACM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	APIM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	BCM#1	●	●	●	●	○
Fusion	2.5L	IVCT	2013	C-CM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	DACM-C	●	●	●	○	○
Fusion	2.5L	IVCT	2013	DDM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	DSM	●	●	●	●	○
Fusion	2.5L	IVCT	2013	DSP	●	●	●	○	○
Fusion	2.5L	IVCT	2013	FCDIM	●	●	●	●	○
Fusion	2.5L	IVCT	2013	FCIM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	GFM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	GPSM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	GWM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	HCM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	HSWM	●	●	●	●	○
Fusion	2.5L	IVCT	2013	HUD	●	●	●	○	○
Fusion	2.5L	IVCT	2013	IPC	●	●	●	●	○
Fusion	2.5L	IVCT	2013	IPM-A	●	●	●	○	○
Fusion	2.5L	IVCT	2013	OCSM	●	●	●	○	○
Fusion	2.5L	IVCT	2013	PAM	●	●	○	○	○
Fusion	2.5L	IVCT	2013	PCM	●	●	●	●	○
Fusion	2.5L	IVCT	2013	PDM	●	●	○	○	○
Fusion	2.5L	IVCT	2013	PSCM	●	●	○	○	○
Fusion	2.5L	IVCT	2013	RACM	●	●	○	○	○
Fusion	2.5L	IVCT	2013	RCM	●	●	○	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	2.5L	IVCT	2013	RGTM	●	●	○	○	○
Fusion	2.5L	IVCT	2013	RTM	●	●	○	○	○
Fusion	2.5L	IVCT	2013	SCCM	●	●	○	○	○
Fusion	2.5L	IVCT	2013	SCM-E	●	●	○	○	○
Fusion	2.5L	IVCT	2013	SCM-G	●	●	○	○	○
Fusion	2.5L	IVCT	2013	SCM-H	●	●	○	○	○
Fusion	2.5L	IVCT	2013	SOD-L	●	●	○	○	○
Fusion	2.5L	IVCT	2013	SOD-R	●	●	○	○	○
Fusion	2.5L	IVCT	2013	VDM	●	●	○	○	○
Fusion	3.0L	4V	2006 - 2007	EATC	●	●	●	●	○
Fusion	3.0L	4V	2006 - 2007	GEM	●	●	●	●	○
Fusion	3.0L	4V	2006 - 2009	IC	●	●	●	●	0005
Fusion	3.0L	4V	2006 - 2009	TCM	●	●	●	●	○
Fusion	3.0L	4V	2006 - 2012	ABS	●	●	●	●	0012
Fusion	3.0L	4V	2006 - 2012	ACM	●	●	●	●	○
Fusion	3.0L	4V	2006 - 2012	OCSM	●	●	●	○	000C 0015
Fusion	3.0L	4V	2006 - 2012	PCM	●	●	●	●	0023 0009 0025
Fusion	3.0L	4V	2006 - 2012	RCM	●	●	●	●	0005
Fusion	3.0L	4V	2006 - 2012	TBM	●	●	●	●	○
Fusion	3.0L	4V	2007 - 2009	SDARS	●	●	●	●	0005
Fusion	3.0L	4V	2007 - 2012	4X4	●	●	●	●	○
Fusion	3.0L	4V	2008 - 2012	APIM	●	●	●	●	○
Fusion	3.0L	4V	2008 - 2012	GEM / SJB	●	●	●	●	0005 000A 000F 0042
Fusion	3.0L	4V	2008 - 2012	HVAC	●	●	●	●	○
Fusion	3.0L	4V	2008 - 2012	PAM	●	●	●	●	0005
Fusion	3.0L	4V	2010 - 2012	DSP	●	●	●	●	○
Fusion	3.0L	4V	2010 - 2012	FCIM	●	●	●	●	○
Fusion	3.0L	4V	2010 - 2012	FDIM	●	●	●	●	○
Fusion	3.0L	4V	2010 - 2012	GPSM	●	●	●	○	○
Fusion	3.0L	4V	2010 - 2012	IPC	●	●	●	●	○
Fusion	3.0L	4V	2010 - 2012	PSCM	●	●	●	●	○
Fusion	3.0L	4V	2010 - 2012	SOD-L	●	●	●	●	○
Fusion	3.0L	4V	2010 - 2012	SOD-R	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	4X4	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	ABS	●	●	●	●	0005 0008 0012
Fusion	3.5L	4V	2010 - 2012	ACM	●	●	●	●	0017

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fusion	3.5L	4V	2010 - 2012	APIM	●	●	●	●	0019 001C
Fusion	3.5L	4V	2010 - 2012	DSP	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	FCIM	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	FDIM	●	●	●	●	0005
Fusion	3.5L	4V	2010 - 2012	GEM / SJB	●	●	●	●	000A 000F 0042
Fusion	3.5L	4V	2010 - 2012	GPSM	●	●	●	○	○
Fusion	3.5L	4V	2010 - 2012	HVAC	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	IPC	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	OCSM	●	●	●	●	000C 0015
Fusion	3.5L	4V	2010 - 2012	PAM	●	●	●	●	0005
Fusion	3.5L	4V	2010 - 2012	PCM	●	●	●	●	0023 0025 0037
Fusion	3.5L	4V	2010 - 2012	PSCM	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	RCM	●	●	●	●	0005
Fusion	3.5L	4V	2010 - 2012	SOD-L	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	SOD-R	●	●	●	●	○
Fusion	3.5L	4V	2010 - 2012	TBM	●	●	●	○	○
Fusion	3.5L	4V	2010 - 2012	TCM	●	●	●	○	○
Fusion	Other	Other	2012	4X4	●	●	●	●	○
Fusion	Other	Other	2012	ABS	●	●	●	●	○
Fusion	Other	Other	2012	ACM	●	●	●	○	○
Fusion	Other	Other	2012	APIM	●	●	●	●	○
Fusion	Other	Other	2012	DSP	●	●	●	●	○
Fusion	Other	Other	2012	FCIM	●	●	●	●	○
Fusion	Other	Other	2012	FDIM	●	●	●	●	○
Fusion	Other	Other	2012	GEM / SJB	●	●	●	●	0042
Fusion	Other	Other	2012	GPSM	●	●	●	●	○
Fusion	Other	Other	2012	HVAC	●	●	●	●	○
Fusion	Other	Other	2012	IPC	●	●	●	●	0009
Fusion	Other	Other	2012	OCSM	●	●	●	●	○
Fusion	Other	Other	2012	PAM	●	●	●	●	○
Fusion	Other	Other	2012	PSCM	●	●	●	●	○
Fusion	Other	Other	2012	RCM	●	●	●	●	○
Fusion	Other	Other	2012	SOD-L	●	●	●	●	○
Fusion	Other	Other	2012	SOD-R	●	●	●	●	○
Fusion	Other	Other	2012	TBM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	ABS	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	ACM	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	AHCM	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	BCMii	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CCMii	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CDP	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CMR	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	DDM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	DSM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	HCM	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	HVAC	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	IPC	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	IPM-A	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	NAV	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PAM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PBM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PCM	●	●	●	●	0090 0092 0098 0099 009A 00B1 00B7 00B9 00BC 00BD 00C1 00C3
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PDM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PSCM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RCM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RFA	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RGTM	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RHVAC	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SASM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-L	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-R	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SRM	●	●	●	○	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	TRM	●	●	●	●	○
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	VDM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	AHCM	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	BCMii	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CCMii	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CDP	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CMR	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPM-A	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	NAV	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PBM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PDM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RGTM	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RHVAC	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SRM	●	●	●	○	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	TRM	●	●	●	●	○
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	VDM	●	●	●	○	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●	●	002B 0053 0054 00D9
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	AHCM	●	●	●	○	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	CCMii	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	CDP	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	DDM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	HCM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	HVAC	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	NAV	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PBM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	●	006F 0090 0092 0098 0099 009A 00AB 00AC
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PDM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PSCM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●	○	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RFA	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RGTM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RHVAC	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	SASM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	TRM	●	●	●	●	○
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	VDM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006	GDM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	ABS	●	●	●	●	002B 0053 0054 00D9
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	ACM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	AHCM	●	●	●	○	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	BCMii	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	CCMii	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	CDP	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	DDM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	HCM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	HVAC	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	IPC	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	NAV	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PAM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PBM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PCM	●	●	●	●	00AC
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PDM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PSCM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RCM	●	●	●	○	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RFA	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RGTM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RHVAC	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	SASM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	SRM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	TRM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	VDM	●	●	●	●	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	CMR	●	●	●	○	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	DSM	●	●	●	○	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	IPM-A	●	●	●	○	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	SOD-L	●	●	●	○	○
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	SOD-R	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	ABS	●	●	●	●	002B 0053 0054 00D9
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	ACM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	AHCM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	BCMii	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	CCMii	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	CDP	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	DDM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	HCM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	HVAC	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	IPC	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	NAV	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PAM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PBM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PCM	●	●	●	●	006F 0090 0092 0098 0099 009A 00AB 00AC
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PDM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PSCM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RCM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RFA	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RGTM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RHVAC	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	SASM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	SRM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	TCM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	TRM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	VDM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	CMR	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	DABM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	DSM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	IPM-A	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-L	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-R	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ABS	●	●	●	○	002B 0053 0054 00D9 00E2
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ACM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	AHCM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	BCMii	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CCMii	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CDP	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CMR	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DDM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DSM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HCM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HVAC	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPC	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPM-A	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	NAV	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PAM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PBM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PCM	●	●	●	○	0092 0098 0099 009A 00A4 00B0 00B1 00B3 00B7 00B8 00B9 00BC
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PDM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PSCM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RCM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RFA	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RGTM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RHVAC	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SASM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-L	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-R	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SRM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TCM	●	●	●	○	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TRM	●	●	●	●	○
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	VDM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS	●	●	●	○	002B 0053 0054 00D9
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	AHCM	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	BCMii	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CCMii	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CDP	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CMR	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPM-A	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	NAV	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PBM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PDM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RGTM	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RHVAC	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SRM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	TCM	●	●	●	○	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	TRM	●	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	VDM	●	●	●	○	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●	●	002B 0053 0054 00D9
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	AHCM	●	●	●	○	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CCMii	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CDP	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	DDM	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	HCM	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	HVAC	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	NAV	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PBM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	●	0090 0092 0098 0099 009A 00A5 00AA 00AF 00B0 00B1 00B2 00B8
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PDM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PSCM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	RFA	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	RGTM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	RHVAC	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	SASM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	TRM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	VDM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ABS	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ACM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	AHCM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	BCMii	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CCMii	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CDP	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CMR	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DDM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DSM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HCM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HVAC	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPM-A	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	NAV	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PAM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PBM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PCM	●	●	●	○	0090 0092 0098 0099 009A 00AF 00B0 00B1 00B2 00B8 00B9 00BE
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PDM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PSCM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RCM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RFA	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RGTM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RHVAC	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SASM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-L	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-R	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SRM	●	●	●	○	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TRM	●	●	●	●	○
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	VDM	●	●	●	○	○
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006	GDM	●	●	●	●	○
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	ABS	●	●	●	●	002B 0053 0054 00D9
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	ACM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	AHCM	●	●	●	○	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	BCMii	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	CCMii	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	CDP	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	DDM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	HCM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	HVAC	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	IPC	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	NAV	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PAM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PBM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PCM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PDM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PSCM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	RCM	●	●	●	○	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	RFA	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	RGTM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	RHVAC	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	SASM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	SRM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	TCM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	TRM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	VDM	●	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2010	CMR	●	●	●	○	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2010	DABM	●	●	●	○	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2010	DSM	●	●	●	○	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2010	IPM-A	●	●	●	○	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2010	SOD-L	●	●	●	○	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2010	SOD-R	●	●	●	○	○
GALAXY\S-Max	2.5L	I5	2006	ABS	●	●	●	●	002B 0053 0054 00D9
GALAXY\S-Max	2.5L	I5	2006	ACM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	AHCM	●	●	●	○	○
GALAXY\S-Max	2.5L	I5	2006	BCMii	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	CCMii	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	CDP	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	DDM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
GALAXY\S-Max	2.5L	I5	2006	GDM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	HCM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	HVAC	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	IPC	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	NAV	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	PAM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	PBM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	PCM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	PDM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	PSCM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	RCM	●	●	●	○	○
GALAXY\S-Max	2.5L	I5	2006	RFA	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	RGTM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	RHVAC	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	SASM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	SRM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	TRM	●	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	VDM	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001	FFH	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001	LHID	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001	MFSW	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001	PAM	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001	RADIO	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001	RCC	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001	RHID	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001	RNS	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 -	ABS	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 -	CCM	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 -	CJB	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 -	IC	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 -	PATS	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 -	PCM	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 -	RCM	●	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 -	TCM	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	ABS	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	CCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	CJB	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	IC	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	PATS	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	PCM	●	●	●	●	0025 0009
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	RCM	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	TCM	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	LHID	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	MFSW	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	PAM	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RADIO	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RCC	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RHID	●	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RNS	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	ABS	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	CCM	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	CJB	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	IC	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	PATS	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	PCM	●	●	●	●	0025 0009
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	RCM	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	TCM	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	2000	LHID	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	2000	MFSW	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	2000	PAM	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	2000	RADIO	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	2000	RCC	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	2000	RHID	●	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	2000	RNS	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001	LHID	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001	MFSW	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001	PAM	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001	RADIO	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001	RCC	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001	RHID	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001	RNS	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001 -	ABS	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Galaxy	2.8L	2.8 CD-V6	2001 -	CCM	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001 -	CJB	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001 -	IC	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001 -	PATS	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001 -	PCM	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001 -	RCM	●	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001 -	TCM	●	●	●	●	○
KA	1.0L	HCS	1997	PATS	●	●	●	●	○
KA	1.0L	HCS	1997 - 1999	ABS/TCS	●	●	●	●	○
KA	1.0L	HCS	1997 - 1999	CSM	●	●	●	●	○
KA	1.0L	HCS	1997 - 1999	PCM	●	●	●	●	0025 0009
KA	1.0L	HCS	1999	ECS	●	●	●	●	○
KA	1.0L	Zetec Rocam	1999	ABS/TCS	●	●	●	●	○
KA	1.0L	Zetec Rocam	1999	CSM	●	●	●	●	○
KA	1.0L	Zetec Rocam	1999	PCM	●	●	●	●	0009 0023 0025
KA	1.2L	DURATEC 8V	2009	ABS	●	●	●	●	○
KA	1.2L	DURATEC 8V	2009	BCMii	●	●	●	●	○
KA	1.2L	DURATEC 8V	2009	EPS	●	●	●	●	○
KA	1.2L	DURATEC 8V	2009	PAM	●	●	●	○	○
KA	1.3L	DURATEC 8V	2000	ABS/TCS	●	●	●	●	○
KA	1.3L	DURATEC 8V	2000	CSM	●	●	●	●	○
KA	1.3L	DURATEC 8V	2000	ECS	●	●	●	●	○
KA	1.3L	DURATEC 8V	2000	GEM	●	●	●	●	○
KA	1.3L	DURATEC 8V	2000	PCM	●	●	●	●	0009 0025
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	ABS	●	●	●	●	○
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	BCMii	●	●	●	●	○
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	EPS	●	●	●	●	○
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	PAM	●	●	●	○	○
KA	1.3L	Endura-E	1997 -	PATS	●	●	●	●	○
KA	1.3L	Endura-E	1997 - 2000	ABS/TCS	●	●	●	●	○
KA	1.3L	Endura-E	1997 - 2000	CSM	●	●	●	●	○
KA	1.3L	Endura-E	1997 - 2000	PCM	●	●	●	●	0009 0023 0025
KA	1.3L	Endura-E	1999 - 2000	ECS	●	●	●	●	○
KA	1.3L	Endura-E	2000	GEM	●	●	●	●	○
KA	1.6L	DURATEC 8V	2000	ABS/TCS	●	●	●	●	○
KA	1.6L	DURATEC 8V	2000	CSM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
KA	1.6L	DURATEC 8V	2000	ECS	●	●	●	●	○
KA	1.6L	DURATEC 8V	2000	GEM	●	●	●	●	○
KA	1.6L	DURATEC 8V	2000	PCM	●	●	●	●	0009 0025
KA	1.6L	Zetec Rocam	2001	ABS/TCS	●	●	●	●	○
KA	1.6L	Zetec Rocam	2001	CSM	●	●	●	●	○
KA	1.6L	Zetec Rocam	2001	ECS	●	●	●	●	○
KA	1.6L	Zetec Rocam	2001	PCM	●	●	●	●	0009 0025
KA	Other	Other	2009	ABS	●	●	●	●	○
KA	Other	Other	2009	BCMii	●	●	●	●	○
KA	Other	Other	2009	EPS	●	●	●	●	○
KA	Other	Other	2009	PAM	●	●	●	○	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●	●	0008 0029 002A 002B 002C 00DD 00DE
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	AWD	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	D DCU	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	EATC	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	EPS	●	●	●	○	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	FFH	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	GEM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	HCM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	IC	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	PAM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	●	006F 0090 0092 0098 0099 00AB 00AC 00B4
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	P DCU	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RETM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RKE	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	●	●	●	●	0008 0029 002A 002B 002C 00DD 00DE
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	AWD	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CMR	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	D_DCU	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EATC	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EPS	●	●	●	○	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FFH	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	GEM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HCM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IC	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PAM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●	○	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	P_DCU	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RETM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RKE	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	●	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	TCM	●	●	●	●	○
Kuga	2.5L	I5	2008	ABS	●	●	●	●	0008 0029 002A 002B 002C 00DD 00DE
Kuga	2.5L	I5	2008	ACM	●	●	●	●	○
Kuga	2.5L	I5	2008	AWD	●	●	●	●	○
Kuga	2.5L	I5	2008	CMR	●	●	●	●	○
Kuga	2.5L	I5	2008	D_DCU	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Kuga	2.5L	I5	2008	EATC	●	●	●	●	○
Kuga	2.5L	I5	2008	EPS	●	●	●	○	○
Kuga	2.5L	I5	2008	FFH	●	●	●	●	○
Kuga	2.5L	I5	2008	GEM	●	●	●	●	○
Kuga	2.5L	I5	2008	HCM	●	●	●	●	○
Kuga	2.5L	I5	2008	IC	●	●	●	●	○
Kuga	2.5L	I5	2008	PAM	●	●	●	●	○
Kuga	2.5L	I5	2008	PCM	●	●	●	●	○
Kuga	2.5L	I5	2008	P_DCU	●	●	●	●	○
Kuga	2.5L	I5	2008	RCM	●	●	●	●	○
Kuga	2.5L	I5	2008	RETM	●	●	●	●	○
Kuga	2.5L	I5	2008	RKE	●	●	●	●	○
Kuga	2.5L	I5	2008	SRM	●	●	●	●	○
Kuga	2.5L	I5	2008	TCM	●	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	ABS	●	●	●	○	002B 0053 0054 00D9
MONDEO	1.6L	DURATEC VCT	2007 - 2011	ACM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	AHCM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	BCMii	●	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CCMii	●	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CDP	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CMR	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	DDM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	DSM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	HCM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	HVAC	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	IPC	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PAM	●	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PBM	●	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PCM	●	●	●	○	0025
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PDM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PSCM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	RCM	●	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	RFA	●	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	SASM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	SRM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	TRM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	1.6L	DURATEC VCT	2007 - 2011	VDM	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2011	IPM-A	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2011	RGTM	●	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2011	RHVAC	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2011	SOD-L	●	●	●	○	○
MONDEO	1.6L	DURATEC VCT	2011	SOD-R	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	●	●	●	○	002B 0054 00E2 00E8
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CCMii	●	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CDP	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CMR	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DSM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HCM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	●	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PBM	●	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●	●	0090 0092 0098 0099 009A 00B1 00B7 00B9 00BC 00BD 00C1 00C3
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	●	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RHVAC	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	●	●	●	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	VDM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	ABS	●	●	●	○	002B 0053 0054 00D9
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	ACM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	AHCM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	BCMii	●	●	●	●	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	CCMii	●	●	●	●	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	CDP	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	CMR	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	DDM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	DSM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	HCM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	HVAC	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	IPC	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	PAM	●	●	●	●	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	PBM	●	●	●	●	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	PCM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	PDM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	PSCM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	RCM	●	●	●	●	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	RFA	●	●	●	●	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	RGTM	●	●	●	●	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	RHVAC	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	SASM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	SRM	●	●	●	○	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	TRM	●	●	●	●	○
MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	2011	VDM	●	●	●	○	○
MONDEO	1.6L	Zetec	1993 – 1999	ABS	●	●	●	●	○
MONDEO	1.6L	Zetec	1993 – 1999	CSM	●	●	●	●	○
MONDEO	1.6L	Zetec	1993 – 1999	PATS	●	●	●	●	○
MONDEO	1.6L	Zetec	1997 – 1999	FFH	●	●	●	●	○
MONDEO	1.6L	Zetec	1997 – 1999	PCM	●	●	●	●	0023 0025
MONDEO	1.6L	Zetec	1998 – 1999	ABS/TCS	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	ABS	●	●	●	●	0008
MONDEO	1.8L	DURATEC-HE / I4	2001	ABS/TCS	●	●	●	●	0008

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	1.8L	DURATEC-HE / I4	2001	ACM	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	CDP	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	CSM	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	EATC	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	GDM	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	GEM	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	HEC	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	LHID	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	NAV	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	PATS	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	PCM	●	●	●	●	0009 0025
MONDEO	1.8L	DURATEC-HE / I4	2001	RCM	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	RETM	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	RHID	●	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	SRM	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	ABS	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	ABS/TCS	●	●	●	●	0008
MONDEO	1.8L	DURATEC-SCi	2001	ACM	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	CDP	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	CSM	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	EATC	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	GDM	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	GEM	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	HEC	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	LHID	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	NAV	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	PATS	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	PCM	●	●	●	●	0009 0025
MONDEO	1.8L	DURATEC-SCi	2001	RCM	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	RETM	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	RHID	●	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	SRM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	ABS	●	●	●	●	002B 0053 0054 00D9 00E2 00E8
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	ACM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	AHCM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	BCMii	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CCMii	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CDP	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CMR	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	DDM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	DSM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	HCM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	HVAC	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	IPC	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PAM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PBM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PCM	●	●	●	●	006F 0090 0092 0098 0099 009A 00AB 00AC
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PDM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PSCM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	RCM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	RFA	●	●	●	○	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	SASM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	SRM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	TRM	●	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	VDM	●	●	●	○	○
MONDEO	1.8L	Endura-DE	1997	FFH	●	●	●	●	○
MONDEO	1.8L	Endura-DE	1997	PCM	○	○	●	○	○
MONDEO	1.8L	Endura-DE	1997 -	ABS	●	●	●	●	○
MONDEO	1.8L	Endura-DE	1997 -	CSM	●	●	●	●	○
MONDEO	1.8L	Endura-DE	1997 -	PATS	●	●	●	●	○
MONDEO	1.8L	Zetec	1993 - 2000	ABS	●	●	●	●	○
MONDEO	1.8L	Zetec	1993 - 2000	CSM	●	●	●	●	○
MONDEO	1.8L	Zetec	1993 - 2000	PATS	●	●	●	●	○
MONDEO	1.8L	Zetec	1997 - 1999	FFH	●	●	●	●	○
MONDEO	1.8L	Zetec	1997 - 2000	PCM	●	●	●	●	0023 0025 0009
MONDEO	1.8L	Zetec	1998 - 2000	ABS/TCS	●	●	●	●	○
MONDEO	1.8L	Zetec	2000	AFCM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001	ABS/TCS	●	●	●	●	0008
MONDEO	2.0L	DURATEC-HE / I4	2001	CSM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001	EATC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2.0L	DURATEC-HE / I4	2001	GDM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001	GEM	●	●	●	●	0005
MONDEO	2.0L	DURATEC-HE / I4	2001	HEC	●	●	●	●	0005
MONDEO	2.0L	DURATEC-HE / I4	2001	LHID	●	●	●	●	0005
MONDEO	2.0L	DURATEC-HE / I4	2001	NAV	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001	PATS	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001	RETM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001	RHID	●	●	●	●	0005
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	ABS	●	●	●	●	0008 002B 0053 0054 00D9 00E2 00E8
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	ACM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	CDP	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	PCM	●	●	●	●	0009 0025 00AC
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	RCM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	SRM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	AHCM	●	●	●	○	○
MONDEO	2.0L	DURATEC-HE / I4	2007	BCMii	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	CCMii	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	CMR	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	DDM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	DSM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	HCM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	HVAC	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	IPC	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	PAM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	PBM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	PDM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	PSCM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	RFA	●	●	●	○	○
MONDEO	2.0L	DURATEC-HE / I4	2007	SASM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	TRM	●	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2007	VDM	●	●	●	○	○
MONDEO	2.0L	DURATORQ DI	2001	ABS	●	●	●	○	0008
MONDEO	2.0L	DURATORQ DI	2001	ABS/TCS	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	ACM	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	CDP	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2.0L	DURATORQ DI	2001	CSM	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	EATC	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	FFH	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	FIP	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	GDM	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	GEM	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	HEC	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	LHID	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	NAV	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	PATS	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	PCM	●	●	●	●	0009
MONDEO	2.0L	DURATORQ DI	2001	RCM	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	RETM	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	RHID	●	●	●	●	○
MONDEO	2.0L	DURATORQ DI	2001	SRM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	EATC	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	GDM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	GEM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	LHID	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	NAV	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PATS	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RETM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RHID	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	ABS	●	●	●	○	002B 0053 0054 00D9 00E2 00E8
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	ACM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	CDP	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	PCM	●	●	●	●	006F 0090 0092 0098 0099 009A 00AB 00AC
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	RCM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	SRM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	TCM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	AHCM	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	BCMii	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	CCMii	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	CMR	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	DDM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	DSM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	HCM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	HVAC	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	IPC	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PAM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PBM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PDM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PSCM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	RFA	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	SASM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	TRM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	VDM	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DABM	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RHVAC	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007	TCM	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	ABS	●	●	●	●	002B 0053 0054 00D9 00E2 00E8
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	ACM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	AHCM	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	BCMii	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CCMii	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CDP	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CMR	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	DDM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	DSM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	HCM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	HVAC	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	IPC	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PAM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PBM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PCM	●	●	●	○	0092 0098 0099 009A 00A4 00B0 00B1 00B3 00B7 00B8 00B9 00BC
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PDM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PSCM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	RCM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	RFA	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	SASM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	SRM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	TRM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	VDM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.
 As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPM-A	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RGTM	●	●	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RHVAC	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-L	●	●	●	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-R	●	●	●	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	ABS	●	●	●	●	002B 0053 0054 00D9 00E2 00E8
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	ACM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	AHCM	●	●	●	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	BCMii	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CCMii	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CDP	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CMR	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	DDM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	DSM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	HCM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	HVAC	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	IPC	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PAM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PBM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PCM	●	●	●	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PDM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PSCM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	RCM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	RFA	●	●	●	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	SASM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	SRM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	TCM	●	●	●	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	TRM	●	●	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	VDM	●	●	●	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RGTM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2011	RHVAC	●	●	●	○	○
MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●	○	○
MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●	○	○
MONDEO	2.0L	Zetec	1993 – 2000	ABS	●	●	●	●	○
MONDEO	2.0L	Zetec	1993 – 2000	CSM	●	●	●	●	○
MONDEO	2.0L	Zetec	1993 – 2000	PATS	●	●	●	●	○
MONDEO	2.0L	Zetec	1997 – 1999	FFH	●	●	●	●	○
MONDEO	2.0L	Zetec	1997 – 2000	PCM	●	●	●	●	0023 0025 0009
MONDEO	2.0L	Zetec	1998 – 2000	ABS/TCS	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	EATC	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	GDM	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	GEM	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	●	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	LHID	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	NAV	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	PATS	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	RETM	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	RHID	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 – 2007	ABS	●	●	●	○	0008 002B 0053 0054 00D9 00E2 00E8
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 – 2007	ACM	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 – 2007	CDP	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 – 2007	PCM	●	●	●	●	0009 0092 0090 0098 0099 009A 00A5 00AA 00AF 00B0 00B1 00B2
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 – 2007	RCM	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 – 2007	SRM	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	AHCM	●	●	●	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	BCMii	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	CCMii	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	CMR	●	●	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	DDM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	DSM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	HCM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	HVAC	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	IPC	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	PAM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	PBM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	PDM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	PSCM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	RFA	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	SASM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	TRM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2007	VDM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	ABS	●	●	●	○	00E8
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	ACM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	AHCM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	BCMii	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CCMii	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CDP	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CMR	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	DDM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	DSM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	HCM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	HVAC	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPC	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPM-A	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PAM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PBM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PCM	●	●	●	○	0090 0092 0098 0099 009A 00AF 00B0 00B1 00B2 00B8 00B9 00BE
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PDM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PSCM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RCM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RFA	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RGTM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RHVAC	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SASM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-L	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-R	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SRM	●	●	●	○	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	TRM	●	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	VDM	●	●	●	○	○
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	ABS	●	●	●	●	00E8 002B 0053 0054 00D9 00E2
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	ACM	●	●	●	●	○
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	AHCM	●	●	●	○	○
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	BCMii	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	CCMii	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	CDP	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	CMR	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	DDM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	DSM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	HCM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	HVAC	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	IPC	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PAM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PBM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PCM	●	●	●	●	0025 00AC
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PDM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PSCM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	RCM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	RFA	●	●	●	○	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	SASM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	SRM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	TCM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	TRM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	VDM	●	●	●	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	DABM	●	●	●	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	IPM-A	●	●	●	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	RGTM	●	●	●	●	○
MONDEO	2.3L	DURATEC-HE / I4	2011	RHVAC	●	●	●	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	SOD-L	●	●	●	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	SOD-R	●	●	●	○	○
MONDEO	2.5L	Duratec-VE	1994 - 2001	ABS	●	●	●	●	0008
MONDEO	2.5L	Duratec-VE	1994 - 2001	CSM	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	1994 - 2001	PATS	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	1997 - 1999	FFH	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	1997 - 2001	PCM	●	●	●	●	0023 0025 0009
MONDEO	2.5L	Duratec-VE	1998 - 2001	ABS/TCS	●	●	●	●	0008
MONDEO	2.5L	Duratec-VE	2001	ACM	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	CDP	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	EATC	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	GDM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	2.5L	Duratec-VE	2001	GEM	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	HEC	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	LHID	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	NAV	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	RCM	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	RETM	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	RHID	●	●	●	●	○
MONDEO	2.5L	Duratec-VE	2001	SRM	●	●	●	●	○
MONDEO	2.5L	I5	2007	ABS	●	●	●	●	002B 0053 0054 00D9
MONDEO	2.5L	I5	2007	ACM	●	●	●	●	○
MONDEO	2.5L	I5	2007	AHCM	●	●	●	○	○
MONDEO	2.5L	I5	2007	BCMii	●	●	●	●	○
MONDEO	2.5L	I5	2007	CCMii	●	●	●	●	○
MONDEO	2.5L	I5	2007	CDP	●	●	●	●	○
MONDEO	2.5L	I5	2007	CMR	●	●	●	●	○
MONDEO	2.5L	I5	2007	DDM	●	●	●	●	○
MONDEO	2.5L	I5	2007	DSM	●	●	●	●	○
MONDEO	2.5L	I5	2007	HCM	●	●	●	●	○
MONDEO	2.5L	I5	2007	HVAC	●	●	●	●	○
MONDEO	2.5L	I5	2007	IPC	●	●	●	●	○
MONDEO	2.5L	I5	2007	PAM	●	●	●	●	○
MONDEO	2.5L	I5	2007	PBM	●	●	●	●	○
MONDEO	2.5L	I5	2007	PCM	●	●	●	●	○
MONDEO	2.5L	I5	2007	PDM	●	●	●	●	○
MONDEO	2.5L	I5	2007	PSCM	●	●	●	●	○
MONDEO	2.5L	I5	2007	RCM	●	●	●	●	○
MONDEO	2.5L	I5	2007	RFA	●	●	●	○	○
MONDEO	2.5L	I5	2007	SASM	●	●	●	●	○
MONDEO	2.5L	I5	2007	SRM	●	●	●	●	○
MONDEO	2.5L	I5	2007	TRM	●	●	●	●	○
MONDEO	2.5L	I5	2007	VDM	●	●	●	○	○
MONDEO	3.0L	Duratec SE	2001	ABS	●	●	●	●	0008
MONDEO	3.0L	Duratec SE	2001	ABS/TCS	●	●	●	●	0008
MONDEO	3.0L	Duratec SE	2001	ACM	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	CDP	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	CSM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MONDEO	3.0L	Duratec SE	2001	EATC	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	GDM	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	GEM	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	HEC	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	LHID	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	NAV	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	PATS	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	PCM	●	●	●	●	0009 0025
MONDEO	3.0L	Duratec SE	2001	RCM	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	RETM	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	RHID	●	●	●	●	○
MONDEO	3.0L	Duratec SE	2001	SRM	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	ABS	●	●	●	●	0008
MONDEO	3.0L	Duratec-ST	2001	ABS/TCS	●	●	●	●	0008
MONDEO	3.0L	Duratec-ST	2001	ACM	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	CDP	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	CSM	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	EATC	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	GDM	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	GEM	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	HEC	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	LHID	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	NAV	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	PATS	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	PCM	●	●	●	●	0009 0025
MONDEO	3.0L	Duratec-ST	2001	RCM	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	RETM	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	RHID	●	●	●	●	○
MONDEO	3.0L	Duratec-ST	2001	SRM	●	●	●	●	○
Puma	1.4L	Zetec-SE	19985 -	ABS/TCS	●	●	●	●	○
Puma	1.4L	Zetec-SE	19985 -	HEC	●	●	●	●	○
Puma	1.4L	Zetec-SE	19985 -	PATS	○	○	●	○	○
Puma	1.4L	Zetec-SE	19985 -	PCM	●	●	●	●	0023 0025
Puma	1.4L	Zetec-SE	1999	GEM	●	●	●	●	○
Puma	1.6L	Zetec-SE	2001	ABS/TCS	●	●	●	●	○
Puma	1.6L	Zetec-SE	2001	GEM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Puma	1.6L	Zetec-SE	2001	HEC	●	●	●	●	○
Puma	1.6L	Zetec-SE	2001	PATS	●	●	●	●	○
Puma	1.6L	Zetec-SE	2001	PCM	●	●	●	●	0009 0023 0025
Puma	1.7L	Zetec-SE	1997 - 2001	ABS/TCS	●	●	●	●	○
Puma	1.7L	Zetec-SE	1997 - 2001	HEC	●	●	●	●	○
Puma	1.7L	Zetec-SE	1997 - 2001	PATS	●	●	●	●	○
Puma	1.7L	Zetec-SE	1997 - 2001	PCM	●	●	●	●	0023 0025
Puma	1.7L	Zetec-SE	1999 - 2001	GEM	●	●	●	●	○
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	4X4	●	●	●	●	○
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	ABS/TCS	●	●	●	●	0008
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	GEM	●	●	●	●	000A
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	IC	●	●	●	●	0009
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	PCM	●	●	●	●	0009 0023 0025
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	RCM	●	●	●	●	○
Ranger	2.3L	DURATEC-HE / I4	2009	TBM	●	●	●	●	○
Ranger	3.0L	I4 DSL Electronic	2005	4X4	●	●	●	●	○
Ranger	3.0L	I4 DSL Electronic	2005	ABS/TCS	●	●	●	●	○
Ranger	3.0L	I4 DSL Electronic	2005	GEM	●	●	●	●	○
Ranger	3.0L	I4 DSL Electronic	2005	IC	●	●	●	●	○
Ranger	3.0L	I4 DSL Electronic	2005	PCM	●	●	●	●	0009
Ranger	3.0L	I4 DSL Electronic	2005	RCM	●	●	●	●	○
Ranger	3.0L	I4 DSL Electronic	2005	TBM	●	●	●	●	○
Ranger / Courier / Mazda B Series	4.0L	V6 SOHC	2003	ABS/TCS	●	●	●	●	0008
Ranger / Courier / Mazda B Series	4.0L	V6 SOHC	2003	ESOF	●	●	●	●	○
Ranger / Courier / Mazda B Series	4.0L	V6 SOHC	2003	PCM	●	●	●	●	0009 0023 0025
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TBM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2007	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2009	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	PCM	●	●	●	●	0009 0023 0025 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005	TPM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 - 2011	OCSM	●	●	●	○	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 - 2011	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 - 2011	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 - 2011	ABS	●	●	●	●	0008 0012
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 - 1997	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 - 1997	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 - 1997	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 - 1997	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 - 1997	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	1996 - 2003	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	Other	1996 - 2003	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	1996 - 2003	PCM	●	●	●	●	0023 0025 0009 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	Other	2001	PATS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 - 2003	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 - 2003	RAP	●	●	●	●	000A 000F
Ranger / Mazda B Series / Courier	2.3L	Other	2001 - 2003	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	ABS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	ACM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	BCMii	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	DDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	FCDIM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	HVAC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	IPC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	PAM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	PCM	●	●	●	●	0025
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	PDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	RCM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	SRM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TBM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TRM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.5L	Other	1999 - 2001	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.5L	Other	1999 - 2001	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.8L	Other	2001	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	PATS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	PCM	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.8L	Other	2001	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.8L	Other	2001	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2003	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2007	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2008	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2008	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033 0009

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	3.0L	Other	1996 - 1998	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1999 - 2008	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2000 - 2001	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	Other	2001 - 2008	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2004 - 2008	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	Other	2005	TPM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2007 - 2008	OCSM	●	●	●	○	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2007 - 2008	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2008	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	●	●	●	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	●	●	●	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	●	●	●	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	●	●	●	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TBM	●	●	●	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1995 - 2002	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	Other	1995 - 2002	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1995 - 2002	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033 0009
Ranger / Mazda B Series / Courier	4.0L	Other	1995 - 2002	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	Other	1996 - 1998	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1999 - 2001	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	4.0L	Other	1999 - 2002	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2001 - 2002	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003	RAP	●	●	●	●	000A 000F
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2007	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2009	ABS/TCS	●	●	●	●	0008

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2011	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2011	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2011	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 - 2011	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005	TPM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 - 2011	OCSM	●	●	●	○	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 - 2011	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 - 2011	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 - 2011	ABS	●	●	●	●	0008 0012
Ranger / Mazda B Series / Courier	Other	Other	2004	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004 - 2011	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	ABS	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	ACM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	BCMii	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	DDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	FCDIM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	HVAC	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	IPC	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	PAM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	PDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	SRM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TBM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TRM	●	●	●	●	○
S. A. Fiesta	1.6L	FFV	2002	ABS/TCS	●	●	●	●	0008
S. A. Fiesta	1.6L	FFV	2002	IC	●	●	●	●	○
S. A. Fiesta	1.6L	FFV	2002	PCM	●	●	●	●	0009 0025
S. A. Fiesta	1.6L	FFV	2002	RCM	●	●	●	●	○
S. A. Fiesta	1.6L	FFV	2002	RKE	●	●	●	●	000A
S. A. Fiesta	1.6L	Zetec Rocam	2006	ABS/TCS	●	●	●	●	0008
S. A. Fiesta	1.6L	Zetec Rocam	2006	IC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
S. A. Fiesta	1.6L	Zetec Rocam	2006	PCM	●	●	●	●	0009 0025
S. A. Fiesta	1.6L	Zetec Rocam	2006	RCM	●	●	●	●	○
S. A. Fiesta	1.6L	Zetec Rocam	2006	RKE	●	●	●	●	000A
Street Ka	1.6L	DURATEC 8V	2003	ABS/TCS	●	●	●	●	○
Street Ka	1.6L	DURATEC 8V	2003	CSM	●	●	●	●	○
Street Ka	1.6L	DURATEC 8V	2003	ECS	●	●	○	○	○
Street Ka	1.6L	DURATEC 8V	2003	GEM	●	●	●	●	○
Street Ka	1.6L	DURATEC 8V	2003	PCM	●	●	●	●	0009
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	PATS	●	●	●	●	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	ABS	●	●	●	●	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	ABS/TCS	●	●	●	●	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	CSM	●	●	●	●	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	PCM	●	●	●	●	0023 0025
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1999	AFCM	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	ABS	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	ACM	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	GEM / SJB	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	IC	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	OCSM	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	PAM	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	PCM	●	●	●	●	0025 0023
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	RCM	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	SRM	●	●	●	○	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	VSM	●	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2012	APIM	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	ABS/TCS	●	●	●	●	0008
Transit Connect	2.0L	DURATORQ DI	2001	CSM	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	EPB	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	FFH	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	FIP	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	HEC	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	PAM	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	PATS	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	PCM	●	●	●	●	0009
Transit Connect	2.0L	DURATORQ DI	2001	RASM	●	●	●	●	○
Transit Connect	2.0L	DURATORQ DI	2001	RCM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Transit Connect	2.0L	DURATORQ DI	2001	TCM	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FIP	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	●	○	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PAM	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PCM	●	●	●	●	0092
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RASM	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RCM	●	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	TCM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	●	0090 0092 0098 00A6 00A7 00A8 00A9 00B0 00B1 00B5 00B6 00C0
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	ABS	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	ABS/TCS	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	ACM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	BCMii	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	CSM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	FFH	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	IPC	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	PAM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	PCM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	RCM	●	●	●	●	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage	2006	SRM	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●	●	○
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Transit Connect	2. 3L	DOHC SFI (16V)	2001	ABS/TCS	●	●	●	●	0008
Transit Connect	2. 3L	DOHC SFI (16V)	2001	CSM	●	●	●	●	○
Transit Connect	2. 3L	DOHC SFI (16V)	2001	HEC	●	●	●	●	○
Transit Connect	2. 3L	DOHC SFI (16V)	2001	PAM	●	●	●	●	○
Transit Connect	2. 3L	DOHC SFI (16V)	2001	PATS	●	●	●	●	○
Transit Connect	2. 3L	DOHC SFI (16V)	2001	PCM	●	●	●	●	0009 0025
Transit Connect	2. 3L	DOHC SFI (16V)	2001	RASM	●	●	●	●	○
Transit Connect	2. 3L	DOHC SFI (16V)	2001	RCM	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	ABS	●	●	●	●	0053 00DD 00E3 00E4
Transit Connect	2. 3L	DURATEC-HE / I4	2006	ABS/TCS	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	ACM	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	BCMii	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	CSM	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	FFH	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	IPC	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	PAM	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	PCM	●	●	●	●	0025
Transit Connect	2. 3L	DURATEC-HE / I4	2006	RCM	●	●	●	●	○
Transit Connect	2. 3L	DURATEC-HE / I4	2006	SRM	●	●	●	●	○
Transit Connect	2. 4L	DURATORQ DI	2000	ABS/TCS	●	●	●	●	0008
Transit Connect	2. 4L	DURATORQ DI	2000	CSM	●	●	●	●	○
Transit Connect	2. 4L	DURATORQ DI	2000	EPB	●	●	●	●	○
Transit Connect	2. 4L	DURATORQ DI	2000	FFH	●	●	●	●	○
Transit Connect	2. 4L	DURATORQ DI	2000	FIP	●	●	●	●	○
Transit Connect	2. 4L	DURATORQ DI	2000	HEC	●	●	●	●	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Transit Connect	2.4L	DURATORQ DI	2000	PAM	●	●	●	●	○
Transit Connect	2.4L	DURATORQ DI	2000	PATS	●	●	●	●	○
Transit Connect	2.4L	DURATORQ DI	2000	PCM	●	●	●	●	0009
Transit Connect	2.4L	DURATORQ DI	2000	RASM	●	●	●	●	○
Transit Connect	2.4L	DURATORQ DI	2000	RCM	●	●	●	●	○
Transit Connect	2.4L	DURATORQ DI	2000	TCM	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000	HEC	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000	ICU	○	○	●	○	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	ABS/TCS	●	●	●	●	0008
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	CSM	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	FFH	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	PAM	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	PCM	●	●	●	●	0009 0092 0090 0098 00A6 00A7 00A8 00A9 00B0 00B1 00B5 00B6 00C0 00C1 00C2 00C4
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	RCM	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●	●	0053 00DD 00E3 00E4
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	TBM	●	●	●	●	○
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	ABS	●	●	●	●	○
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	ABS/TCS	●	●	●	●	○
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	CSM	●	●	●	●	○
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	PCM	●	●	●	●	0025
Transit Connect	28kWh	Battery Electric Vehicle	2011	ABS	●	●	●	●	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	ACCM#2	●	●	●	●	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	ACM	●	●	●	●	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	GEM / SJB	●	●	●	●	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	IC	●	●	●	●	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	OCSM	●	●	●	●	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	PAM	●	●	●	●	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	PSCM	●	●	●	○	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	RCM	●	●	●	○	○

MaxiDas_FordEU_V6.00 Function List

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Transit Connect	28kWh	Battery Electric Vehicle	2011	SRM	●	●	●	○	○
Transit Connect	28kWh	Battery Electric Vehicle	2011	VSM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	●	0090 0092 0098 00A6 00A7 00A8 00A9 00B0 00B1 00B5 00B6 00C0
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●	●	0053 00DD 00E3 00E4
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●	●	○
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●	●	○
Windstar	3. 0L	V6 OHV	1995 - 1998	GEM	●	●	●	●	○
Windstar	3. 0L	V6 OHV	1995 - 1999	ABS/TCS	●	●	●	●	0008
Windstar	3. 0L	V6 OHV	1995 - 1999	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033
Windstar	3. 0L	V6 OHV	1996 - 1998	IAB	●	●	●	●	○
Windstar	3. 0L	V6 OHV	1996 - 1998	PATS	●	●	●	●	○
Windstar	3. 0L	V6 OHV	1998	RAP	●	●	●	●	000A
Windstar	3. 0L	V6 OHV	1999	DDM	●	●	●	●	000A
Windstar	3. 0L	V6 OHV	1999	FEM	●	●	●	●	○
Windstar	3. 0L	V6 OHV	1999	IC	●	●	●	●	0009

MaxiDas_FordEU_V6.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Windstar	3.0L	V6 OHV	1999	MC	●	●	●	●	○
Windstar	3.0L	V6 OHV	1999	NGSC	●	●	●	●	○
Windstar	3.0L	V6 OHV	1999	PAM	●	●	●	●	○
Windstar	3.0L	V6 OHV	1999	RCM	●	●	●	●	○
Windstar	3.0L	V6 OHV	1999	REM	●	●	●	●	○
Windstar	3.8L	V6 OHV	1995 - 1998	GEM	●	●	●	●	○
Windstar	3.8L	V6 OHV	1995 - 2003	ABS/TCS	●	●	●	●	0008 0005 0012
Windstar	3.8L	V6 OHV	1995 - 2003	PCM	●	●	●	●	0023 0025 0010 0028 0031 0033 0009
Windstar	3.8L	V6 OHV	1996 - 1998	IAB	●	●	●	●	○
Windstar	3.8L	V6 OHV	1996 - 1998	PATS	●	●	●	●	○
Windstar	3.8L	V6 OHV	1998	RAP	●	●	●	●	000A
Windstar	3.8L	V6 OHV	1999 - 2003	DDM	●	●	●	●	000A 0005
Windstar	3.8L	V6 OHV	1999 - 2003	FEM	●	●	●	●	0005
Windstar	3.8L	V6 OHV	1999 - 2003	IC	●	●	●	●	0009
Windstar	3.8L	V6 OHV	1999 - 2003	LPSDM	●	●	●	●	○
Windstar	3.8L	V6 OHV	1999 - 2003	MC	●	●	●	●	○
Windstar	3.8L	V6 OHV	1999 - 2003	NGSC	●	●	●	●	○
Windstar	3.8L	V6 OHV	1999 - 2003	PAM	●	●	●	●	○
Windstar	3.8L	V6 OHV	1999 - 2003	RCM	●	●	●	●	000C
Windstar	3.8L	V6 OHV	1999 - 2003	REM	●	●	●	●	000F
Windstar	3.8L	V6 OHV	1999 - 2003	RPSDM	●	●	●	●	○
Windstar	3.8L	V6 OHV	2000 - 2003	DSM	●	●	●	●	○

Specil Function

index	Specil Function Name
0005	Programmable Module Installation
0006	Module Reprogramming
0007	Programmable Parameters
0008	ABS Service Bleed
0009	PATS Functions
000A	Remote Keyless Entry
000B	G Sensor Calibration
000C	Passenger System Reset
000D	Neutral Position Setting
000E	Ride Height Calibration
000F	Factory Keyless Entry Code
0010	Stop Use of Transmission Adaptive
0011	Power Seat Calibration
0012	IVD Initialization Sequence
0013	Pneumatic Test
0014	Accurate Trim Test
0015	Passenger Zero Seat Weight Test
0016	Microphone Test
0017	Audio Speaker Walkaround Test
0018	Infotainment Display Test
0019	Tones Test
001A	TPMS Functions
001B	Zero Speed Test
001C	Rear Tones Test
001D	Monotones Test
001E	Sensor Initialization
001F	EPB calibration.
0020	EATC Operation Check
0021	Rain Sensor Reset
0022	LPSDM and RPSDM Service Function
0023	Power Balance
0024	EVAP Test
0025	Reset PCM KAM
0026	OBDII Modes
0027	Clear Transmission Adaptive Learning
0028	Clear Transmission Adaptive Tables
0029	Configure All Three Sensors Together.
002A	Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.
002B	Configure the lateral acceleration sensor.
002C	Configure the pressure sensor.
002D	FFH SelfTest and Prefill Utility
002E	FFH Start Heater Utility
002F	FFH Unlock Utility
0030	Auxiliary vehicle ID reset
0031	Halt Transmission Adaptive Learning
0032	Headlamp Alignment
0033	Resume Transmission Adaptive Learning
0034	Resume Transmission Adaptive Tables

Specil Function

index	Specil Function Name
0035	Keyfob Training
0036	Transmission
0037	Transmission Learning
0038	Transmission Solenoid Body IDN
0039	VSM Service Functions
003A	A/C Test
003B	ACM
003C	ACM Security Bypass Test
003D	Air/Fuel Learning
003E	AM Antenna Reception Sensitivity Test
003F	ASM Service Functions
0040	audio configuration
0041	Auto Leveling Sensor Re-zero Procedure
0042	Tire pressure monitoring system
0043	BSM Radar Test
0044	Button Test
0045	CAN Bus Fault Test
0046	CCM Calibration
0047	Clear EGR Adaptive Tables
0048	Clear Fuel Injector & HP Pump Adaptive Tables
0050	Clearing of Learning Value
0051	Component/Parameter Reset
0053	Configure the steering angle sensor.
0054	Configure the yaw rate sensor.
0055	Data Reset
0056	DPF
0057	DPF Component Parameter
0058	DPF Manual Regeneration
0059	DPF Parameter Reset
005A	Electronic Throttle Control
005B	EPS Steering Angle Calibration
005C	ETB/EGR Initialization
005D	FACM
005E	FFH Operation Check
005F	Gauge Test
0060	ICCM Aiming Adjustment
0061	Illumination Test
0062	Input and Data Test
0063	Interior Scan Test
0064	Keyless Entry Keypad Code Reset
0065	Learning
0066	Misfire Check
0067	Misfire Monitor Neutral Profile Correction
0068	Module Identification
0069	Multifunction Output Test
006A	Network Test
006B	New FACM
006C	Parking Aid Switch Test
006D	Passenger Seat Weight Sensor ReZero

Specil Function

index	Specil Function Name
006E	Rebalance
006F	Reset the Knock Sensor Learned Values
0070	Reset Transmission Tables
0071	Resetting adaptive values
0072	RVM Aiming
0074	Service Routine
0075	Special Ignition ON
0076	Steering angle sensor calibration
0077	Supplemental Heater Test
0080	Mode 1 Powertrain Data
0081	Mode 6 On-Board Test Results
0082	Mode 8 - On-Board device control
0083	Mode 9 - Vehicle Information
0084	OBD Drive Cycle
0085	Service Functions
0090	Diesel Particulate Filter Static Regeneration
0091	DPF Regeneration Suspension
0092	Fuel Injector Correction Factors
0093	IQA
0094	Refill the FAT.
0095	Relearn Vehicle Data
0096	Reset Charge Air Cooler Bypass Valve Position Offset.
0097	Reset the Cooling Fan Motor Learned Values
0098	Reset the Diesel Particulate Filter Learned Values
0099	Reset the Exhaust Gas Recirculation Valve Learned Values
009A	Reset the Intake Air Throttle Valve Learned Values
009B	Reset / Clear Specified Function
009C	SCR Dosing Measurement Test
009D	SCR Parameter Reset
009E	SCR System Emptying
009F	SCR System Refill Activation
00A0	SCR Visual Leak Check
00A1	System Prime
00A2	WIF Reset
00A3	DPF Reset
00A4	Enter the Fuel Injector Default Count Value
00A5	Clutch Switch Learn
00A6	Engine Oil Quality History
00A7	Fuel Injection Pump Learn
00A8	Fuel Injector Pilot Correction Learn
00A9	Fuel System Leak Test
00AA	Initialize the Exhaust Gas Related Component.
00AB	Reset Differential Pressure Sensor Learned Values
00AC	Reset KAM
00AD	Reset MAF Sensor Drift.
00AE	Reset MAF Sensor Offset.
00AF	Reset the air conditioning compressor learned values.

Specil Function

index	Specil Function Name
00B0	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values
00B1	Reset the Exhaust Gas Temperature Value
00B2	Reset the Fuel Injection Pump Learned Values
00B3	Reset the Fuel Injector Learned Values
00B4	Reset the Fuel Metering Valve Learned Values
00B5	Reset the Fuel Pressure Relief Valve Open Count Learned Value
00B6	Reset the Fuel Pressure Relief Valve Open Duration Learned Value
00B7	Reset the Fuel Rail Pressure Sensor Learned Values
00B8	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values
00B9	Reset the Mass Air Flow Sensor Learned Values
00BA	Reset the Neutral Gear Position Learned Value
00BB	Reset the oil change indicator.
00BC	Reset the Powertrain Control Module Learned Values
00BD	Reset the Turbocharger Learned Values.
00BE	Reset the Turbocharger Variable Vane Actuator Learned Values
00BF	Reset the Turbocharger Variable Vane Position Sensor Learned Values
00C0	Reset the Vehicle Speed Limit
00C1	Reset the water in fuel Warning Indicator.
00C2	rpm Controller
00C3	Stop-Start Activation
00C4	Speed Limiting
00C5	TR Sensor Test
00C6	Transmission Fluid Level Test
00C7	Automatic Transmission PRNDL Display Test
00C8	BSI Solenoid Test
00C9	Automatic Transmission Park Switch Test
00CA	ABS reset and configuration.
00CB	PDC Reset
00CC	Steering Wheel Position Sensor Calibration
00CD	Preliminary Checks
00CE	Reset TCM KAM
00CF	Fuel System Prime
00D0	Remote Start
00D1	TBM SIM RAV_ID
00D2	Reset TBM Password
00D3	TBM Transit Mode
00D4	CEI Lock Configuration
00D5	BMS Reset
00D6	Navigation
00D7	Calibrate Steering Angle Sensor
00D8	Configure the steering column assembly
00D9	Configure the longitudinal acceleration sensor
00DA	Configure the intermediate shaft

Specil Function

index	Specil Function Name
00DB	Module Initialization
00DC	Pull Drift Compensation
00DD	Calibrate Longitudinal Acceleration Sensor
00DE	Inhibit longitudinal accelerometer monitoring
00DF	Pull Drift Compensation enable/disable
00E0	Straight Ahead Adaption Angle Reset
00E1	Steering Rack Limiter Configuration
00E2	Pressure Sensor Calibration
00E3	Reset Pressure Sensor Offset
00E4	Enable/Disable hill launch assist
00E5	Camera Alignment
00E6	Shift fork system learn.
00E7	Reset the High Pressure Fuel System Learned Values
00E8	BleedMASTER
00E9	FCDIM_Keycode_reset
00EA	EPB
0101	Audio
0102	Battery saver
0103	Body Type
0104	Courtesy Lamp
0105	Door Trigger Disable Mode
0106	Body and Fuel Type
0107	Hazard Warning
0108	Horn Warning
0109	Master Door Trigger Disable Mode
010A	Panic Alarm
010B	Police Mode
010C	Traction control system
010D	Autolamp Off Setting
010E	Autolamp On Setting
010F	Police Speedometer Offset
0110	Cabin Temperature Sensor Calibration Factor
0111	Taxi Mode
0112	Low Coolant Warning
0113	Parking Brake Warning
0114	Headlamp Delay Door Open
0115	Headlamp Delay Ignition Off
0116	Headlamp Delay Remote Lock Pressed
0117	Dynamic Stability Control
0118	Hill Descent Control LED
0119	Brake System Configuration
011A	BPM fitted
011B	Camera fitted
011C	Audio Interface Module
011D	Sonar fitted
011E	Navigation System
011F	Parking Aid Module
0120	Odometer Write
0121	Subwoofer

Specil Function

index	Specil Function Name
0122	Driver Beltminder Status
0123	Alarm
0124	Audio Configure