

## MaxiDas\_Nissan\_V4.30 Function List

## NOTES:

• This function is supported.

\* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

As for special function please refer to the special function table.

	DOU I C	Read codes	Erase Codes	Freeze Data	Live Data	Active Test	WORK SUPPORT	Other
Unit	ECU Info.							
ABS	•	•	•	*	•	•	*	
TCS	•	•	•	•	•	•	•	
IVMS	•	•	•	•	•	•	•	
CVT	•	•	•	0	•	0	•	CAN DIAG SUPPORT MNTR
ASCD	0	•	0	0	•	0	0	
AIR PRESSURE MONITOR	*	•	0	0	•	*	•	
Active SUS	•	•	•	•	•	•	•	
ACT D/SUS	•	•	•	•	•	•		
4WD	•	•	•	*	•	*	•	
SMART ENTRANCE	0	•	•	*	•	*	•	CAN DIAG SUPPORT MNTR
ICC	•	•	•	*	•	•	•	CAN DIAG SUPPORT MNTR
NATS	0	•	•	0	0	0	0	C/U INITIALIZATION SELF FOUNCTION CHECK
Engine	•	•	•	*	•	•	•	
A/T	•	•	•	*	•	*	•	
S/BLIND CAMERA	•	0	0	0	•	0	•	
REARVIEW CAMERA	•	0	0	0	•	0	•	
MOTOR ASSIST	0	•	•	0	•	0	•	
HEAD LAMP LEVELIZER	•	•	•	0	•	•	•	
DIFF LOCK	0	•	•	0	•	0	0	CAN DIAG SUPPORT MNTR
ALL MODE AWD/4WD	0	•	•	0	•	0	0	CAN DIAG SUPPORT MNTR
IPDM	0	•	•	0	•	•		
AIR LEVELIZER	•	•	•	0	•	•	•	
SONAR	•	•	•	0	•	•		
AT	•	•	•	0	•	•	•	CALIBRATION DATA
Airbag	0	•	•	0	0	0	0	READ CODES [PAST] TROUBLE DIAG RECORD ECU DISCRIMINATED NO
PRECRASH SEATBELT	•	•	•	0	•	0	0	CAN DIAG SUPPORT MNTR
MULTI AV	*	•	•	0	•	0	0	
METER AC AMP	•	•	•	0	•	0	0	CAN DIAG SUPPORT MNTR



## MaxiDas\_Nissan\_V4.30 Function List

## NOTES:

• This function is supported.

imes This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

lacktriangle This function is the new feature in this version.

As for special function please refer to the special function table.

0	•	•	0	•	0	0	CAN DIAG SUPPORT MNTR
0	•	•	0	•	•	0	CAN DIAG SUPPORT MNTR
•	•	•	0	•	•	•	CAN DIAG SUPPORT MNTR
•	•	•	0	•	*		CAN DIAG SUPPORT MNTR
•	•	•	0	•	0	•	CAN DIAG SUPPORT MNTR
•	•	•	*	•	•		CAN DIAG SUPPORT MNTR
•	•	•	0	•	•	•	CAN DIAG SUPPORT MNTR
*	•	•	0	•	•	•	CAN DIAG SUPPORT MNTR
•	•	•	0	•	•		CAN DIAG SUPPORT MNTR
•	•	•	0	•	•	•	CAN DIAG SUPPORT MNTR
•	•	•	0	•	•	•	
•	•	•	0	•	•		
•	•	•	0	•	•		CAN DIAG SUPPORT MNTR
0	•	•	0	•	0	0	
0	0	0	0	0	•	0	
•	0	0	0	•	0	•	
•	•	•	0	•	•	•	

-Autel	Special_Function					
index	Specil Function Name					
0001	work support					
0002	CAN DIAG SUPPORT MNTR					
0003	ECU DISCRIMINATED NO"					
0004	C/U INITIALIZATION					
0005	READ CODES [PAST]					
0006	SELF FOUNCTION CHECK"					
0007	CALIBRATION DATA					
0008	TROUBLE DIAG RECORD					