

NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60 (11-)	2011	PBM		• III 0.	•	•	TTAME	Data	O	249	
V60	2011	PBM		•	•	•	•	•	0	249	
S80 (07-)	2011	PBM		•	•	•	•	•	0	249	
V70 (08-)	2011	PBM		•	•	•	•	•	0	249	
XC70 (08-)	2011	PBM		•	•	•	•	•	0	249	
XC60	2011	PBM		•	•	•	•	•	0	249	
S80 (07-)	2012	PBM		•	•	•	•	•	0	249	
S60 (11-)	2012	PBM		•	•	•	•	•	0	249	
V70 (08-)	2012	PBM		•	•	•	•	•	0	249	
XC70 (08-)	2012	PBM		•	•	•	•	•	0	249	
V60	2012	PBM		•	•	•	•	•	0	249	
XC60	2012	PBM		•	•	•	•	•	0	249	
S60 (11-)	2012A	PBM		•	•	•	•	•	0	249	
V70 (08-)	2010	ECM	B4204S3	•	•	•	•	•	•	229	
V70 (08-)	2010	ECM	B4204S4	•	•	•	•	•	•	229	
V70 (08-)	2010	ECM	B4204S4\MPS6	•	•	•	•	•	•	229	
V70 (08-)	2010	ECM	B4204S7	•	•	•	•	•	•	229	
S80 (07-)	2010	ECM	B4204S4	•	•	•	•	•	•	229	
S80 (07-)	2010	ECM	B4204S3	•	•	•	•	•	•	229	
S80 (07-)	2010	ECM	B4204S4\MPS6	•	•	•	•	•	•	229	
S80 (07-)	2011	ECM	B4204S3	•	•	•	•	•	•	229	
S80 (07-)	2011	ECM	B4204S4	•	•	•	•	•	•	229	
S80 (07-)	2011	ECM	B4204S4\MPS6	•	•	•	•	•	•	229	
V70 (08-)	2011	ECM	B4204S3	•	•	•	•	•	•	229	
V70 (08-)	2011	ECM	B4204S4	•	•	•	•	•	•	229	
V70 (08-)	2011	ECM	B4204S4\MPS6	•	•	•	•	•	•	229	
XC70 (08-)	2010	DIM		•	•	•	•	•	0	161	
V70 (08-)	2010	DIM		•	•	•	•	•	0	161	
XC60	2010	DIM		•	•	•	•	•	0	161	
S80L	2010	DIM		•	•	•	•	•	0	161	
S40 (04-)	2010	DIM		•	•	•	•	•	•	161	
S40 (04-)	2010	CEM		•	•	•	•	•	•	161	
S40 (04-)	2010	CEM-HS		•	•	•	•	•	•	161	
V50	2010	DIM		•	•	•	•	•	•	161	
V50	2010	CEM		•	•	•	•	•	•	161	
V50	2010	CEM-HS		•	•	•	•	•	•	161	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2010	DIM		•	•	•	•	•	•	161	
C70 (06-)	2010	CEM		•	•	•	•	•	•	161	
C70 (06-)	2010	CEM-HS		•	•	•	•	•	•	161	
C30	2010	DIM		•	•	•	•	•	•	161	
C30	2010	CEM		•	•	•	•	•	•	161	
C30	2010	CEM-HS		•	•	•	•	•	•	161	
S60 (11-)	2011	DIM		•	•	•	•	•	0	161	
V60	2011	DIM		•	•	•	•	•	0	161	
C30	2011	DIM		•	•	•	•	•	•	161	
C30	2011	CEM-HS		•	•	•	•	•	•	161	
C30	2011	CEM		•	•	•	•	•	•	161	
V50	2011	DIM		•	•	•	•	•	•	161	
V50	2011	CEM-HS		•	•	•	•	•	•	161	
V50	2011	CEM		•	•	•	•	•	•	161	
C70 (06-)	2011	DIM		•	•	•	•	•	•	161	
C70 (06-)	2011	CEM-HS		•	•	•	•	•	•	161	
C70 (06-)	2011	CEM		•	•	•	•	•	•	161	
S40 (04-)	2011	DIM		•	•	•	•	•	•	161	
S40 (04-)	2011	CEM-HS		•	•	•	•	•	•	161	
S40 (04-)	2011	CEM		•	•	•	•	•	•	161	
C30	2011	CEM	D5204T	•	•	•	•	•	•	161	
C30	2011	CEM-HS	D5204T	•	•	•	•	•	•	161	
C70 (06-)	2011	CEM	D5204T	•	•	•	•	•	•	161	
C70 (06-)	2011	CEM-HS	D5204T	•	•	•	•	•	•	161	
S40 (04-)	2011	CEM	D5204T	•	•	•	•	•	•	161	
S40 (04-)	2011	CEM-HS	D5204T	•	•	•	•	•	•	161	
V50	2011	CEM	D5204T	•	•	•	•	•	•	161	
V50	2011	CEM-HS	D5204T	•	•	•	•	•	•	161	
S80 (07-)	2011	DIM		•	•	•	•	•	0	161	
V70 (08-)	2011	DIM		•	•	•	•	•	0	161	
S80L	2011	DIM		•	•	•	•	•	0	161	
XC70 (08-)	2011	DIM		•	•	•	•	•	0	161	
C70 (06-)	2011A	DIM		•	•	•	•	•	•	161	
C70 (06-)	2011A	CEM		•	•	•	•	•	•	161	
C70 (06-)	2011A	CEM-HS		•	•	•	•	•	•	161	
C30	2011A	DIM		•	•	•	•	•	•	161	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2011A	CEM		• • • • • • • • • • • • • • • • • • •	•	•	11 a.m.c	•	1050	161	
C30	2011A	CEM-HS		•	•	•	•	•	•	161	
C70 (06-)	2011	CEM	D5204T5	•	•	•	•	•	•	161	
C70 (06-)	2011	CEM-HS	D5204T5	•	•	•	•	•	•	161	
V50	2011	CEM	D4162T	•	•	•	•	•	•	161	
V50	2011	CEM-HS	D4162T	•	•	•	•	•	•	161	
S40 (04-)	2011	CEM	D4162T	•	•	•	•	•	•	161	
S40 (04-)	2011	CEM-HS	D4162T	•	•	•	•	•	•	161	
C30	2011	CEM	D4162T	•	•	•	•	•	•	161	
C30	2011	CEM-HS	D4162T	•	•	•	•	•	•	161	
XC60	2011	DIM		•	•	•	•	•	0	161	
C30	2011	CEM	D5204T5	•	•	•	•	•	•	161	
C30	2011	CEM-HS	D5204T5	•	•	•	•	•	•	161	
S40 (04-)	2011	CEM	D5204T5	•	•	•	•	•	•	161	
S40 (04-)	2011	CEM-HS	D5204T5	•	•	•	•	•	•	161	
V50	2011	CEM	D5204T5	•	•	•	•	•	•	161	
V50	2011	CEM-HS	D5204T5	•	•	•	•	•	•	161	
S80 (07-)	2012	DIM		•	•	•	•	•	0	161	
S60 (11-)	2012	DIM		•	•	•	•	•	0	161	
V70 (08-)	2012	DIM		•	•	•	•	•	0	161	
XC70 (08-)	2012	DIM		•	•	•	•	•	0	161	
S80L	2012	DIM		•	•	•	•	•	0	161	
V60	2012	DIM		•	•	•	•	•	0	161	
XC60	2012	DIM		•	•	•	•	•	0	161	
S40 (04-)	2012	DIM		•	•	•	•	•	•	161	
S40 (04-)	2012	CEM		•	•	•	•	•	•	161	
S40 (04-)	2012	CEM-HS		•	•	•	•	•	•	161	
V50	2012	DIM		•	•	•	•	•	•	161	
V50	2012	CEM		•	•	•	•	•	•	161	
V50	2012	CEM-HS		•	•	•	•	•	•	161	
C30	2012	DIM		•	•	•	•	•	•	161	
C30	2012	CEM		•	•	•	•	•	•	161	
C30	2012	CEM-HS		•	•	•	•	•	•	161	
C70 (06-)	2012	DIM		•	•	•	•	•	•	161	
C70 (06-)	2012	CEM		•	•	•	•	•	•	161	
C70 (06-)	2012	CEM-HS		•	•	•	•	•	•	161	



NOTES:

● This function is supported. ※ This

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2012	CEM	D4162T	•	•	•	•	•	•	161	
S40 (04-)	2012	CEM-HS	D4162T	•	•	•	•	•	•	161	
S40 (04-)	2012	CEM	D5204T	•	•	•	•	•	•	161	
S40 (04-)	2012	CEM-HS	D5204T	•	•	•	•	•	•	161	
S40 (04-)	2012	CEM	D5204T5	•	•	•	•	•	•	161	
S40 (04-)	2012	CEM-HS	D5204T5	•	•	•	•	•	•	161	
V50	2012	CEM	D5204T	•	•	•	•	•	•	161	
V50	2012	CEM-HS	D5204T	•	•	•	•	•	•	161	
V50	2012	CEM	D4162T	•	•	•	•	•	•	161	
V50	2012	CEM-HS	D4162T	•	•	•	•	•	•	161	
V50	2012	CEM	D5204T5	•	•	•	•	•	•	161	
V50	2012	CEM-HS	D5204T5	•	•	•	•	•	•	161	
C30	2012	CEM	D5204T5	•	•	•	•	•	•	161	
C30	2012	CEM-HS	D5204T5	•	•	•	•	•	•	161	
C30	2012	CEM	D4162T	•	•	•	•	•	•	161	
C30	2012	CEM-HS	D4162T	•	•	•	•	•	•	161	
C30	2012	CEM	D5204T	•	•	•	•	•	•	161	
C30	2012	CEM-HS	D5204T	•	•	•	•	•	•	161	
C70 (06-)	2012	CEM	D5204T5	•	•	•	•	•	•	161	
C70 (06-)	2012	CEM-HS	D5204T5	•	•	•	•	•	•	161	
C70 (06-)	2012	CEM	D5204T	•	•	•	•	•	•	161	
C70 (06-)	2012	CEM-HS	D5204T	•	•	•	•	•	•	161	
S60 (11-)	2012A	DIM		•	•	•	•	•	0	161	
C30 Electric	2011	DIM		•	•	•	•	•	•	161	
C30 Electric	2011	CEM-HS		•	•	•	•	•	•	161	
C30 Electric	2011	CEM		•	•	•	•	•	•	161	
C30 Electric	2012	DIM		•	•	•	•	•	•	161	
C30 Electric	2012	CEM-HS		•	•	•	•	•	•	161	
C30 Electric	2012	CEM		•	•	•	•	•	•	161	
C30	2011A	DIM		•	•	•	•	•	•	161	
C30	2011A	CEM		•	•	•	•	•	•	161	
C30	2011A	CEM-HS		•	•	•	•	•	•	161	
C70 (06-)	2011A	DIM		•	•	•	•	•	•	161	
C70 (06-)	2011A	CEM		•	•	•	•	•	•	161	
C70 (06-)	2011A	CEM-HS		•	•	•	•	•	•	161	
S80 (07-)	2011	TCM	TF-80SC	•	•	•	•	•	0	82250	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2011	TCM	B5254T8\TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2011	TCM	TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2011	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
V60	2011	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
V60	2011	TCM	TF-80SC	•	•	•	•	•	0	82250	
S40 (04-)	2011	TCM	D5204T\TF-80SC	•	•	•	•	•	0	82250	
V50	2011	TCM	D5204T\TF-80SC	•	•	•	•	•	0	82250	
C70 (06-)	2011	TCM	D5204T\TF-80SC	•	•	•	•	•	0	82250	
C30	2011	TCM	D5204T\TF-80SC	•	•	•	•	•	0	82250	
S80 (07-)	2011	TCM	B5254T11\TF-80SC	•	•	•	•	•	0	82250	
S80 (07-)	2011	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
S80L	2011	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
V70 (08-)	2011	TCM	TF-80SC	•	•	•	•	•	0	82250	
V70 (08-)	2011	TCM	B5254T11\TF-80SC	•	•	•	•	•	0	82250	
V70 (08-)	2011	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
V70 (08-)	2011	TCM	D5244T10\TF-80SC	•	•	•	•	•	0	82250	
V70 (08-)	2011	TCM	D5244T10\TF-80SC AWD	•	•	•	•	•	0	82250	
XC70 (08-)	2011	TCM	TF-80SC	•	•	•	•	•	0	82250	
XC70 (08-)	2011	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
XC70 (08-)	2011	TCM	D5244T10\TF-80SC AWD	•	•	•	•	•	0	82250	
XC70 (08-)	2011	TCM	D5244T16\TF-80SC AWD	•	•	•	•	•	0	82250	
C70 (06-)	2011	TCM	D5204T5\TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2011	TCM	B5254T5\TF-80SC	•	•	•	•	•	0	82250	
V60	2011	TCM	B5254T5\TF-80SC	•	•	•	•	•	0	82250	
S80 (07-)	2011	TCM	B5254T10\TF-80SC	•	•	•	•	•	0	82250	
V70 (08-)	2011	TCM	B5254T10\TF-80SC	•	•	•	•	•	0	82250	
XC60	2011	TCM	TF-80SC	•	•	•	•	•	0	82250	
XC60	2011	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
XC60	2011	TCM	D5244T10\TF-80SC AWD	•	•	•	•	•	0	82250	
XC60	2011	TCM	D5244T16\TF-80SC AWD	•	•	•	•	•	0	82250	
C30	2011	TCM	D5204T5\TF-80SC	•	•	•	•	•	0	82250	
S40 (04-)	2011	TCM	D5204T5\TF-80SC	•	•	•	•	•	0	82250	
V50	2011	TCM	D5204T5\TF-80SC	•	•	•	•	•	0	82250	
S40 (04-)	2012	TCM	D5204T\TF-80SC	•	•	•	•	•	0	82250	
S40 (04-)	2012	TCM	D5204T5\TF-80SC	•	•	•	•	•	0	82250	
V50	2012	TCM	D5204T\TF-80SC	•	•	•	•	•	0	82250	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU	Read DTC	Clear	Freeze	Live	Active	Special	Other
		· ·		Info.		DTC	Frame	Data	Test	Function	0 01101
V50	2012	TCM	D5204T5\TF-80SC	•	•	•	•	•	0	82250	
C30	2012	TCM	D5204T\TF-80SC	•	•	•	•	•	0	82250	
C30	2012	TCM	D5204T5\TF-80SC	•	•	•	•	•	0	82250	
C70 (06-)	2012	TCM	D5204T\TF-80SC	•	•	•	•	•	0	82250	
C70 (06-)	2012	TCM	D5204T5\TF-80SC	•	•	•	•	•	0	82250	
S80 (07-)	2012	TCM	TF-80SC		•	•	•	•	0	82250	
S80 (07-)	2012	TCM	B5254T8\TF-80SC	•	•	•	•	•	0	82250	
S80 (07-)	2012	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
S80L	2012	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
V70 (08-)	2012	TCM	TF-80SC	•	•	•	•	•	0	82250	
V70 (08-)	2012	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
XC70 (08-)	2012	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
XC70 (08-)	2012	TCM	TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2012	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
S60 (11-)	2012	TCM	TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2012	TCM	B5254T5\TF-80SC	•	•	•	•	•	0	82250	
V60	2012	TCM	TF-80SC	•	•	•	•	•	0	82250	
V60	2012	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
XC60	2012	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
XC60	2012	TCM	TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2012A	TCM	TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2012A	TCM	B5254T5\TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2012A	TCM	TF-80SC AWD	•	•	•	•	•	0	82250	
V70 (08-)	2012	TCM	B5254T10\TF-80SC	•	•	•	•	•	0	82250	
S80 (07-)	2012	TCM	B5254T10\TF-80SC	•	•	•	•	•	0	82250	
S60 (11-)	2012	TCM	D5204T3\TF-80SD	•	•	•	•	•	0	82250	
V60	2012	TCM	D5204T3\TF-80SD	•	•	•	•	•	0	82250	
S80 (07-)	2012	TCM	D5204T3\TF-80SD	•	•	•	•	•	0	82250	
V70 (08-)	2012	TCM	D5204T3\TF-80SD	•	•	•	•	•	0	82250	
S80L	2012	TCM	TF-80SC	•	•	•	•	•	0	82250	
S80 (07-)	2010	DIM		•	•	•	•	•	0	0	
S60 (11-)	2012A	CPM		•	•	•	•	•	•		
S60 (11-)	2012A	SUM		•	•	•	•	•	•		
S60 (11-)	2012A	PAM		•	•	•	•	•	0		
S60 (11-)	2012A	PSM		•	•	•	•	•	•		
S60 (11-)	2012A	AUU		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60 (11-)	2012A	PHM		- IIII 0.	•	•	•	•	0	T dilo 01011	
S60 (11-)	2012A	RDAR		•	•	•	•	0	0		
S60 (11-)	2012A	DABM		•	•	•	•	0	0		
S60 (11-)	2012A	HCM		•	•	•	•	•	0		
S60 (11-)	2012A	FLR		•	•	•	•	0	0		
S60 (11-)	2012A	CVM		•	•	•	•	0	0		
S60 (11-)	2012A	PSCM		•	•	•	•	•	0		
S60 (11-)	2012A	KVM		•	•	•	•	•	0		
S60 (11-)	2012A	IAM		•	•	•	•	•	0		
S60 (11-)	2012A	TRM		•	•	•	•	•	0		
S60 (11-)	2012A	SRS		•	•	•	•	•	0		
S60 (11-)	2012A	PDM		•	•	•	•	•	0		
S60 (11-)	2012A	CCM		•	•	•	•	•	0		
S60 (11-)	2012A	ICM		•	•	•	•	•	0		
S60 (11-)	2012A	SAS		•	•	•	•	•	0		
S60 (11-)	2012A	PAC		•	•	•	•	0	0		
S60 (11-)	2012A	AUD		•	•	•	•	0	0		
S60 (11-)	2012A	TVM		•	•	•	•	•	0		
S60 (11-)	2012A	FSM		•	•	•	•	•	0		
S60 (11-)	2012A	BCM		•	•	•	•	•	0		
S60 (11-)	2012A	CEM		•	•	•	•	•	0		
S60 (11-)	2012A	ECM	B5254T5	•	•	•	•	•	0		
S60 (11-)	2012A	ECM	B6304T4	•	•	•	•	•	0		
S60 (11-)	2012A	DEM	TF-80SC AWD	•	•	•	•	•	•		
S60 (11-)	2012A	DDM		•	•	•	•	•	0		
XC90	2012	GPS		•	•	•	•	•	0		
XC90	2012	PSM		•	•	•	•	•	•		
XC90	2012	SUB		0	0	0	0	0	0		
XC90	2012	DDM		•	•	•	•	•	•		
XC90	2012	PDM		•	•	•	•	•	•		
XC90	2012	AEM		•	•	•	•	•	•		
XC90	2012	AUD		•	•	•	•	0	0		
XC90	2012	PAC		•	0	0	0	0	0		
XC90	2012	AUU		•	•	•	•	•	0		
XC90	2012	DIM		•	•	•	•	•	•		
XC90	2012	IAM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2012	UEM		•	•	•	•	•	•		
XC90	2012	BPM		•	•	•	•	•	0		
XC90	2012	MMM		•	•	•	•	•	•		
XC90	2012	SRS		•	•	•	•	•	0		
XC90	2012	PHM		•	•	•	•	•	0		
XC90	2012	ICM		•	•	•	•	•	•		
XC90	2012	CCM		•	•	•	•	•	0		
XC90	2012	CPM		•	•	0	0	0	0		
XC90	2012	REM		•	•	•	•	•	•		
XC90	2012	RDAR		•	•	•	•	•	0		
XC90	2012	BCM	B6324S5	•	•	•	•	•	•		
XC90	2012	SAS	B6324S5	•	•	•	•	•	0		
XC90	2012	HCM	B6324S5	•	•	•	•	•	0		
XC90	2012	ECM	B6324S5	0	0	0	0	0	0		
XC90	2012	CEM	B6324S5	•	•	•	•	•	0		
XC90	2012	CEM-HS	B6324S5	0	0	0	0	0	0		
XC90	2012	CPM	B6324S5	0	0	0	0	0	0		
XC90	2012	TCM	B6324S5/TF-80SC AWD	0	0	0	0	0	0		
XC90	2012	DEM	B6324S5/TF-80SC AWD	•	•	•	•	•	0		
XC90	2012	TCM	B6324S5/TF-80SC	0	0	0	0	0	0		
XC90	2012	BCM	D5244T5	•	•	•	•	•	•		
XC90	2012	SAS	D5244T5	•	•	•	•	•	0		
XC90	2012	HCM	D5244T5	•	•	•	•	•	0		
XC90	2012	CEM	D5244T5	•	•	•	•	•	0		
XC90	2012	ECM	D5244T5	•	•	•	•	•	•		
XC90	2012	BCM	D5244T18	•	•	•	•	•	•		
XC90	2012	SAS	D5244T18	•	•	•	•	•	0		
XC90	2012	HCM	D5244T18	•	•	•	•	•	0		
XC90	2012	CEM	D5244T18	•	•	•	•	•	0		
XC90	2012	ECM	D5244T18	•	•	•	•	•	•		
XC90	2012	BCM	B5254T2	•	•	•	•	•	•		
XC90	2012	SAS	B5254T2	•	•	•	•	•	0		
XC90	2012	ECM	B5254T2	•	•	•	•	•	•		
XC90	2012	HCM	B5254T2	•	•	•	•	•	0		
XC90	2012	CEM	B5254T2	•	•	•	•	•	0		
XC90	2012	TCM	AW50/51 AWD	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2012	DEM	B5254T2/AW50/51 AWD	•	•	•	•	•	0		
XC90	2012	TCM	D5244T18/TF-80SC AWD	•	•	•	•	•	•		
XC90	2012	DEM	D5244T18/TF-80SC AWD	•	•	•	•	•	0		
XC90	2012	TCM	D5244T5/TF-80SC	•	•	•	•	•	•		
XC90	2012	BCM	D5244T4	•	•	•	•	•	•		
XC90	2012	SAS	D5244T4	•	•	•	•	•	0		
XC90	2012	HCM	D5244T4	•	•	•	•	•	0		
XC90	2012	ECM	D5244T4	•	•	•	•	•	•		
XC90	2012	CEM	D5244T4	•	•	•	•	•	0		
XC90	2012	TCM	D5244T4/TF-80SC AWD	•	•	•	•	•	•		
XC90	2012	DEM	D5244T4/TF-80SC AWD	•	•	•	•	•	0		
XC70 (08-)	2012	DDM		•	•	•	•	•	0		
XC70 (08-)	2012	CPM		•	•	•	•	•	•		
XC70 (08-)	2012	SUM		•	•	•	•	•	•		
XC70 (08-)	2012	PAM		•	•	•	•	•	0		
XC70 (08-)	2012	HLDF		•	•	•	•	•	0		
XC70 (08-)	2012	TRM		•	•	•	•	•	0		
XC70 (08-)	2012	SRS		•	•	•	•	•	0		
XC70 (08-)	2012	SUB		•	•	•	•	0	0		
XC70 (08-)	2012	BPM		•	•	•	•	•	0		
XC70 (08-)	2012	DABM		•	•	•	•	0	0		
XC70 (08-)	2012	KVM		•	•	•	•	•	0		
XC70 (08-)	2012	PBM		•	•	•	•	•	0		
XC70 (08-)	2012	FLR		•	•	•	•	0	0		
XC70 (08-)	2012	PSCM		•	•	•	•	•	0		
XC70 (08-)	2012	MMM		•	•	•	•	0	0		
XC70 (08-)	2012	PDM		•	•	•	•	•	0		
XC70 (08-)	2012	AUD		•	•	•	•	0	0		
XC70 (08-)	2012	POT		•	•	•	•	•	0		
XC70 (08-)	2012	PHM		•	•	•	•	•	0		
XC70 (08-)	2012	SAS		•	•	•	•	•	0		
XC70 (08-)	2012	FSM		•	•	•	•	•	0		
XC70 (08-)	2012	TVM		•	•	•	•	•	0		
XC70 (08-)	2012	CCM		•	•	•	•	•	0		
XC70 (08-)	2012	CVM		•	•	•	•	0	0		
XC70 (08-)	2012	PAC		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2012	PSM		•	•	•	•	•	0		
XC70 (08-)	2012	RSE		•	•	•	•	•	0		
XC70 (08-)	2012	CEM		•	•	•	•	•	0		
XC70 (08-)	2012	IAM		•	•	•	•	•	0		
XC70 (08-)	2012	ICM		•	•	•	•	•	0		
XC70 (08-)	2012	BCM		•	•	•	•	•	0		
XC70 (08-)	2012	RDAR		•	•	•	•	0	0		
XC70 (08-)	2012	ECM	B6324S5	•	•	•	•	•	0		
XC70 (08-)	2012	ECM	B6304T4	•	•	•	•	•	0		
XC70 (08-)	2012	ECM	B6324S4	•	•	•	•	•	0		
XC70 (08-)	2012	ECM	D5244T15	•	•	•	•	•	0		
XC70 (08-)	2012	ECM	D5244T11	•	•	•	•	•	0		
XC70 (08-)	2012	ECM	D5204T3	•	•	•	•	•	0		
XC70 (08-)	2012	ECM	D5244T17	•	•	•	•	•	0		
XC70 (08-)	2012	DEM	TF-80SC AWD	•	•	•	•	•	•		
XC70 (08-)	2012	TCM	TF-80SC AWD	•	•	•	•	•	0		
XC70 (08-)	2012	DEM	M66 AWD	•	•	•	•	•	•		
XC70 (08-)	2012	TCM	TF-80SC	•	•	•	•	•	0		
XC60	2012	DDM		•	•	•	•	•	0		
XC60	2012	CPM		•	•	•	•	•	•		
XC60	2012	SUM		•	•	•	•	•	•		
XC60	2012	PAM		•	•	•	•	•	0		
XC60	2012	TRM		•	•	•	•	•	0		
XC60	2012	SUB		•	•	•	•	0	0		
XC60	2012	HLDF		•	•	•	•	•	0		
XC60	2012	DABM		•	•	•	•	0	0		
XC60	2012	SRS		•	•	•	•	•	0		
XC60	2012	KVM		•	•	•	•	•	0		
XC60	2012	PAC		•	•	•	•	0	0		
XC60	2012	FLR		•	•	•	•	0	0		
XC60	2012	PSCM		•	•	•	•	•	0		
XC60	2012	MMM		•	•	•	•	0	0		
XC60	2012	PDM		•	•	•	•	•	0		
XC60	2012	AUD		•	•	•	•	0	0		
XC60	2012	POT		•	•	•	•	•	0		
XC60	2012	PHM		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC60	2012	SAS		•	•	•	•	•	0		
XC60	2012	FSM		•	•	•	•	•	0		
XC60	2012	TVM		•	•	•	•	•	0		
XC60	2012	CCM		•	•	•	•	•	0		
XC60	2012	CVM		•	•	•	•	0	0		
XC60	2012	PSM		•	•	•	•	•	0		
XC60	2012	RSE		•	•	•	•	•	0		
XC60	2012	CEM		•	•	•	•	•	0		
XC60	2012	IAM		•	•	•	•	•	0		
XC60	2012	ICM		•	•	•	•	•	0		
XC60	2012	BCM		•	•	•	•	•	0		
XC60	2012	RDAR		•	•	•	•	0	0		
XC60	2012	ECM	B6324S5	•	•	•	•	•	0		
XC60	2012	ECM	B6304T4	•	•	•	•	•	0		
XC60	2012	ECM	B6324S4	•	•	•	•	•	0		
XC60	2012	ECM	D5204T3	•	•	•	•	•	0		
XC60	2012	ECM	B4204T7	•	•	•	•	•	0		
XC60	2012	ECM	D5244T15	•	•	•	•	•	0		
XC60	2012	ECM	D5244T11	•	•	•	•	•	0		
XC60	2012	ECM	D5244T17	•	•	•	•	•	0		
XC60	2012	TCM	MPS6	•	•	•	•	•	0		
XC60	2012	DEM	TF-80SC AWD	•	•	•	•	•	•		
XC60	2012	DEM	M66 AWD	•	•	•	•	•	•		
XC60	2012	ECM	B4204T6	•	•	•	•	•	0		
V70 (08-)	2012	DDM		•	•	•	•	•	0		
V70 (08-)	2012	CPM		•	•	•	•	•	•		
V70 (08-)	2012	SUM		•	•	•	•	•	•		
V70 (08-)	2012	PAM		•	•	•	•	•	0		
V70 (08-)	2012	HLDF		•	•	•	•	•	0		
V70 (08-)	2012	TRM		•	•	•	•	•	0		
V70 (08-)	2012	SRS		•	•	•	•	•	0		
V70 (08-)	2012	SUB		•	•	•	•	0	0		
V70 (08-)	2012	BPM		•	•	•	•	•	0		
V70 (08-)	2012	DABM		•	•	•	•	0	0		
V70 (08-)	2012	KVM		•	•	•	•	•	0		
V70 (08-)	2012	PBM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (08-)	2012	FLR		•	•	•	•	0	0		
V70 (08-)	2012	PSCM		•	•	•	•	•	0		
V70 (08-)	2012	MMM		•	•	•	•	0	0		
V70 (08-)	2012	PDM		•	•	•	•	•	0		
V70 (08-)	2012	AUD		•	•	•	•	0	0		
V70 (08-)	2012	POT		•	•	•	•	•	0		
V70 (08-)	2012	PHM		•	•	•	•	•	0		
V70 (08-)	2012	SAS		•	•	•	•	•	0		
V70 (08-)	2012	FSM		•	•	•	•	•	0		
V70 (08-)	2012	TVM		•	•	•	•	•	0		
V70 (08-)	2012	CCM		•	•	•	•	•	0		
V70 (08-)	2012	CVM		•	•	•	•	0	0		
V70 (08-)	2012	PAC		•	•	•	•	•	0		
V70 (08-)	2012	PSM		•	•	•	•	•	0		
V70 (08-)	2012	RSE		•	•	•	•	•	0		
V70 (08-)	2012	CEM		•	•	•	•	•	0		
V70 (08-)	2012	IAM		•	•	•	•	•	0		
V70 (08-)	2012	ICM		•	•	•	•	•	0		
V70 (08-)	2012	BCM		•	•	•	•	•	0		
V70 (08-)	2012	RDAR		•	•	•	•	0	0		
V70 (08-)	2012	ECM	D5244T11	•	•	•	•	•	0		
V70 (08-)	2012	ECM	D5244T15	•	•	•	•	•	0		
V70 (08-)	2012	ECM	D4162T	•	•	•	•	•	0		
V70 (08-)	2012	ECM	D5204T3	•	•	•	•	•	0		
V70 (08-)	2012	ECM	B4164T	•	•	•	•	•	0		
V70 (08-)	2012	ECM	B6324S5	•	•	•	•	•	0		
V70 (08-)	2012	ECM	B4204T7	•	•	•	•	•	0		
V70 (08-)	2012	ECM	B4164T2	•	•	•	•	•	0		
V70 (08-)	2012	ECM	B6304T4	•	•	•	•	•	0		
V70 (08-)	2012	TCM	MPS6	•	•	•	•	•	0		
V70 (08-)	2012	TCM	TF-80SC	•	•	•	•	•	0		
V70 (08-)	2012	DEM	TF-80SC AWD	•	•	•	•	•	•		
V70 (08-)	2012	TCM	TF-80SC AWD	•	•	•	•	•	0		
V70 (08-)	2012	ECM	B5254T10	•	•	•	•	•	0		
V70 (08-)	2012	TCM	B5254T10/TF-80SC	•	•	•	•	•	0		
V70 (08-)	2012	TCM	D5204T3/TF-80SD	•	•	•	•	•	0	<u> </u>	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V60	2012	CPM		•	•	•	•	•	•		
V60	2012	SUM		•	•	•	•	•	•		
V60	2012	PAM		•	•	•	•	•	0		
V60	2012	DABM		•	•	•	•	0	0		
V60	2012	PAC		•	•	•	•	0	0		
V60	2012	FLR		•	•	•	•	0	0		
V60	2012	PSCM		•	•	•	•	•	0		
V60	2012	KVM		•	•	•	•	•	0		
V60	2012	TRM		•	•	•	•	•	0		
V60	2012	SRS		•	•	•	•	•	0		
V60	2012	PDM		•	•	•	•	•	0		
V60	2012	AUD		•	•	•	•	0	0		
V60	2012	PHM		•	•	•	•	•	0		
V60	2012	SAS		•	•	•	•	•	0		
V60	2012	DDM		•	•	•	•	•	0		
V60	2012	TVM		•	•	•	•	•	0		
V60	2012	CCM		•	•	•	•	•	0		
V60	2012	CVM		•	•	•	•	0	0		
V60	2012	FSM		•	•	•	•	•	0		
V60	2012	PSM		•	•	•	•	•	0		
V60	2012	CEM		•	•	•	•	•	0		
V60	2012	IAM		•	•	•	•	•	0		
V60	2012	ICM		•	•	•	•	•	0		
V60	2012	BCM		•	•	•	•	•	0		
V60	2012	RDAR		•	•	•	•	0	0		
V60	2012	ECM	B6304T4	•	•	•	•	•	0		
V60	2012	ECM	B4164T2	•	•	•	•	•	0		
V60	2012	ECM	B4164T	•	•	•	•	•	0		
V60	2012	ECM	B4204T7	•	•	•	•	•	0		
V60	2012	ECM	D5244T15	•	•	•	•	•	0		
V60	2012	ECM	B4164T3	•	•	•	•	•	0		
V60	2012	ECM	D5204T3	•	•	•	•	•	0		
V60	2012	ECM	D4162T	•	•	•	•	•	0		
V60	2012	ECM	D5244T11	•	•	•	•	•	0		
V60	2012	TCM	MPS6	•	•	•	•	•	0		
V60	2012	DEM	TF-80SC AWD	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V60	2012	TCM	D5204T3/TF-80SD	•	•	•	•	•	0		
V50	2012	PSM		•	•	•	•	•	•		
V50	2012	AEM		•	•	•	•	•	•		
V50	2012	PAM		•	•	•	•	•	0		
V50	2012	AUD		•	•	•	•	0	0		
V50	2012	SRS		•	•	•	•	•	0		
V50	2012	DDM		•	•	•	•	•	•		
V50	2012	PDM		•	•	•	•	•	•		
V50	2012	AUU		•	•	•	•	•	0		
V50	2012	TRM		•	•	•	•	•	0		
V50	2012	SWM		•	•	•	•	•	0		
V50	2012	IAM		•	•	•	•	•	•		
V50	2012	SUB		•	•	•	•	0	0		
V50	2012	BCM		•	•	•	•	•	0		
V50	2012	KVM		•	•	•	•	•	•		
V50	2012	ICM		•	•	•	•	•	•		
V50	2012	HCM		•	•	•	•	•	0		
V50	2012	CPM		•	•	•	•	•	•		
V50	2012	BPM		•	•	•	•	•	0		
V50	2012	EPS		•	•	•	•	•	0		
V50	2012	MMM		•	•	•	•	•	•		
V50	2012	CCM		•	•	•	•	•	0		
V50	2012	PHM		•	•	•	•	•	0		
V50	2012	RDAR		•	•	•	•	•	0		
V50	2012	ECM	B5254T7	•	•	•	•	•	•		
V50	2012	ECM	B4204S3	•	•	•	•	•	•		
V50	2012	ECM	B4204S4	•	•	•	•	•	•		
V50	2012	ECM	B4164S3	•	•	•	•	•	•		
V50	2012	SAS	D5204T	•	•	•	•	•	0		
V50	2012	HCM	D5204T	•	•	•	•	•	0		
V50	2012	BCM	D5204T	•	•	•	•	•	•		
V50	2012	EPS	D5204T	•	•	•	•	•	0		
V50	2012	ECM	D5204T	•	•	•	•	•	0		
V50	2012	SAS	D4162T	•	•	•	•	•	0		
V50	2012	HCM	D4162T	•	•	•	•	•	0		
V50	2012	BCM	D4162T	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2012	EPS	D4162T	•	•	•	•	•	0		
V50	2012	ECM	D4162T	•	•	•	•	•	0		
V50	2012	SAS	D5204T5	•	•	•	•	•	0		
V50	2012	HCM	D5204T5	•	•	•	•	•	0		
V50	2012	BCM	D5204T5	•	•	•	•	•	•		
V50	2012	EPS	D5204T5	•	•	•	•	•	0		
V50	2012	ECM	D5204T5	•	•	•	•	•	0		
V50	2012	TCM	MPS6	•	•	•	•	•	0		
V50	2012	TCM	AW55-50/51SN	•	•	•	•	•	•		
S80L	2012	DDM		•	•	•	•	•	0		
S80L	2012	CPM		•	•	•	•	•	•		
S80L	2012	SUM		•	•	•	•	•	•		
S80L	2012	PAM		•	•	•	•	•	0		
S80L	2012	HLDF		•	•	•	•	•	0		
S80L	2012	TRM		•	•	•	•	•	0		
S80L	2012	PBM		•	•	•	•	•	0		
S80L	2012	SRS		•	•	•	•	•	0		
S80L	2012	BPM		•	•	•	•	•	0		
S80L	2012	DABM		•	•	•	•	0	0		
S80L	2012	KVM		•	•	•	•	•	0		
S80L	2012	FLR		•	•	•	•	0	0		
S80L	2012	PSCM		•	•	•	•	•	0		
S80L	2012	MMM		•	•	•	•	0	0		
S80L	2012	PDM		•	•	•	•	•	0		
S80L	2012	AUD		•	•	•	•	0	0		
S80L	2012	PHM		•	•	•	•	•	0		
S80L	2012	SAS		•	•	•	•	•	0		
S80L	2012	FSM		•	•	•	•	•	0		
S80L	2012	CCM		•	•	•	•	•	0		
S80L	2012	CVM		•	•	•	•	0	0		
S80L	2012	PAC		•	•	•	•	•	0		
S80L	2012	PSM		•	•	•	•	•	0		
S80L	2012	RSE		•	•	•	•	•	0		
S80L	2012	CEM		•	•	•	•	•	0		
S80L	2012	IAM		•	•	•	•	•	0		
S80L	2012	ICM		•	•	•	•	•	0		



NOTES:

• This function is supported.

imes This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80L	2012	BCM		•	•	•	•	•	0		
S80L	2012	RDAR		•	•	•	•	0	0		
S80L	2012	ECM	B6304T4	•	•	•	•	•	0		
S80L	2012	ECM	B4204T7	•	•	•	•	•	0		
S80L	2012	TCM	MPS6	•	•	•	•	•	0		
S80L	2012	DEM	TF-80SC AWD	•	•	•	•	•	•		
S80L	2012	ECM	B4204T6	•	•	•	•	•	0		
S80L	2012	ECM	B5254T12	0	0	0	0	0	0		
S80L	2012	ECM	B5204T8	0	0	0	0	0	0		
S80 (07-)	2012	DDM		•	•	•	•	•	0		
S80 (07-)	2012	CPM		•	•	•	•	•	•		
S80 (07-)	2012	SUM		•	•	•	•	•	•		
S80 (07-)	2012	PAM		•	•	•	•	•	0		
S80 (07-)	2012	HLDF		•	•	•	•	•	0		
S80 (07-)	2012	TRM		•	•	•	•	•	0		
S80 (07-)	2012	SRS		•	•	•	•	•	0		
S80 (07-)	2012	BPM		•	•	•	•	•	0		
S80 (07-)	2012	DABM		•	•	•	•	0	0		
S80 (07-)	2012	KVM		•	•	•	•	•	0		
S80 (07-)	2012	PBM		•	•	•	•	•	0		
S80 (07-)	2012	FLR		•	•	•	•	0	0		
S80 (07-)	2012	PSCM		•	•	•	•	•	0		
S80 (07-)	2012	MMM		•	•	•	•	0	0		
S80 (07-)	2012	PDM		•	•	•	•	•	0		
S80 (07-)	2012	AUD		•	•	•	•	0	0		
S80 (07-)	2012	PHM		•	•	•	•	•	0		
S80 (07-)	2012	SAS		•	•	•	•	•	0		
S80 (07-)	2012	FSM		•	•	•	•	•	0		
S80 (07-)	2012	TVM		•	•	•	•	•	0		
S80 (07-)	2012	CCM		•	•	•	•	•	0		
S80 (07-)	2012	CVM		•	•	•	•	0	0		
S80 (07-)	2012	PAC		•	•	•	•	•	0		
S80 (07-)	2012	PSM		•	•	•	•	•	0		
S80 (07-)	2012	RSE		•	•	•	•	•	0		
S80 (07-)	2012	CEM		•	•	•	•	•	0		
S80 (07-)	2012	IAM		•	•	•	•	•	0		



NOTES:

• This function is supported.

** This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2012	ICM		•	•	•	•	•	0		
S80 (07-)	2012	BCM		•	•	•	•	•	0		
S80 (07-)	2012	RDAR		•	•	•	•	0	0		
S80 (07-)	2012	ECM	B6304T4	•	•	•	•	•	0		
S80 (07-)	2012	ECM	B6324S5	•	•	•	•	•	0		
S80 (07-)	2012	ECM	B6324S4	•	•	•	•	•	0		
S80 (07-)	2012	ECM	B4164T2	•	•	•	•	•	0		
S80 (07-)	2012	ECM	B4164T	•	•	•	•	•	0		
S80 (07-)	2012	ECM	B5254T8	•	•	•	•	•	•		
S80 (07-)	2012	ECM	B4204T7	•	•	•	•	•	0		
S80 (07-)	2012	ECM	D5244T15	•	•	•	•	•	0		
S80 (07-)	2012	ECM	D4162T	•	•	•	•	•	0		
S80 (07-)	2012	ECM	D5204T3	•	•	•	•	•	0		
S80 (07-)	2012	ECM	D5244T11	•	•	•	•	•	0		
S80 (07-)	2012	TCM	MPS6	•	•	•	•	•	0		
S80 (07-)	2012	DEM	TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2012	ECM	B4204T6	•	•	•	•	•	0		
S80 (07-)	2012	ECM	B5254T10	•	•	•	•	•	0		
S60 (11-)	2012	CPM		•	•	•	•	•	•		
S60 (11-)	2012	SUM		•	•	•	•	•	•		
S60 (11-)	2012	PAM		•	•	•	•	•	0		
S60 (11-)	2012	DABM		•	•	•	•	0	0		
S60 (11-)	2012	PAC		•	•	•	•	0	0		
S60 (11-)	2012	FLR		•	•	•	•	0	0		
S60 (11-)	2012	PSCM		•	•	•	•	•	0		
S60 (11-)	2012	KVM		•	•	•	•	•	0		
S60 (11-)	2012	TRM		•	•	•	•	•	0		
S60 (11-)	2012	SRS		•	•	•	•	•	0		
S60 (11-)	2012	PDM		•	•	•	•	•	0		
S60 (11-)	2012	AUD		•	•	•	•	0	0		
S60 (11-)	2012	PHM		•	•	•	•	•	0		
S60 (11-)	2012	SAS		•	•	•	•	•	0		
S60 (11-)	2012	DDM		•	•	•	•	•	0		
S60 (11-)	2012	TVM		•	•	•	•	•	0		
S60 (11-)	2012	CCM		•	•	•	•	•	0		
S60 (11-)	2012	CVM		•	•	•	•	0	0		



NOTES:

This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60 (11-)	2012	FSM		11110.	•	•	•	•	0	i dilotton	
S60 (11-)	2012	PSM		•	•	•	•	•	0		
S60 (11-)	2012	CEM		•	•	•	•	•	0		
S60 (11-)	2012	IAM		•	•	•	•	•	0		
S60 (11-)	2012	ICM		•	•	•	•	•	0		
S60 (11-)	2012	BCM		•	•	•	•	•	0		
S60 (11-)	2012	RDAR		•	•	•	•	0	0		
S60 (11-)	2012	ECM	B6304T4	•	•	•	•	•	0		
S60 (11-)	2012	ECM	B5254T5	•	•	•	•	•	0		
S60 (11-)	2012	ECM	D5244T11	•	•	•	•	•	0		
S60 (11-)	2012	ECM	B4204T7	•	•	•	•	•	0		
S60 (11-)	2012	ECM	D5244T15	•	•	•	•	•	0		
S60 (11-)	2012	ECM	D4162T	•	•	•	•	•	0		
S60 (11-)	2012	ECM	D5204T3	•	•	•	•	•	0		
S60 (11-)	2012	ECM	B4164T3	•	•	•	•	•	0		
S60 (11-)	2012	ECM	B4164T	•	•	•	•	•	0		
S60 (11-)	2012	ECM	B4164T2	•	•	•	•	•	0		
S60 (11-)	2012	TCM	MPS6	•	•	•	•	•	0		
S60 (11-)	2012	DEM	TF-80SC AWD	•	•	•	•	•	•		
S40 (04-)	2012	BCM		•	•	•	•	•	0		
S40 (04-)	2012	PSM		•	•	•	•	•	•		
S40 (04-)	2012	AEM		•	•	•	•	•	•		
S40 (04-)	2012	PAM		•	•	•	•	•	0		
S40 (04-)	2012	AUD		•	•	•	•	0	0		
S40 (04-)	2012	SRS		•	•	•	•	•	0		
S40 (04-)	2012	DDM		•	•	•	•	•	•		
S40 (04-)	2012	PDM		•	•	•	•	•	•		
S40 (04-)	2012	AUU		•	•	•	•	•	0		
S40 (04-)	2012	TRM		•	•	•	•	•	0		
S40 (04-)	2012	SWM		•	•	•	•	•	0		
S40 (04-)	2012	IAM		•	•	•	•	•	•		
S40 (04-)	2012	SUB		•	•	•	•	0	0		
S40 (04-)	2012	KVM		•	•	•	•	•	•		
S40 (04-)	2012	ICM		•	•	•	•	•	•		
S40 (04-)	2012	HCM		•	•	•	•	•	0		
S40 (04-)	2012	CPM		•	•	•	•	•	•	ļ	



NOTES:

• This function is supported.
** This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2012	BPM		•	•	•	•	•	0		
S40 (04-)	2012	EPS		•	•	•	•	•	0		
S40 (04-)	2012	MMM		•	•	•	•	•	•		
S40 (04-)	2012	CCM		•	•	•	•	•	0		
S40 (04-)	2012	PHM		•	•	•	•	•	0		
S40 (04-)	2012	RDAR		•	•	•	•	•	0		
S40 (04-)	2012	ECM	B5254T7	•	•	•	•	•	•		
S40 (04-)	2012	TCM	AW55-50/51SN	•	•	•	•	•	•		
S40 (04-)	2012	SAS	D4162T	•	•	•	•	•	0		
S40 (04-)	2012	HCM	D4162T	•	•	•	•	•	0		
S40 (04-)	2012	BCM	D4162T	•	•	•	•	•	•		
S40 (04-)	2012	EPS	D4162T	•	•	•	•	•	0		
S40 (04-)	2012	ECM	D4162T	•	•	•	•	•	0		
S40 (04-)	2012	ECM	B4204S3	•	•	•	•	•	•		
S40 (04-)	2012	ECM	B4204S4	•	•	•	•	•	•		
S40 (04-)	2012	ECM	B4164S3	•	•	•	•	•	•		
S40 (04-)	2012	SAS	D5204T	•	•	•	•	•	0		
S40 (04-)	2012	HCM	D5204T	•	•	•	•	•	0		
S40 (04-)	2012	BCM	D5204T	•	•	•	•	•	•		
S40 (04-)	2012	EPS	D5204T	•	•	•	•	•	0		
S40 (04-)	2012	ECM	D5204T	•	•	•	•	•	0		
S40 (04-)	2012	TCM	MPS6	•	•	•	•	•	0		
S40 (04-)	2012	SAS	D5204T5	•	•	•	•	•	0		
S40 (04-)	2012	HCM	D5204T5	•	•	•	•	•	0		
S40 (04-)	2012	BCM	D5204T5	•	•	•	•	•	•		
S40 (04-)	2012	EPS	D5204T5	•	•	•	•	•	0		
S40 (04-)	2012	ECM	D5204T5	•	•	•	•	•	0		
C70 (06-)	2012	BCM		•	•	•	•	•	0		
C70 (06-)	2012	AEM		•	•	•	•	•	•		
C70 (06-)	2012	EPS		•	•	•	•	•	0		
C70 (06-)	2012	PAM		•	•	•	•	•	0		
C70 (06-)	2012	AUD		•	•	•	•	0	0		
C70 (06-)	2012	DDM		•	•	•	•	•	•		
C70 (06-)	2012	PDM		•	•	•	•	•	•		
C70 (06-)	2012	AUU		•	•	•	•	•	0		
C70 (06-)	2012	TRM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2012	SRS		•	•	•	•	•	0		
C70 (06-)	2012	SWM		•	•	•	•	•	0		
C70 (06-)	2012	IAM		•	•	•	•	•	•		
C70 (06-)	2012	SUB		•	•	•	•	0	0		
C70 (06-)	2012	KVM		•	•	•	•	•	•		
C70 (06-)	2012	PSL		•	•	•	•	•	0		
C70 (06-)	2012	PSR		•	•	•	•	•	0		
C70 (06-)	2012	ICM		•	•	•	•	•	•		
C70 (06-)	2012	CRM		•	•	•	•	•	0		
C70 (06-)	2012	HCM		•	•	•	•	•	0		
C70 (06-)	2012	CPM		•	•	•	•	•	•		
C70 (06-)	2012	BPM		•	•	•	•	•	0		
C70 (06-)	2012	MMM		•	•	•	•	•	•		
C70 (06-)	2012	CCM		•	•	•	•	•	0		
C70 (06-)	2012	PHM		•	•	•	•	•	0		
C70 (06-)	2012	RDAR		•	•	•	•	•	0		
C70 (06-)	2012	ECM	B5254T7	•	•	•	•	•	•		
C70 (06-)	2012	SAS	D5204T5	•	•	•	•	•	0		
C70 (06-)	2012	HCM	D5204T5	•	•	•	•	•	0		
C70 (06-)	2012	BCM	D5204T5	•	•	•	•	•	•		
C70 (06-)	2012	EPS	D5204T5	•	•	•	•	•	0		
C70 (06-)	2012	ECM	D5204T5	•	•	•	•	•	0		
C70 (06-)	2012	SAS	D5204T	•	•	•	•	•	0		
C70 (06-)	2012	HCM	D5204T	•	•	•	•	•	0		
C70 (06-)	2012	BCM	D5204T	•	•	•	•	•	•		
C70 (06-)	2012	EPS	D5204T	•	•	•	•	•	0		
C70 (06-)	2012	ECM	D5204T	•	•	•	•	•	0		
C70 (06-)	2012	TCM	AW55-50/51SN	•	•	•	•	•	•		
C30 Electric	2012	BCM		•	•	•	•	•	0		
C30 Electric	2012	AEM		•	•	•	•	•	•		
C30 Electric	2012	PAM		•	•	•	•	•	0		
C30 Electric	2012	AUD		•	•	•	•	0	0		
C30 Electric	2012	SRS		•	•	•	•	•	0		
C30 Electric	2012	DDM		•	•	•	•	•	•		
C30 Electric	2012	PDM		•	•	•	•	•	•		
C30 Electric	2012	AUU		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30 Electric	2012	SWM		•	•	•	•	•	0		
C30 Electric	2012	IAM		•	•	•	•	•	•		
C30 Electric	2012	RDAR		•	•	•	•	•	0		
C30 Electric	2012	KVM		•	•	•	•	•	•		
C30 Electric	2012	ICM		•	•	•	•	•	•		
C30 Electric	2012	HCM		•	•	•	•	•	0		
C30 Electric	2012	CPM		•		•	•	•	•		
C30 Electric	2012	BPM		•	•	•	•	•	0		
C30 Electric	2012	EPS		•	•	•	•	•	0		
C30 Electric	2012	MMM		•	•	•	•	•	•		
C30 Electric	2012	PHM		•	•	•	•	•	0		
C30 Electric	2012	CEM-HS		•	•	•	•	•	•		
C30 Electric	2012	CCM		•	•	•	•	•	0		
C30 Electric	2012	CEM		•	•	•	•	•	•		
C30	2012	BCM		•	•	•	•	•	0		
C30	2012	AEM		•	•	•	•	•	•		
C30	2012	PAM		•	•	•	•	•	0		
C30	2012	AUD		•	•	•	•	0	0		
C30	2012	SRS		•	•	•	•	•	0		
C30	2012	DDM		•	•	•	•	•	•		
C30	2012	PDM		•	•	•	•	•	•		
C30	2012	AUU		•	•	•	•	•	0		
C30	2012	TRM		•	•	•	•	•	0		
C30	2012	SWM		•	•	•	•	•	0		
C30	2012	IAM		•	•	•	•	•	•		
C30	2012	KVM		•	•	•	•	•	•		
C30	2012	PSL		•	•	•	•	•	0		
C30	2012	PSR		•	•	•	•	•	0		
C30	2012	ICM		•	•	•	•	•	•		
C30	2012	HCM		•	•	•	•	•	0		
C30	2012	CPM		•	•	•	•	•	•		
C30	2012	BPM		•	•	•	•	•	0		
C30	2012	EPS		•	•	•	•	•	0		
C30	2012	MMM		•	•	•	•	•	•		
C30	2012	CCM		•	•	•	•	•	0		
C30	2012	PHM		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2012	CEM		•	•	•	•	•	•		
C30	2012	CEM-HS		•	•	•	•	•	•		
C30	2012	RDAR		•	•	•	•	•	0		
C30	2012	ECM	B5254T7	•	•	•	•	•	•		
C30	2012	SAS	D5204T5	•	•	•	•	•	0		
C30	2012	HCM	D5204T5	•	•	•	•	•	0		
C30	2012	BCM	D5204T5	•	•	•	•	•	•		
C30	2012	EPS	D5204T5	•	•	•	•	•	0		
C30	2012	ECM	D5204T5	•	•	•	•	•	0		
C30	2012	CEM	D5204T5	•	•	•	•	•	•		
C30	2012	CEM-HS	D5204T5	•	•	•	•	•	•		
C30	2012	CEM-HS	D5204T5	0	0	0	0	0	0		
C30	2012	SAS	D4162T	•	•	•	•	•	0		
C30	2012	HCM	D4162T	•	•	•	•	•	0		
C30	2012	BCM	D4162T	•	•	•	•	•	•		
C30	2012	EPS	D4162T	•	•	•	•	•	0		
C30	2012	ECM	D4162T	•	•	•	•	•	0		
C30	2012	CEM	D4162T	•	•	•	•	•	•		
C30	2012	CEM-HS	D4162T	•	•	•	•	•	•		
C30	2012	CEM-HS	D4162T	0	0	0	0	0	0		
C30	2012	ECM	B4204S4	•	•	•	•	•	•		
C30	2012	ECM	B4204S3	•	•	•	•	•	•		
C30	2012	SAS	D5204T	•	•	•	•	•	0		
C30	2012	HCM	D5204T	•	•	•	•	•	0		
C30	2012	BCM	D5204T	•	•	•	•	•	•		
C30	2012	EPS	D5204T	•	•	•	•	•	0		
C30	2012	ECM	D5204T	•	•	•	•	•	0		
C30	2012	CEM	D5204T	•	•	•	•	•	•		
C30	2012	CEM-HS	D5204T	•	•	•	•	•	•		
C30	2012	CEM-HS	D5204T	0	0	0	0	0	0		
C30	2012	ECM	B4164S3	•	•	•	•	•	•		
C30	2012	TCM	MPS6	•	•	•	•	•	0		
C30	2012	TCM	D5204T/TF-80SC	•	•	•	•	•	0		
C30	2012	TCM	D5204T5/TF-80SC	•	•	•	•	•	0		
C30	2012	TCM	AW55-50/51SN	•	•	•	•	•	•		
C70 (06-)	2011A	BCM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2011A	AEM		•	•	•	•	•	•		
C70 (06-)	2011A	EPS		•	•	•	•	•	0		
C70 (06-)	2011A	PAM		•	•	•	•	•	0		
C70 (06-)	2011A	AUD		•	•	•	•	0	0		
C70 (06-)	2011A	DDM		•	•	•	•	•	•		
C70 (06-)	2011A	PDM		•	•	•	•	•	•		
C70 (06-)	2011A	PSL		•	•	•	•	•	0		
C70 (06-)	2011A	PSR		•	•	•	•	•	0		
C70 (06-)	2011A	AUU		•	•	•	•	•	0		
C70 (06-)	2011A	TRM		•	•	•	•	•	0		
C70 (06-)	2011A	SRS		•	•	•	•	•	0		
C70 (06-)	2011A	SWM		•	•	•	•	•	0		
C70 (06-)	2011A	IAM		•	•	•	•	•	•		
C70 (06-)	2011A	SUB		•	•	•	•	0	0		
C70 (06-)	2011A	RDAR		•	•	•	•	•	0		
C70 (06-)	2011A	KVM		•	•	•	•	•	•		
C70 (06-)	2011A	BPM		•	•	•	•	•	0		
C70 (06-)	2011A	CPM		•	•	•	•	•	•		
C70 (06-)	2011A	ICM		•	•	•	•	•	•		
C70 (06-)	2011A	CRM		•	•	•	•	•	0		
C70 (06-)	2011A	MMM		•	•	•	•	•	•		
C70 (06-)	2011A	PHM		•	•	•	•	•	0		
C70 (06-)	2011A	HCM		•	•	•	•	•	0		
C70 (06-)	2011A	CCM		•	•	•	•	•	0		
C70 (06-)	2011A	ECM	B5254T7	•	•	•	•	•	•		
C70 (06-)	2011A	TCM	AW55-50/51SN	•	•	•	•	•	•		
C70 (06-)	2011A	BCM		•	•	•	•	•	0		
C70 (06-)	2011A	AEM		•	•	•	•	•	•		
C70 (06-)	2011A	EPS		•	•	•	•	•	0		
C70 (06-)	2011A	PAM		•	•	•	•	•	0		
C70 (06-)	2011A	AUD		•	•	•	•	0	0		
C70 (06-)	2011A	DDM		•	•	•	•	•	•		
C70 (06-)	2011A	PDM		•	•	•	•	•	•		
C70 (06-)	2011A	PSL		•	•	•	•	•	0		
C70 (06-)	2011A	PSR		•	•	•	•	•	0		
C70 (06-)	2011A	AUU		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2011A	TRM		•	•	•	•	•	0		
C70 (06-)	2011A	SRS		•	•	•	•	•	0		
C70 (06-)	2011A	SWM		•	•	•	•	•	0		
C70 (06-)	2011A	IAM		•	•	•	•	•	•		
C70 (06-)	2011A	SUB		•	•	•	•	0	0		
C70 (06-)	2011A	RDAR		•	•	•	•	•	0		
C70 (06-)	2011A	KVM		•	•	•	•	•	•		
C70 (06-)	2011A	BPM		•	•	•	•	•	0		
C70 (06-)	2011A	CPM		•	•	•	•	•	•		
C70 (06-)	2011A	ICM		•	•	•	•	•	•		
C70 (06-)	2011A	CRM		•	•	•	•	•	0		
C70 (06-)	2011A	MMM		•	•	•	•	•	•		
C70 (06-)	2011A	PHM		•	•	•	•	•	0		
C70 (06-)	2011A	HCM		•	•	•	•	•	0		
C70 (06-)	2011A	CCM		•	•	•	•	•	0		
C70 (06-)	2011A	ECM	B5254T7	•	•	•	•	•	•		
C70 (06-)	2011A	TCM	AW55-50/51SN	•	•	•	•	•	•		
C30	2011A	BCM		•	•	•	•	•	0		
C30	2011A	AEM		•	•	•	•	•	•		
C30	2011A	PAM		•	•	•	•	•	0		
C30	2011A	AUD		•	•	•	•	0	0		
C30	2011A	SRS		•	•	•	•	•	0		
C30	2011A	DDM		•	•	•	•	•	•		
C30	2011A	PDM		•	•	•	•	•	•		
C30	2011A	PSL		•	•	•	•	•	0		
C30	2011A	PSR		•	•	•	•	•	0		
C30	2011A	AUU		•	•	•	•	•	0		
C30	2011A	TRM		•	•	•	•	•	0		
C30	2011A	SWM		•	•	•	•	•	0		
C30	2011A	IAM		•	•	•	•	•	•		
C30	2011A	RDAR		•	•	•	•	•	0		
C30	2011A	KVM		•	•	•	•	•	•		
C30	2011A	BPM		•	•	•	•	•	0		
C30	2011A	CPM		•	•	•	•	•	•		
C30	2011A	ICM		•	•	•	•	•	•		
C30	2011A	MMM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2011A	PHM		•	•	•	•	•	0		
C30	2011A	HCM		•	•	•	•	•	0		
C30	2011A	CCM		•	•	•	•	•	0		
C30	2011A	EPS		•	•	•	•	•	0		
C30	2011A	ECM	B5244S4	•	•	•	•	•	•		
C30	2011A	ECM	B5254T7	•	•	•	•	•	•		
C30	2011A	TCM	AW55-50/51SN	•	•	•	•	•	•		
C30	2011A	BCM		•	•	•	•	•	0		
C30	2011A	AEM		•	•	•	•	•	•		
C30	2011A	PAM		•	•	•	•	•	0		
C30	2011A	AUD		•	•	•	•	0	0		
C30	2011A	SRS		•	•	•	•	•	0		
C30	2011A	DDM		•	•	•	•	•	•		
C30	2011A	PDM		•	•	•	•	•	•		
C30	2011A	PSL		•	•	•	•	•	0		
C30	2011A	PSR		•	•	•	•	•	0		
C30	2011A	AUU		•	•	•	•	•	0		
C30	2011A	TRM		•	•	•	•	•	0		
C30	2011A	SWM		•	•	•	•	•	0		
C30	2011A	IAM		•	•	•	•	•	•		
C30	2011A	RDAR		•	•	•	•	•	0		
C30	2011A	KVM		•	•	•	•	•	•		
C30	2011A	BPM		•	•	•	•	•	0		
C30	2011A	CPM		•	•	•	•	•	•		
C30	2011A	ICM		•	•	•	•	•	•		
C30	2011A	MMM		•	•	•	•	•	•		
C30	2011A	PHM		•	•	•	•	•	0		
C30	2011A	HCM		•	•	•	•	•	0		
C30	2011A	CCM		•	•	•	•	•	0		
C30	2011A	EPS		•	•	•	•	•	0		
C30	2011A	ECM	B5244S4	•		•	•	•	•		
C30	2011A	ECM	B5254T7	•	•	•	•	•	•		
XC90	2011	GPS		•	•	•	•	•	0		
XC90	2011	PSM		•	•	•	•	•	•		
XC90	2011	DDM		•	•	•	•	•	•		
XC90	2011	PDM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2011	AEM		•	•	•	•	•	•		
XC90	2011	AUD		•	•	•	•	0	0		
XC90	2011	PAC		•	0	0	0	0	0		
XC90	2011	AUU		•	•	•	•	•	0		
XC90	2011	DIM		•	•	•	•	•	•		
XC90	2011	IAM		•	•	•	•	•	•		
XC90	2011	RDAR		•	•	•	•	•	0		
XC90	2011	UEM		•	•	•	•	•	•		
XC90	2011	BPM		•	•	•	•	•	0		
XC90	2011	MMM		•	•	•	•	•	•		
XC90	2011	SRS		•	•	•	•	•	0		
XC90	2011	PHM		•	•	•	•	•	0		
XC90	2011	ICM		•	•	•	•	•	•		
XC90	2011	CCM		•	•	•	•	•	0		
XC90	2011	CPM		•	数据流	0	0	0	0		
XC90	2011	REM		•	•	•	•	•	•		
XC90	2011	BCM	B5254T2	•	•	•	•	•	•		
XC90	2011	SAS	B5254T2	•	•	•	•	•	0		
XC90	2011	ECM	B5254T2	•	•	•	•	•	•		
XC90	2011	HCM	B5254T2	•	•	•	•	•	0		
XC90	2011	CEM	B5254T2	•	•	•	•	•	0		
XC90	2011	BCM	D5244T4	•	•	•	•	•	•		
XC90	2011	SAS	D5244T4	•	•	•	•	•	0		
XC90	2011	HCM	D5244T4	•	•	•	•	•	0		
XC90	2011	ECM	D5244T4	•	•	•	•	•	•		
XC90	2011	CEM	D5244T4	•	•	•	•	•	0		
XC90	2011	BCM	D5244T5	•	•	•	•	•	•		
XC90	2011	SAS	D5244T5	•	•	•	•	•	0		
XC90	2011	HCM	D5244T5	•	•	•	•	•	0		
XC90	2011	CEM	D5244T5	•	•	•	•	•	0		
XC90	2011	ECM	D5244T5	•	•	•	•	•	•		
XC90	2011	BCM	B8444S	•	•	•	•	•	•		
XC90	2011	SAS	B8444S	•	•	•	•	•	0		
XC90	2011	HCM	B8444S	•	•	•	•	•	0		
XC90	2011	ECM	B8444S	•	•	•	•	•	0		
XC90	2011	CEM	B8444S	•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2011	CEM-HS	B8444S	0	0	0	0	0	0		
XC90	2011	CPM	B8444S	0	0	0	0	0	0		
XC90	2011	TCM	AW50/51 AWD	•	•	•	•	•	•		
XC90	2011	DEM	D5244T5/M66 AWD	•	•	•	•	•	0		
XC90	2011	TCM	D5244T5/TF-80SC AWD	•	•	•	•	•	•		
XC90	2011	DEM	D5244T5/TF-80SC AWD	•	•	•	•	•	0		
XC90	2011	DEM	D5244T4/M66 AWD	•	•	•	•	•	0		
XC90	2011	TCM	D5244T4/TF-80SC AWD	•	•	•	•	•	•		
XC90	2011	DEM	D5244T4/TF-80SC AWD	•	•	•	•	•	0		
XC90	2011	DEM	B5254T2/AW50/51 AWD	•	•	•	•	•	0		
XC90	2011	TCM	B8444S/TF-80SC AWD	•	•	•	•	•	•		
XC90	2011	DEM	B8444S/TF-80SC AWD	•	•	•	•	•	0		
XC90	2011	BCM	B6324S5	•	•	•	•	•	•		
XC90	2011	SAS	B6324S5	•	•	•	•	•	0		
XC90	2011	HCM	B6324S5	•	•	•	•	•	0		
XC90	2011	ECM	B6324S5	0	0	0	0	0	0		
XC90	2011	CEM	B6324S5	•	•	•	•	•	0		
XC90	2011	CEM-HS	B6324S5	0	0	0	0	0	0		
XC90	2011	CPM	B6324S5	0	0	0	0	0	0		
XC90	2011	TCM	B6324S5/TF-80SC AWD	0	0	0	0	0	0		
XC90	2011	DEM	B6324S5/TF-80SC AWD	•	•	•	•	•	0		
XC90	2011	TCM	B6324S5/TF-80SC	0	0	0	0	0	0		
XC90	2011	TCM	D5244T5/TF-80SC	•	•	•	•	•	•		
XC90	2011	TCM	D5244T4/TF-80SC	•	•	•	•	•	•		
XC90	2011	BCM	D5244T18	•	•	•	•	•	•		
XC90	2011	SAS	D5244T18	•	•	•	•	•	0		
XC90	2011	HCM	D5244T18	•	•	•	•	•	0		
XC90	2011	CEM	D5244T18	•	•	•	•	•	0		
XC90	2011	ECM	D5244T18	•	•	•	•	•	•		
XC90	2011	TCM	D5244T18/TF-80SC AWD	•	•	•	•	•	•		
XC90	2011	DEM	D5244T18/TF-80SC AWD	•	•	•	•	•	0		
XC70 (08-)	2011	DDM		•	•	•	•	•	0		
XC70 (08-)	2011	CPM		•	•	•	•	•	•		
XC70 (08-)	2011	AUD		•	•	•	•	0	0		
XC70 (08-)	2011	SUM		•	•	•	•	•	•		
XC70 (08-)	2011	HCM		•	•	•	•	•	0		



NOTES:

- This function is supported.

 * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2011	PAM		•	•	•	•	•	0		
XC70 (08-)	2011	HLDF		•	•	•	•	•	0		
XC70 (08-)	2011	TRM		•	•	•	•	•	0		
XC70 (08-)	2011	PSM		•	•	•	•	•	•		
XC70 (08-)	2011	AUU		•	•	•	•	•	0		
XC70 (08-)	2011	PHM		•	•	•	•	•	0		
XC70 (08-)	2011	SRS		•	•	•	•	•	0		
XC70 (08-)	2011	SUB		•	•	•	•	0	0		
XC70 (08-)	2011	BPM		•	•	•	•	•	0		
XC70 (08-)	2011	PAC		•	•	•	•	•	0		
XC70 (08-)	2011	RDAR		•	•	•	•	0	0		
XC70 (08-)	2011	DABM		•	•	•	•	0	0		
XC70 (08-)	2011	ICM		•	•	•	•	•	•		
XC70 (08-)	2011	KVM		•	•	•	•	•	0		
XC70 (08-)	2011	SAS		•	•	•	•	•	0		
XC70 (08-)	2011	IAM		•	•	•	•	•	0		
XC70 (08-)	2011	PBM		•	•	•	•	•	0		
XC70 (08-)	2011	FLR		•	•	•	•	0	0		
XC70 (08-)	2011	PSCM		•	•	•	•	•	0		
XC70 (08-)	2011	MMM		•	•	•	•	0	0		
XC70 (08-)	2011	PDM		•	•	•	•	•	0		
XC70 (08-)	2011	POT		•	•	•	•	•	0		
XC70 (08-)	2011	CCM		•	•	•	•	•	0		
XC70 (08-)	2011	FSM		•	•	•	•	•	0		
XC70 (08-)	2011	BCM		•	•	•	•	•	0		
XC70 (08-)	2011	CEM		•	•	•	•	•	0		
XC70 (08-)	2011	ECM	D5204T2	•	•	•	•	•	0		
XC70 (08-)	2011	ECM	B6304T4	•	•	•	•	•	0		
XC70 (08-)	2011	ECM	D5244T10	•	•	•	•	•	0		
XC70 (08-)	2011	ECM	B6324S5	•	•	•	•	•	0		
XC70 (08-)	2011	ECM	D5244T16	•	•	•	•	•	0		
XC70 (08-)	2011	ECM	B6324S4	•	•	•	•	•	0		
XC70 (08-)	2011	TCM	TF-80SC	•	•	•	•	•	0		
XC70 (08-)	2011	DEM	M66 AWD	•	•	•	•	•	•		
XC70 (08-)	2011	DEM	TF-80SC AWD	•	•	•	•	•	•		
XC70 (08-)	2011	TCM	TF-80SC AWD	•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2011	TCM	D5244T10/TF-80SC AWD	•	•	•	•	•	0		
XC70 (08-)	2011	TCM	D5244T16/TF-80SC AWD	•	•	•	•	•	0		
XC60	2011	DDM		•	•	•	•	•	0		
XC60	2011	ECM	B4204T7	•	•	•	•	•	0		
XC60	2011	CPM		•	•	•	•	•	•		
XC60	2011	SUM		•	•	•	•	•	•		
XC60	2011	PAM		•	•	•	•	•	0		
XC60	2011	TRM		•	•	•	•	•	0		
XC60	2011	PSM		•	•	•	•	•	•		
XC60	2011	AUU		•	•	•	•	•	0		
XC60	2011	PHM		•	•	•	•	•	0		
XC60	2011	SUB		•	•	•	•	0	0		
XC60	2011	HLDF		•	•	•	•	•	0		
XC60	2011	RDAR		•	•	•	•	0	0		
XC60	2011	BPM		•	•	•	•	•	0		
XC60	2011	DABM		•	•	•	•	0	0		
XC60	2011	SRS		•	•	•	•	•	0		
XC60	2011	KVM		•	•	•	•	•	0		
XC60	2011	SAS		•	•	•	•	•	0		
XC60	2011	HCM		•	•	•	•	•	0		
XC60	2011	PAC		•	•	•	•	0	0		
XC60	2011	FLR		•	•	•	•	0	0		
XC60	2011	CVM		•	•	•	•	0	0		
XC60	2011	PSCM		•	•	•	•	•	0		
XC60	2011	IAM		•	•	•	•	•	0		
XC60	2011	MMM		•	•	•	•	0	0		
XC60	2011	PDM		•	•	•	•	•	0		
XC60	2011	CCM		•	•	•	•	•	0		
XC60	2011	POT		•	•	•	•	•	0		
XC60	2011	FSM		•	•	•	•	•	0		
XC60	2011	AUD		•	•	•	•	0	0		
XC60	2011	TVM		•	•	•	•	•	0		
XC60	2011	ICM		•	•	•	•	•	0		
XC60	2011	BCM		•	•	•	•	•	0		
XC60	2011	CEM		•	•	•	•	•	0		
XC60	2011	ECM	D5204T2	•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze	Live	Active	Special	Other
XC60	2011	ECM	B6304T4	Info.	•	DIC	Frame	Data	Test	Function	
XC60	2011	ECM	D5244T10			•			0		
XC60	2011	ECM	B4204T6				•		0		
XC60	2011	ECM	D5244T16			•	•		0		
XC60	2011	ECM	B6324S5			•	•		0		
XC60	2011	ECM	B6324S4			•	•		0		
XC60	2011	TCM	MPS6				•	•	0		
XC60	2011	DEM	TF-80SC AWD			•	•	-	•		
XC60	2011	DEM	M66 AWD			•	•		•		
V70 (08-)	2011	DDM	MOO AWD				•		0		
V70 (08-)	2011	СРМ							•		
V70 (08-)	2011	AUD						0	0		
V70 (08-)	2011	SUM				•	•	•	•		
V70 (08-)	2011	HCM							0		
V70 (08-)	2011	PAM					•		0		
V70 (08-)	2011	HLDF							0		
V70 (08-)	2011	TRM							0		
V70 (08-)	2011	PSM				•	•		•		
V70 (08-)	2011	AUU					•		0		
V70 (08-)	2011	PHM				•	•	•	0		
V70 (08-)	2011	SRS				•	•		0		
V70 (08-)	2011	SUB				•	•	0	0		
V70 (08-)	2011	BPM					•	•	0		
V70 (08-)	2011	PAC				•	•	•	0		
V70 (08-)	2011	RDAR					•	0	0		
V70 (08-)	2011	DABM			•	•	•	0	0		
V70 (08-)	2011	ICM					•	•	•		
V70 (08-)	2011	KVM		•		•	•	•	0		
V70 (08-)	2011	SAS						•	0		
V70 (08-)	2011	IAM				•	•	•	0		
V70 (08-)	2011	PBM					•	•	0		
V70 (08-)	2011	FLR		•		•	•	0	0		
V70 (08-)	2011	PSCM			•		•	•	0		
V70 (08-)	2011	MMM			•	•		0	0		
V70 (08-)	2011	PDM					•	•	0		
V70 (08-)	2011	POT		•		•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (08-)	2011	CCM		•	•	•	•	•	0		
V70 (08-)	2011	FSM		•	•	•	•	•	0		
V70 (08-)	2011	BCM		•	•	•	•	•	0		
V70 (08-)	2011	CEM		•	•	•	•	•	0		
V70 (08-)	2011	ECM	B6324S5	•	•	•	•	•	0		
V70 (08-)	2011	ECM	B6304T4	•	•	•	•	•	0		
V70 (08-)	2011	ECM	D5204T2	•	•	•	•	•	0		
V70 (08-)	2011	ECM	B4164T	•	•	•	•	•	0		
V70 (08-)	2011	ADM	D4164T	•	•	•	•	•	0		
V70 (08-)	2011	ECM	D4164T	•	•	•	•	•	0		
V70 (08-)	2011	PSCM	D4164T	•	•	•	•	•	0		
V70 (08-)	2011	ECM	B5254T11	•	•	•	•	•	•		
V70 (08-)	2011	ECM	B4204T6	•	•	•	•	•	0		
V70 (08-)	2011	ECM	D5244T10	•	•	•	•	•	0		
V70 (08-)	2011	ECM	B6324S4	•	•	•	•	•	0		
V70 (08-)	2011	TCM	MPS6	•	•	•	•	•	0		
V70 (08-)	2011	TCM	B4204S4/MPS6	•	•	•	•	•	0		
V70 (08-)	2011	TCM	TF-80SC	•	•	•	•	•	0		
V70 (08-)	2011	TCM	B5254T11/TF-80SC	•	•	•	•	•	0		
V70 (08-)	2011	DEM	TF-80SC AWD	•	•	•	•	•	•		
V70 (08-)	2011	TCM	TF-80SC AWD	•	•	•	•	•	0		
V70 (08-)	2011	TCM	D5244T10/TF-80SC	•	•	•	•	•	0		
V70 (08-)	2011	TCM	D5244T10/TF-80SC AWD	•	•	•	•	•	0		
V70 (08-)	2011	ECM	B4204T7	•	•	•	•	•	0		
V70 (08-)	2011	ECM	B5254T10	•	•	•	•	•	•		
V70 (08-)	2011	TCM	B5254T10/TF-80SC	•	•	•	•	•	0		
V60	2011	CPM		•	•	•	•	•	•		
V60	2011	SUM		•	•	•	•	•	•		
V60	2011	PAM		•	•	•	•	•	0		
V60	2011	PSM		•	•	•	•	•	•		
V60	2011	AUU		•	•	•	•	•	0		
V60	2011	PHM		•	•	•	•	•	0		
V60	2011	RDAR		•	•	•	•	0	0		
V60	2011	DABM		•	•	•	•	0	0		
V60	2011	HCM		•	•	•	•	•	0		
V60	2011	FLR		•	•	•	•	0	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V60	2011	CVM		•	•	•	•	0	0		
V60	2011	PSCM		•	•	•	•	•	0		
V60	2011	KVM		•	•	•	•	•	0		
V60	2011	IAM		•	•	•	•	•	0		
V60	2011	TRM		•	•	•	•	•	0		
V60	2011	SRS		•	•	•	•	•	0		
V60	2011	PDM		•	•	•	•	•	0		
V60	2011	CCM		•	•	•	•	•	0		
V60	2011	ICM		•	•	•	•	•	0		
V60	2011	SAS		•	•	•	•	•	0		
V60	2011	PAC		•	•	•	•	0	0		
V60	2011	AUD		•	•	•	•	0	0		
V60	2011	TVM		•	•	•	•	•	0		
V60	2011	FSM		•	•	•	•	•	0		
V60	2011	BCM		•	•	•	•	•	0		
V60	2011	CEM		•	•	•	•	•	0		
V60	2011	ECM	B4164T2	0	0	0	0	0	0		
V60	2011	ECM	B4204T6	•	•	•	•	•	0		
V60	2011	ECM	B4164T3	•	•	•	•	•	0		
V60	2011	ECM	B4164T	•	•	•	•	•	0		
V60	2011	ECM	D5204T2	•	•	•	•	•	0		
V60	2011	ECM	D5244T10	•	•	•	•	•	0		
V60	2011	ECM	B6304T4	•	•	•	•	•	0		
V60	2011	TCM	MPS6	•	•	•	•	•	0		
V60	2011	DEM	TF-80SC AWD	•	•	•	•	•	•		
V60	2011	ECM	B4204T7	•	•	•	•	•	0		
V60	2011	ECM	D4162T	•	•	•	•	•	0		
V60	2011	ECM	B5254T5	•	•	•	•	•	0		
V60	2011	DDM		•	•	•	•	•	0		
V50	2011	PSM		•	•	•	•	•	•		
V50	2011	AEM		•	•	•	•	•	•		
V50	2011	PAM		•	•	•	•	•	0		
V50	2011	AUD		•	•	•	•	0	0		
V50	2011	SRS		•	•	•	•	•	0		
V50	2011	DDM		•	•	•	•	•	•		
V50	2011	PDM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2011	AUU		•	•	•	•	•	0		
V50	2011	TRM		•	•	•	•	•	0		
V50	2011	SWM		•	•	•	•	•	0		
V50	2011	IAM		•	•	•	•	•	•		
V50	2011	SUB		•	•	•	•	0	0		
V50	2011	BCM		•	•	•	•	•	0		
V50	2011	RDAR		•	•	•	•	•	0		
V50	2011	KVM		•	•	•	•	•	•		
V50	2011	ICM		•	•	•	•	•	•		
V50	2011	HCM		•	•	•	•	•	0		
V50	2011	CPM		•	•	•	•	•	•		
V50	2011	BPM		•	•	•	•	•	0		
V50	2011	EPS		•	•	•	•	•	0		
V50	2011	MMM		•	•	•	•	•	•		
V50	2011	PHM		•	•	•	•	•	0		
V50	2011	CCM		•	•	•	•	•	0		
V50	2011	SAS	D5204T	•	•	•	•	•	0		
V50	2011	HCM	D5204T	•	•	•	•	•	0		
V50	2011	BCM	D5204T	•	•	•	•	•	•		
V50	2011	EPS	D5204T	•	•	•	•	•	0		
V50	2011	ECM	D5204T	•	•	•	•	•	0		
V50	2011	ECM	B4204S4	•	•	•	•	•	•		
V50	2011	ECM	B4164S3	•	•	•	•	•	•		
V50	2011	ECM	B4204S3	•	•	•	•	•	•		
V50	2011	TCM	MPS6	•	•	•	•	•	0		
V50	2011	ECM	B5254T7	•	•	•	•	•	•		
V50	2011	TCM	AW55-50/51SN	•	•	•	•	•	•		
V50	2011	SAS	D4162T	•	•	•	•	•	0		
V50	2011	HCM	D4162T	•	•	•	•	•	0		
V50	2011	BCM	D4162T	•	•	•	•	•	•		
V50	2011	EPS	D4162T	•	•	•	•	•	0		
V50	2011	ECM	D4162T	•	•	•	•	•	0		
V50	2011	ADM	D4164T	•	•	•	•	•	0		
V50	2011	ECM	D4164T	•	•	•	•	•	•		
V50	2011	SAS	D5204T5	•	•	•	•	•	0		
V50	2011	HCM	D5204T5	•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2011	BCM	D5204T5	•	•	•	•	•	•		
V50	2011	EPS	D5204T5	•	•	•	•	•	0		
V50	2011	ECM	D5204T5	•	•	•	•	•	0		
S80L	2011	DDM		•	•	•	•	•	0		
S80L	2011	CPM		•	•	•	•	•	•		
S80L	2011	AUD		•	•	•	•	0	0		
S80L	2011	SUM		•	•	•	•	•	•		
S80L	2011	HCM		•	•	•	•	•	0		
S80L	2011	PAM		•	•	•	•	•	0		
S80L	2011	HLDF		•	•	•	•	•	0		
S80L	2011	TRM		•	•	•	•	•	0		
S80L	2011	PSM		•	•	•	•	•	•		
S80L	2011	AUU		•	•	•	•	•	0		
S80L	2011	PBM		•	•	•	•	•	0		
S80L	2011	PHM		•	•	•	•	•	0		
S80L	2011	SRS		•	•	•	•	•	0		
S80L	2011	BPM		•	•	•	•	•	0		
S80L	2011	PAC		•	•	•	•	•	0		
S80L	2011	RDAR		•	•	•	•	0	0		
S80L	2011	DABM		•	•	•	•	0	0		
S80L	2011	ICM		•	•	•	•	•	•		
S80L	2011	KVM		•	•	•	•	•	0		
S80L	2011	SAS		•	•	•	•	•	0		
S80L	2011	IAM		•	•	•	•	•	0		
S80L	2011	FLR		•	•	•	•	0	0		
S80L	2011	PSCM		•	•	•	•	•	0		
S80L	2011	MMM		•	•	•	•	0	0		
S80L	2011	PDM		•	•	•	•	•	0		
S80L	2011	CCM		•	•	•	•	•	0		
S80L	2011	FSM		•	•	•	•	•	0		
S80L	2011	BCM		•	•	•	•	•	0		
S80L	2011	CEM		•	•	•	•	•	0		
S80L	2011	ECM	B6304T4	•	•	•	•	•	0		
S80L	2011	ECM	B4204T6	•	•	•	•	•	0		
S80L	2011	TCM	MPS6	•	•	•	•	•	0		
S80L	2011	DEM	TF-80SC AWD	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80L	2011	ECM	B4204T7	•	•	•	•	•	0		
S80 (07-)	2011	DDM		•	•	•	•	•	0		
S80 (07-)	2011	CPM		•	•	•	•	•	•		
S80 (07-)	2011	AUD		•	•	•	•	0	0		
S80 (07-)	2011	SUM		•	•	•	•	•	•		
S80 (07-)	2011	HCM		•	•	•	•	•	0		
S80 (07-)	2011	PAM		•	•	•	•	•	0		
S80 (07-)	2011	HLDF		•	•	•	•	•	0		
S80 (07-)	2011	TRM		•	•	•	•	•	0		
S80 (07-)	2011	PSM		•	•	•	•	•	•		
S80 (07-)	2011	AUU		•	•	•	•	•	0		
S80 (07-)	2011	SRS		•	•	•	•	•	0		
S80 (07-)	2011	PHM		•	•	•	•	•	0		
S80 (07-)	2011	BPM		•	•	•	•	•	0		
S80 (07-)	2011	PAC		•	•	•	•	•	0		
S80 (07-)	2011	RDAR		•	•	•	•	0	0		
S80 (07-)	2011	DABM		•	•	•	•	0	0		
S80 (07-)	2011	ICM		•	•	•	•	•	•		
S80 (07-)	2011	KVM		•	•	•	•	•	0		
S80 (07-)	2011	SAS		•	•	•	•	•	0		
S80 (07-)	2011	IAM		•	•	•	•	•	0		
S80 (07-)	2011	PBM		•	•	•	•	•	0		
S80 (07-)	2011	FLR		•	•	•	•	0	0		
S80 (07-)	2011	PSCM		•	•	•	•	•	0		
S80 (07-)	2011	MMM		•	•	•	•	0	0		
S80 (07-)	2011	PDM		•	•	•	•	•	0		
S80 (07-)	2011	CCM		•	•	•	•	•	0		
S80 (07-)	2011	FSM		•	•	•	•	•	0		
S80 (07-)	2011	BCM		•	•	•	•	•	0		
S80 (07-)	2011	CEM		•	•	•	•	•	0		
S80 (07-)	2011	ECM	B5254T8	•	•	•	•	•	•		
S80 (07-)	2011	ECM	B6324S4	•	•	•	•	•	0		
S80 (07-)	2011	ECM	B6324S5	•	•	•	•	•	0		
S80 (07-)	2011	ECM	B6304T4	•	•	•	•	•	0		
S80 (07-)	2011	ECM	B5254T11	•	•	•	•	•	•		
S80 (07-)	2011	ECM	B8444S	•	•	•	•	•	0	<u> </u>	



NOTES:

This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2011	ECM	B4204T6	•	•	•	•	•	0		
S80 (07-)	2011	ADM	D4164T	•	•	•	•	•	0		
S80 (07-)	2011	ECM	D4164T	•	•	•	•	•	0		
S80 (07-)	2011	PSCM	D4164T	•	•	•	•	•	0		
S80 (07-)	2011	ECM	D5244T10	•	•	•	•	•	0		
S80 (07-)	2011	ECM	D5204T2	•	•	•	•	•	0		
S80 (07-)	2011	ECM	B4164T	•	•	•	•	•	0		
S80 (07-)	2011	TCM	MPS6	•	•	•	•	•	0		
S80 (07-)	2011	TCM	B4204S4/MPS6	•	•	•	•	•	0		
S80 (07-)	2011	DEM	TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2011	TCM	B8444S/TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2011	ECM	B4204T7	•	•	•	•	•	0		
S80 (07-)	2011	ECM	B5254T10	•	•	•	•	•	•		
S60 (11-)	2011	CPM		•	•	•	•	•	•		
S60 (11-)	2011	SUM		•	•	•	•	•	•		
S60 (11-)	2011	PAM		•	•	•	•	•	0		
S60 (11-)	2011	PSM		•	•	•	•	•	•		
S60 (11-)	2011	AUU		•	•	•	•	•	0		
S60 (11-)	2011	PHM		•	•	•	•	•	0		
S60 (11-)	2011	RDAR		•	•	•	•	0	0		
S60 (11-)	2011	DABM		•	•	•	•	0	0		
S60 (11-)	2011	HCM		•	•	•	•	•	0		
S60 (11-)	2011	FLR		•	•	•	•	0	0		
S60 (11-)	2011	CVM		•	•	•	•	0	0		
S60 (11-)	2011	PSCM		•	•	•	•	•	0		
S60 (11-)	2011	KVM		•	•	•	•	•	0		
S60 (11-)	2011	IAM		•	•	•	•	•	0		
S60 (11-)	2011	TRM		•	•	•	•	•	0		
S60 (11-)	2011	SRS		•	•	•	•	•	0		
S60 (11-)	2011	PDM		•	•	•	•	•	0		
S60 (11-)	2011	CCM		•	•	•	•	•	0		
S60 (11-)	2011	ICM		•	•	•	•	•	0		
S60 (11-)	2011	SAS		•	•	•	•	•	0		
S60 (11-)	2011	PAC		•	•	•	•	0	0		
S60 (11-)	2011	AUD		•	•	•	•	0	0		
S60 (11-)	2011	TVM		•	•	•	•	•	0		



NOTES:

• This function is supported. X This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60 (11-)	2011	FSM		•	•	•	•	•	0	i direction	
S60 (11-)	2011	BCM		•	•	•	•	•	0		
S60 (11-)	2011	CEM		•	•	•	•	•	0		
S60 (11-)	2011	ECM	B4164T2	0	0	0	0	0	0		
S60 (11-)	2011	ECM	B4204T6	•	•	•	•	•	0		
S60 (11-)	2011	ECM	B4164T3	•	•	•	•	•	0		
S60 (11-)	2011	ECM	B4164T	•	•	•	•	•	0		
S60 (11-)	2011	ECM	D5204T2	•	•	•	•	•	0		
S60 (11-)	2011	ECM	D5244T10	•	•	•	•	•	0		
S60 (11-)	2011	ECM	B6304T4	•	•	•	•	•	0		
S60 (11-)	2011	TCM	MPS6	•	•	•	•	•	0		
S60 (11-)	2011	DEM	TF-80SC AWD	•	•	•	•	•	•		
S60 (11-)	2011	ECM	B4204T7	•	•	•	•	•	0		
S60 (11-)	2011	ECM	D4162T	•	•	•	•	•	0		
S60 (11-)	2011	ECM	B5254T5	•	•	•	•	•	0		
S60 (11-)	2011	DDM		•	•	•	•	•	0		
S40 (04-)	2011	BCM		•	•	•	•	•	0		
S40 (04-)	2011	PSM		•	•	•	•	•	•		
S40 (04-)	2011	AEM		•	•	•	•	•	•		
S40 (04-)	2011	PAM		•	•	•	•	•	0		
S40 (04-)	2011	AUD		•	•	•	•	0	0		
S40 (04-)	2011	SRS		•	•	•	•	•	0		
S40 (04-)	2011	DDM		•	•	•	•	•	•		
S40 (04-)	2011	PDM		•	•	•	•	•	•		
S40 (04-)	2011	AUU		•	•	•	•	•	0		
S40 (04-)	2011	TRM		•	•	•	•	•	0		
S40 (04-)	2011	SWM		•	•	•	•	•	0		
S40 (04-)	2011	IAM		•	•	•	•	•	•		
S40 (04-)	2011	SUB		•	•	•	•	0	0		
S40 (04-)	2011	RDAR		•	•	•	•	•	0		
S40 (04-)	2011	KVM		•	•	•	•	•	•		
S40 (04-)	2011	ICM		•	•	•	•	•	•		
S40 (04-)	2011	HCM		•	•	•	•	•	0		
S40 (04-)	2011	CPM		•	•	•	•	•	•		
S40 (04-)	2011	BPM		•	•	•	•	•	0		
S40 (04-)	2011	EPS		•	•	•	•	•	0		



NOTES:

• This function is supported.
** This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2011	MMM		•	•	•	•	•	•		
S40 (04-)	2011	PHM		•	•	•	•	•	0		
S40 (04-)	2011	CCM		•	•	•	•	•	0		
S40 (04-)	2011	SAS	D5204T	•	•	•	•	•	0		
S40 (04-)	2011	HCM	D5204T	•	•	•	•	•	0		
S40 (04-)	2011	BCM	D5204T	•	•	•	•	•	•		
S40 (04-)	2011	EPS	D5204T	•	•	•	•	•	0		
S40 (04-)	2011	ECM	D5204T	•	•	•	•	•	0		
S40 (04-)	2011	ECM	B4204S4	•	•	•	•	•	•		
S40 (04-)	2011	ECM	B4164S3	•	•	•	•	•	•		
S40 (04-)	2011	ECM	B4204S3	•	•	•	•	•	•		
S40 (04-)	2011	TCM	MPS6	•	•	•	•	•	0		
S40 (04-)	2011	ECM	B5254T7	•	•	•	•	•	•		
S40 (04-)	2011	TCM	AW55-50/51SN	•	•	•	•	•	•		
S40 (04-)	2011	SAS	D4162T	•	•	•	•	•	0		
S40 (04-)	2011	HCM	D4162T	•	•	•	•	•	0		
S40 (04-)	2011	BCM	D4162T	•	•	•	•	•	•		
S40 (04-)	2011	EPS	D4162T	•	•	•	•	•	0		
S40 (04-)	2011	ECM	D4162T	•	•	•	•	•	0		
S40 (04-)	2011	ADM	D4164T	•	•	•	•	•	0		
S40 (04-)	2011	ECM	D4164T	•	•	•	•	•	•		
S40 (04-)	2011	SAS	D5204T5	•	•	•	•	•	0		
S40 (04-)	2011	HCM	D5204T5	•	•	•	•	•	0		
S40 (04-)	2011	BCM	D5204T5	•	•	•	•	•	•		
S40 (04-)	2011	EPS	D5204T5	•	•	•	•	•	0		
S40 (04-)	2011	ECM	D5204T5	•	•	•	•	•	0		
C70 (06-)	2011	BCM		•	•	•	•	•	0		
C70 (06-)	2011	AEM		•	•	•	•	•	•		
C70 (06-)	2011	EPS		•	•	•	•	•	0		
C70 (06-)	2011	PAM		•	•	•	•	•	0		
C70 (06-)	2011	AUD		•	•	•	•	0	0		
C70 (06-)	2011	DDM		•	•	•	•	•	•		
C70 (06-)	2011	PDM		•	•	•	•	•	•		
C70 (06-)	2011	PSL		•	•	•	•	•	0		
C70 (06-)	2011	PSR		•	•	•	•	•	0		
C70 (06-)	2011	AUU		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2011	TRM		•	•	•	•	•	0		
C70 (06-)	2011	SRS		•	•	•	•	•	0		
C70 (06-)	2011	SWM		•	•	•	•	•	0		
C70 (06-)	2011	IAM		•	•	•	•	•	•		
C70 (06-)	2011	SUB		•	•	•	•	0	0		
C70 (06-)	2011	RDAR		•	•	•	•	•	0		
C70 (06-)	2011	KVM		•	•	•	•	•	•		
C70 (06-)	2011	ICM		•	•	•	•	•	•		
C70 (06-)	2011	CRM		•	•	•	•	•	0		
C70 (06-)	2011	HCM		•	•	•	•	•	0		
C70 (06-)	2011	CPM		•	•	•	•	•	•		
C70 (06-)	2011	BPM		•	•	•	•	•	0		
C70 (06-)	2011	MMM		•	•	•	•	•	•		
C70 (06-)	2011	PHM		•	•	•	•	•	0		
C70 (06-)	2011	CCM		•	•	•	•	•	0		
C70 (06-)	2011	SAS	D5204T	•	•	•	•	•	0		
C70 (06-)	2011	HCM	D5204T	•	•	•	•	•	0		
C70 (06-)	2011	BCM	D5204T	•	•	•	•	•	•		
C70 (06-)	2011	EPS	D5204T	•	•	•	•	•	0		
C70 (06-)	2011	ECM	D5204T	•	•	•	•	•	0		
C70 (06-)	2011	ECM	B5254T7	•	•	•	•	•	•		
C70 (06-)	2011	TCM	AW55-50/51SN	•	•	•	•	•	•		
C70 (06-)	2011	SAS	D5204T5	•	•	•	•	•	0		
C70 (06-)	2011	HCM	D5204T5	•	•	•	•	•	0		
C70 (06-)	2011	BCM	D5204T5	•	•	•	•	•	•		
C70 (06-)	2011	EPS	D5204T5	•	•	•	•	•	0		
C70 (06-)	2011	ECM	D5204T5	•	•	•	•	•	0		
C30 Electric	2011	BCM		•	•	•	•	•	0		
C30 Electric	2011	AEM		•	•	•	•	•	•		
C30 Electric	2011	PAM		•	•	•	•	•	0		
C30 Electric	2011	AUD		•	•	•	•	0	0		
C30 Electric	2011	SRS		•	•	•	•	•	0		
C30 Electric	2011	DDM		•	•	•	•	•	•		
C30 Electric	2011	PDM		•	•	•	•	•	•		
C30 Electric	2011	AUU		•	•	•	•	•	0		
C30 Electric	2011	SWM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

				ECU		Clear	Freeze	Live	Active	Special	
Vehicle	Year	System	Туре	Info.	Read DTC	DTC	Frame	Data	Test	Function	Other
C30 Electric	2011	IAM		•	•	•	•	•	•		
C30 Electric	2011	RDAR		•	•	•	•	•	0		
C30 Electric	2011	KVM		•	•	•	•	•	•		
C30 Electric	2011	ICM		•	•	•	•	•	•		
C30 Electric	2011	HCM		•	•	•	•	•	0		
C30 Electric	2011	CPM		•	•	•	•	•	•		
C30 Electric	2011	BPM		•	•	•	•	•	0		
C30 Electric	2011	EPS		•	•	•	•	•	0		
C30 Electric	2011	MMM		•	•	•	•	•	•		
C30 Electric	2011	PHM		•	•	•	•	•	0		
C30 Electric	2011	CEM-HS		•	•	•	•	•	•		
C30 Electric	2011	CCM		•	•	•	•	•	0		
C30 Electric	2011	CEM		•	•	•	•	•	•		
C30	2011	BCM		•	•	•	•	•	0		
C30	2011	AEM		•	•	•	•	•	•		
C30	2011	PAM		•	•	•	•	•	0		
C30	2011	AUD		•	•	•	•	0	0		
C30	2011	SRS		•	•	•	•	•	0		
C30	2011	DDM		•	•	•	•	•	•		
C30	2011	PDM		•	•	•	•	•	•		
C30	2011	PSL		•	•	•	•	•	0		
C30	2011	PSR		•	•	•	•	•	0		
C30	2011	AUU		•	•	•	•	•	0		
C30	2011	TRM		•	•	•	•	•	0		
C30	2011	SWM		•	•	•	•	•	0		
C30	2011	IAM		•	•	•	•	•	•		
C30	2011	RDAR		•	•	•	•	•	0		
C30	2011	KVM		•	•	•	•	•	•		
C30	2011	ICM		•	•	•	•	•	•		
C30	2011	HCM		•	•	•	•	•	0		
C30	2011	CPM		•	•	•	•	•	•		
C30	2011	BPM		•	•	•	•	•	0		
C30	2011	EPS		•	•	•	•	•	0		
C30	2011	MMM		•	•	•	•	•	•		
C30	2011	PHM		•	•	•	•	•	0		
C30	2011	CCM		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2011	SAS	D5204T	•	•	•	•	•	0		
C30	2011	HCM	D5204T	•	•	•	•	•	0		
C30	2011	BCM	D5204T	•	•	•	•	•	•		
C30	2011	EPS	D5204T	•	•	•	•	•	0		
C30	2011	ECM	D5204T	•	•	•	•	•	0		
C30	2011	ECM	B5254T7	•	•	•	•	•	•		
C30	2011	ECM	B4204S3	•	•	•	•	•	•		
C30	2011	ECM	B4164S3	•	•	•	•	•	•		
C30	2011	ECM	B4204S4	•	•	•	•	•	•		
C30	2011	TCM	MPS6	•	•	•	•	•	0		
C30	2011	TCM	AW55-50/51SN	•	•	•	•	•	•		
C30	2011	SAS	D4162T	•	•	•	•	•	0		
C30	2011	HCM	D4162T	•	•	•	•	•	0		
C30	2011	BCM	D4162T	•	•	•	•	•	•		
C30	2011	EPS	D4162T	•	•	•	•	•	0		
C30	2011	ECM	D4162T	•	•	•	•	•	0		
C30	2011	ADM	D4164T	•	•	•	•	•	0		
C30	2011	ECM	D4164T	•	•	•	•	•	•		
C30	2011	SAS	D5204T5	•	•	•	•	•	0		
C30	2011	HCM	D5204T5	•	•	•	•	•	0		
C30	2011	BCM	D5204T5	•	•	•	•	•	•		
C30	2011	EPS	D5204T5	•	•	•	•	•	0		
C30	2011	ECM	D5204T5	•	•	•	•	•	0		
XC90	2010	GPS		•	•	•	•	•	0		
XC90	2010	SRS		•	•	•	•	•	0		
XC90	2010	PSM		•	•	•	•	•	•		
XC90	2010	SUB		0	0	0	0	0	0		
XC90	2010	DDM		•	•	•	•	•	•		
XC90	2010	PDM		•	•	•	•	•	•		
XC90	2010	AEM		•	•	•	•	•	•		
XC90	2010	AUD		•	•	•	•	0	0		
XC90	2010	REM		•	•	•	•	•	•		
XC90	2010	PAC		•	0	0	0	0	0		
XC90	2010	AUU		•	•	•	•	•	0		
XC90	2010	DIM		•	•	•	•	•	•		
XC90	2010	IAM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2010	PHM		•	•	•	•	•	0		
XC90	2010	RDAR		•	•	•	•	•	0		
XC90	2010	CCM		•	•	•	•	•	0		
XC90	2010	ICM		•	•	•	•	•	•		
XC90	2010	UEM		•	•	•	•	•	•		
XC90	2010	MMM		•	•	•	•	•	•		
XC90	2010	CPM		•	数据流	0	0	0	0		
XC90	2010	BCM	B6324S	•	•	•	•	•	•		
XC90	2010	CEM-HS	B6324S	0	0	0	0	0	0		
XC90	2010	SAS	B6324S	•	•	•	•	•	0		
XC90	2010	CEM	B6324S	•	•	•	•	•	•		
XC90	2010	HCM	B6324S	•	•	•	•	•	0		
XC90	2010	ECM	B6324S	0	0	0	0	0	0		
XC90	2010	CPM	B6324S	0	0	0	0	0	0		
XC90	2010	BCM	B5254T2	•	•	•	•	•	•		
XC90	2010	CEM	B5254T2	•	•	•	•	•	•		
XC90	2010	SAS	B5254T2	•	•	•	•	•	0		
XC90	2010	ECM	B5254T2	•	•	•	•	•	•		
XC90	2010	HCM	B5254T2	•	•	•	•	•	0		
XC90	2010	BCM	D5244T5	•	•	•	•	•	•		
XC90	2010	CEM	D5244T5	•	•	•	•	•	•		
XC90	2010	SAS	D5244T5	•	•	•	•	•	0		
XC90	2010	HCM	D5244T5	•	•	•	•	•	0		
XC90	2010	ECM	D5244T5	•	•	•	•	•	•		
XC90	2010	BCM	B8444S	•	•	•	•	•	•		
XC90	2010	CEM-HS	B8444S	0	0	0	0	0	0		
XC90	2010	SAS	B8444S	•	•	•	•	•	0		
XC90	2010	CEM	B8444S	•	•	•	•	•	•		
XC90	2010	HCM	B8444S	•	•	•	•	•	0		
XC90	2010	ECM	B8444S	•	•	•	•	•	0		
XC90	2010	CPM	B8444S	0	0	0	0	0	0		
XC90	2010	BCM	D5244T4	•	•	•	•	•	•		
XC90	2010	CEM	D5244T4	•	•	•	•	•	•		
XC90	2010	SAS	D5244T4	•	•	•	•	•	0		
XC90	2010	HCM	D5244T4	•	•	•	•	•	0		
XC90	2010	ECM	D5244T4	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2010	TCM	B8444S/TF-80SC AWD	•	•	•	•	•	•		
XC90	2010	DEM	B8444S/TF-80SC AWD	•	•	•	•	•	0		
XC90	2010	DEM	D5244T5/M66 AWD	•	•	•	•	•	0		
XC90	2010	TCM	D5244T5/TF-80SC AWD	•	•	•	•	•	•		
XC90	2010	DEM	D5244T5/TF-80SC AWD	•	•	•	•	•	0		
XC90	2010	DEM	D5244T4/M66 AWD	•	•	•	•	•	0		
XC90	2010	TCM	D5244T4/TF-80SC AWD	•	•	•	•	•	•		
XC90	2010	DEM	D5244T4/TF-80SC AWD	•	•	•	•	•	0		
XC90	2010	TCM	B5254T2/AW50/51 AWD	•	•	•	•	•	•		
XC90	2010	DEM	B5254T2/AW50/51 AWD	•	•	•	•	•	0		
XC90	2010	TCM	B6324S/TF-80SC	0	0	0	0	0	0		
XC90	2010	TCM	B6324S/TF-80SC AWD	0	0	0	0	0	0		
XC90	2010	DEM	B6324S/TF-80SC AWD	•	•	•	•	•	0		
XC70 (08-)	2010	CPM		•	•	•	•	•	•		
XC70 (08-)	2010	AUD		•	•	•	•	0	0		
XC70 (08-)	2010	SUM		•	•	•	•	•	•		
XC70 (08-)	2010	HCM		•	•	•	•	•	0		
XC70 (08-)	2010	DDM		•	•	•	•	•	•		
XC70 (08-)	2010	PDM		•	•	•	•	•	•		
XC70 (08-)	2010	PAM		•	•	•	•	•	0		
XC70 (08-)	2010	HLDF		•	•	•	•	•	0		
XC70 (08-)	2010	TRM		•	•	•	•	•	0		
XC70 (08-)	2010	POT		•	•	•	•	•	0		
XC70 (08-)	2010	PSM		•	•	•	•	•	•		
XC70 (08-)	2010	AUU		•	•	•	•	•	0		
XC70 (08-)	2010	PBM		•	•	•	•	•	0		
XC70 (08-)	2010	SRS		•	•	•	•	•	0		
XC70 (08-)	2010	FSM		•	•	•	•	•	0		
XC70 (08-)	2010	SUB		•	•	•	•	0	0		
XC70 (08-)	2010	BPM		•	•	•	•	•	0		
XC70 (08-)	2010	PAC		•	•	•	•	•	0		
XC70 (08-)	2010	BCM		•	•	•	•	•	•		
XC70 (08-)	2010	RDAR		•	•	•	•	0	0		
XC70 (08-)	2010	MMM		•	•	•	•	0	0		
XC70 (08-)	2010	DABM		•	•	•	•	0	0		
XC70 (08-)	2010	PHM		•	•	•	•	•	0		



NOTES:

• This function is supported.

** This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2010	ICM		•	•	•	•	•	•		
XC70 (08-)	2010	KVM		•	•	•	•	•	0		
XC70 (08-)	2010	SAS		•	•	•	•	•	0		
XC70 (08-)	2010	IAM		•	•	•	•	•	0		
XC70 (08-)	2010	CCM		•	•	•	•	•	0		
XC70 (08-)	2010	FLR		•	•	•	•	0	0		
XC70 (08-)	2010	CEM		•	•	•	•	•	0		
XC70 (08-)	2010	DEM	M66 AWD	•	•	•	•	•	•		
XC70 (08-)	2010	DEM	TF-80SC AWD	•	•	•	•	•	•		
XC70 (08-)	2010	ECM	B6304T2	•	•	•	•	•	0		
XC70 (08-)	2010	ECM	B6324S	•	•	•	•	•	0		
XC70 (08-)	2010	ECM	D5244T4	•	•	•	•	•	0		
XC70 (08-)	2010	TCM	B6304T2/TF-80SC AWD	•	•	•	•	•	•		
XC70 (08-)	2010	TCM	B6324S/TF-80SC AWD	•	•	•	•	•	•		
XC70 (08-)	2010	ECM	D5244T5	•	•	•	•	•	0		
XC70 (08-)	2010	ECM	D5244T10	•	•	•	•	•	0		
XC70 (08-)	2010	TCM	D5244T10/TF-80SC AWD	•	•	•	•	•	•		
XC70 (08-)	2010	ECM	D5244T14	•	•	•	•	•	0		
XC70 (08-)	2010	ECM	B6324S2	•	•	•	•	•	0		
XC70 (08-)	2010	TCM	B6324S2/TF-80SC AWD	•	•	•	•	•	•		
XC70 (08-)	2010	TCM	D5244T14/TF-80SC	•	•	•	•	•	•		
XC70 (08-)	2010	ECM	D5244T16	•	•	•	•	•	0		
XC70 (08-)	2010	TCM	D5244T16/TF-80SC AWD	•	•	•	•	•	•		
XC60	2010	CPM		•	•	•	•	•	•		
XC60	2010	AUD		•	•	•	•	0	0		
XC60	2010	SUM		•	•	•	•	•	•		
XC60	2010	DDM		•	•	•	•	•	•		
XC60	2010	PDM		•	•	•	•	•	•		
XC60	2010	TRM		•	•	•	•	•	0		
XC60	2010	PSM		•	•	•	•	•	•		
XC60	2010	AUU		•	•	•	•	•	0		
XC60	2010	PBM		•	•	•	•	•	0		
XC60	2010	FSM		•	•	•	•	•	0		
XC60	2010	SUB		•	•	•	•	0	0		
XC60	2010	CVM		•	•	•	•	0	0		
XC60	2010	BCM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC60	2010	HLDF		•	•	•	•	•	0		
XC60	2010	RDAR		•	•	•	•	0	0		
XC60	2010	HCM		•	•	•	•	•	0		
XC60	2010	BPM		•	•	•	•	•	0		
XC60	2010	MMM		•	•	•	•	0	0		
XC60	2010	DABM		•	•	•	•	0	0		
XC60	2010	SRS		•	•	•	•	•	0		
XC60	2010	POT		•	•	•	•	•	0		
XC60	2010	PHM		•	•	•	•	•	0		
XC60	2010	ICM		•	•	•	•	•	•		
XC60	2010	TVM		0	0	0	0	0	0		
XC60	2010	KVM		•	•	•	•	•	0		
XC60	2010	SAS		•	•	•	•	•	0		
XC60	2010	IAM		•	•	•	•	•	0		
XC60	2010	PAC		•	•	•	•	0	0		
XC60	2010	CCM		•	•	•	•	•	0		
XC60	2010	FLR		•	•	•	•	0	0		
XC60	2010	PAM		•	•	•	•	•	0		
XC60	2010	CEM		•	•	•	•	•	0		
XC60	2010	DEM	M66 AWD	•	•	•	•	•	•		
XC60	2010	ECM	D5244T4	•	•	•	•	•	0		
XC60	2010	DEM	TF-80SC AWD	•	•	•	•	•	•		
XC60	2010	ECM	B6304T2	•	•	•	•	•	•		
XC60	2010	ECM	D5244T5	•	•	•	•	•	0		
XC60	2010	TCM	B6304T2/TF-80SC AWD	•	•	•	•	•	•		
XC60	2010	ECM	B4204T6	•	•	•	•	•	0		
XC60	2010	TCM	MPS6	•	•	•	•	•	0		
XC60	2010	ECM	D5244T10	•	•	•	•	•	0		
XC60	2010	TCM	D5244T10/TF-80SC AWD	•	•	•	•	•	•		
XC60	2010	ECM	D5244T14	•	•	•	•	•	0		
XC60	2010	TCM	D5244T14/TF-80SC	•	•	•	•	•	•		
XC60	2010	ECM	B6324S	•	•	•	•	•	0		
XC60	2010	TCM	B6324S/TF-80SC AWD	•	•	•	•	•	•		
XC60	2010	ECM	B6324S2	•	•	•	•	•	0		
XC60	2010	TCM	B6324S2/TF-80SC AWD	•	•	•	•	•	•		
XC60	2010	ECM	D5244T16	•	•	•	•	•	0		



NOTES:

- This function is supported. ※ This function m
 - * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC60	2010	TCM	D5244T16/TF-80SC AWD	•	•	•	•	•	•		
XC60	2010	TCM	B6324S2/TF-80SC	•	•	•	•	•	•		
XC60	2010	TCM	B6324S/TF-80SC	•	•	•	•	•	•		
V70 (08-)	2010	CPM		•	•	•	•	•	•		
V70 (08-)	2010	AUD		•	•	•	•	0	0		
V70 (08-)	2010	SUM		•	•	•	•	•	•		
V70 (08-)	2010	HCM		•	•	•		•	0		
V70 (08-)	2010	DDM		•	•	•	•	•	•		
V70 (08-)	2010	PDM		•	•	•	•	•	•		
V70 (08-)	2010	PAM		•	•	•	•	•	0		
V70 (08-)	2010	HLDF		•	•	•	•	•	0		
V70 (08-)	2010	TRM		•	•	•	•	•	0		
V70 (08-)	2010	POT		•	•	•	•	•	0		
V70 (08-)	2010	PSM		•	•	•	•	•	•		
V70 (08-)	2010	AUU		•	•	•	•	•	0		
V70 (08-)	2010	PBM		•	•	•	•	•	0		
V70 (08-)	2010	SRS		•	•	•	•	•	0		
V70 (08-)	2010	FSM		•	•	•	•	•	0		
V70 (08-)	2010	SUB		•	•	•	•	0	0		
V70 (08-)	2010	BPM		•	•	•	•	•	0		
V70 (08-)	2010	PAC		•	•	•	•	•	0		
V70 (08-)	2010	BCM		•	•	•	•	•	•		
V70 (08-)	2010	RDAR		•	•	•	•	0	0		
V70 (08-)	2010	MMM		•	•	•	•	0	0		
V70 (08-)	2010	DABM		•	•	•	•	0	0		
V70 (08-)	2010	PHM		•	•	•	•	•	0		
V70 (08-)	2010	ICM		•	•	•	•	•	•		
V70 (08-)	2010	KVM		•	•	•	•	•	0		
V70 (08-)	2010	SAS		•	•	•	•	•	0		
V70 (08-)	2010	IAM		•	•	•	•	•	0		
V70 (08-)	2010	CCM		•	•	•	•	•	0		
V70 (08-)	2010	FLR		•	•	•	•	0	0		
V70 (08-)	2010	CEM		•	•	•	•	•	0		
V70 (08-)	2010	ECM	D5244T4	•	•	•	•	•	0		
V70 (08-)	2010	ECM	B6304T2	•	•	•	•	•	0		
V70 (08-)	2010	ECM	B5254T6	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (08-)	2010	ECM	B6324S	•	•	•	•	•	0		
V70 (08-)	2010	ECM	B5254T8	•	•	•	•	•	•		
V70 (08-)	2010	ECM	D4204T	•	•	•	•	•	0		
V70 (08-)	2010	DEM	TF-80SC AWD	•	•	•	•	•	•		
V70 (08-)	2010	TCM	MPS6	•	•	•	•	•	0		
V70 (08-)	2010	DEM	M66 AWD	•	•	•	•	•	•		
V70 (08-)	2010	TCM	B6304T2/TF-80SC AWD	•	•	•	•	•	•		
V70 (08-)	2010	TCM	B6324S/TF-80SC AWD	•	•	•	•	•	•		
V70 (08-)	2010	TCM	B6324S/TF-80SC	•	•	•	•	•	•		
V70 (08-)	2010	TCM	B4204S4/MPS6	•	•	•	•	•	0		
V70 (08-)	2010	ECM	B4204T6	•	•	•	•	•	0		
V70 (08-)	2010	ECM	D5244T10	•	•	•	•	•	0		
V70 (08-)	2010	TCM	D5244T10/TF-80SC AWD	•	•	•	•	•	•		
V70 (08-)	2010	TCM	D5244T10/TF-80SC	•	•	•	•	•	•		
V70 (08-)	2010	ECM	D5244T14	•	•	•	•	•	0		
V70 (08-)	2010	TCM	D5244T14/TF-80SC	•	•	•	•	•	•		
V70 (08-)	2010	ECM	B6324S2	•	•	•	•	•	0		
V70 (08-)	2010	TCM	B6324S2/TF-80SC	•	•	•	•	•	•		
V70 (08-)	2010	ECM	D5244T5	•	•	•	•	•	0		
V70 (08-)	2010	PSCM	D4164T	•	•	•	•	•	0		
V70 (08-)	2010	ADM	D4164T	•	•	•	•	•	0		
V70 (08-)	2010	ECM	D4164T	•	•	•	•	•	0		
V70 (08-)	2010	ECM	B5254T11	•	•	•	•	•	•		
V70 (08-)	2010	TCM	B5254T11/TF-80SC	•	•	•	•	•	•		
V70 (08-)	2010	ECM	D5244T19	•	•	•	•	•	0		
V70 (08-)	2010	TCM	D5244T19/TF-80SC	•	•	•	•	•	•		
V70 (08-)	2010	ECM	B5254T10	•	•	•	•	•	•		
V70 (08-)	2010	TCM	B5254T10/TF-80SC	•	•	•	•	•	•		
V50	2010	PSM		•	•	•	•	•	•		
V50	2010	SUB		0	0	0	0	0	0		
V50	2010	AEM		•	•	•	•	•	•		
V50	2010	PAM		•	•	•	•	•	0		
V50	2010	AUD		•	•	•	•	0	0		
V50	2010	SRS		•	•	•	•	•	0		
V50	2010	DDM		•	•	•	•	•	•		
V50	2010	PDM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2010	AUU		•	•	•	•	•	0		
V50	2010	TRM		•	•	•	•	•	0		
V50	2010	SWM		•	•	•	•	•	0		
V50	2010	IAM		•	•	•	•	•	•		
V50	2010	BCM		•	•	•	•	•	0		
V50	2010	RDAR		•	•	•	•	•	0		
V50	2010	KVM		•	•	•	•	•	•		
V50	2010	BPM		•	•	•	•	•	0		
V50	2010	CPM		•	•	•	•	•	•		
V50	2010	ICM		•	•	•	•	•	•		
V50	2010	MMM		•	•	•	•	•	•		
V50	2010	PHM		•	•	•	•	•	0		
V50	2010	HCM		•	•	•	•	•	0		
V50	2010	CCM		•	•	•	•	•	0		
V50	2010	EPS		•	•	•	•	•	0		
V50	2010	TCM	AW55-50/51SN	•	•	•	•	•	•		
V50	2010	ECM	B4184S11	•	•	•	•	•	•		
V50	2010	ADM	D4164T	•	•	•	•	•	0		
V50	2010	ECM	D4164T	•	•	•	•	•	•		
V50	2010	ECM	D5244T8	•	•	•	•	•	•		
V50	2010	ECM	B5244S4	•	•	•	•	•	•		
V50	2010	ADM	D4204T	•	•	•	•	•	0		
V50	2010	ECM	D4204T	•	•	•	•	•	•		
V50	2010	ECM	D5244T9	•	•	•	•	•	•		
V50	2010	ECM	B4204S3	•	•	•	•	•	•		
V50	2010	ECM	B5254T7	•	•	•	•	•	•		
V50	2010	ECM	D5244T13	•	•	•	•	•	•		
V50	2010	TCM	MPS6	•	•	•	•	•	0		
V50	2010	ECM	B4164S3	•	•	•	•	•	•		
V50	2010	ECM	B4184S8	•	•	•	•	•	•		
V50	2010	DEM	AW50/51 AWD	•	•	•	•	•	0		
V50	2010	TCM	AW50/51 AWD	•	•	•	•	•	•		
V50	2010	DEM	M66 AWD	•	•	•	•	•	0		
V50	2010	ECM	B4204S3/MPS6	•	•	•	•	•	•		
V50	2010	ECM	D4204T/MPS6	•	•	•	•	•	•		
V50	2010	ECM	B4204S4	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2010	ECM	B5244S5	•		•	•	•	•		
V50	2010	ECM	B5244S7	•	•	•	•	•	•		
S80L	2010	CPM		•	•	•	•	•	•		
S80L	2010	AUD		•	•	•	•	0	0		
S80L	2010	SUM		•	•	•	•	•	•		
S80L	2010	HCM		•	•	•	•	•	0		
S80L	2010	DDM		•	•	•	•	•	•		
S80L	2010	PDM		•	•	•	•	•	•		
S80L	2010	PAM		•	•	•	•	•	0		
S80L	2010	HLDF		•	•	•	•	•	0		
S80L	2010	TRM		•	•	•	•	•	0		
S80L	2010	PSM		•	•	•	•	•	•		
S80L	2010	AUU		•	•	•	•	•	0		
S80L	2010	PBM		•	•	•	•	•	0		
S80L	2010	SRS		•	•	•	•	•	0		
S80L	2010	FSM		•	•	•	•	•	0		
S80L	2010	BPM		•	•	•	•	•	0		
S80L	2010	PAC		•	•	•	•	•	0		
S80L	2010	BCM		•	•	•	•	•	•		
S80L	2010	RDAR		•	•	•	•	0	0		
S80L	2010	MMM		•	•	•	•	0	0		
S80L	2010	DABM		•	•	•	•	0	0		
S80L	2010	PHM		•	•	•	•	•	0		
S80L	2010	ICM		•	•	•	•	•	•		
S80L	2010	KVM		•	•	•	•	•	0		
S80L	2010	SAS		•	•	•	•	•	0		
S80L	2010	IAM		•	•	•	•	•	0		
S80L	2010	CCM		•	•	•	•	•	0		
S80L	2010	FLR		•	•	•	•	0	0		
S80L	2010	CEM		•	•	•	•	•	0		
S80L	2010	TCM	TF-80SC	•		•	•	•	•		
S80L	2010	TCM	TF-80SC AWD	•	•	•	•	•	•		
S80L	2010	DEM	TF-80SC AWD	•	•	•	•	•	•		
S80L	2010	ECM	B6304T2	•	•	•	•	•	0		
S80L	2010	ECM	B5254T6	•	•	•	•	•	•		
S80L	2010	TCM	B6304T2/TF-80SC AWD	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80L	2010	TCM	B5254T6/TF-80SC	•	•	•	•	•	•		
S80L	2010	ECM	B4204T6	•	•	•	•	•	0		
S80L	2010	ECM	B6304T4	•	•	•	•	•	0		
S80L	2010	TCM	MPS6	•	•	•	•	•	0		
S80 (07-)	2010	CPM		•	•	•	•	•	•		
S80 (07-)	2010	AUD		•	•	•	•	0	0		
S80 (07-)	2010	SUM		•	•	•	•	•	•		
S80 (07-)	2010	HCM		•	•	•	•	•	0		
S80 (07-)	2010	DDM		•	•	•	•	•	•		
S80 (07-)	2010	PDM		•	•	•	•	•	•		
S80 (07-)	2010	PAM		•	•	•	•	•	0		
S80 (07-)	2010	HLDF		•	•	•	•	•	0		
S80 (07-)	2010	TRM		•	•	•	•	•	0		
S80 (07-)	2010	PSM		•	•	•	•	•	•		
S80 (07-)	2010	AUU		•	•	•	•	•	0		
S80 (07-)	2010	PBM		•	•	•	•	•	0		
S80 (07-)	2010	SRS		•	•	•	•	•	0		
S80 (07-)	2010	FSM		•	•	•	•	•	0		
S80 (07-)	2010	BPM		•	•	•	•	•	0		
S80 (07-)	2010	PAC		•	•	•	•	•	0		
S80 (07-)	2010	BCM		•	•	•	•	•	•		
S80 (07-)	2010	RDAR		•	•	•	•	0	0		
S80 (07-)	2010	MMM		•	•	•	•	0	0		
S80 (07-)	2010	DABM		•	•	•	•	0	0		
S80 (07-)	2010	PHM		•	•	•	•	•	0		
S80 (07-)	2010	ICM		•	•	•	•	•	•		
S80 (07-)	2010	KVM		•	•	•	•	•	0		
S80 (07-)	2010	SAS		•	•	•	•	•	0		
S80 (07-)	2010	IAM		•	•	•	•	•	0		
S80 (07-)	2010	DIM		•	•	•	•	•	0		
S80 (07-)	2010	CCM		•	•	•	•	•	0		
S80 (07-)	2010	FLR		•	•	•	•	0	0		
S80 (07-)	2010	CEM		•	•	•	•	•	0		
S80 (07-)	2010	ECM	D4204T	•	•	•	•	•	0		
S80 (07-)	2010	ECM	B5254T8	•	•	•	•	•	•		
S80 (07-)	2010	TCM	MPS6	•	•	•	•	•	0		



NOTES:

• This function is supported.

** This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2010	DEM	TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2010	DEM	M66 AWD	•	•	•	•	•	•		
S80 (07-)	2010	ECM	B8444S	•	•	•	•	•	0		
S80 (07-)	2010	ECM	B6304T2	•	•	•	•	•	0		
S80 (07-)	2010	ECM	B5254T6	•	•	•	•	•	•		
S80 (07-)	2010	ECM	B6324S	•	•	•	•	•	0		
S80 (07-)	2010	TCM	B5254T8/TF-80SC	•	•	•	•	•	•		
S80 (07-)	2010	TCM	B8444S/TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2010	TCM	B6304T2/TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2010	TCM	B6324S/TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2010	TCM	B6324S/TF-80SC	•	•	•	•	•	•		
S80 (07-)	2010	TCM	B4204S4/MPS6	•	•	•	•	•	0		
S80 (07-)	2010	ECM	B4204T6	•	•	•	•	•	0		
S80 (07-)	2010	ECM	D5244T10	•	•	•	•	•	0		
S80 (07-)	2010	TCM	D5244T10/TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2010	TCM	D5244T10/TF-80SC	•	•	•	•	•	•		
S80 (07-)	2010	ECM	D5244T14	•	•	•	•	•	0		
S80 (07-)	2010	TCM	D5244T14/TF-80SC	•	•	•	•	•	•		
S80 (07-)	2010	ECM	B6324S2	•	•	•	•	•	0		
S80 (07-)	2010	TCM	B6324S2/TF-80SC	•	•	•	•	•	•		
S80 (07-)	2010	ECM	D5244T5	•	•	•	•	•	0		
S80 (07-)	2010	PSCM	D4164T	•	•	•	•	•	0		
S80 (07-)	2010	ADM	D4164T	•	•	•	•	•	0		
S80 (07-)	2010	ECM	D4164T	•	•	•	•	•	0		
S80 (07-)	2010	ECM	B5254T11	•	•	•	•	•	•		
S80 (07-)	2010	TCM	B5254T11/TF-80SC	•	•	•	•	•	•		
S80 (07-)	2010	ECM	B5254T10	•	•	•	•	•	•		
S80 (07-)	2010	TCM	B5254T10/TF-80SC	•	•	•	•	•	•		
S80 (07-)	2010	ECM	D5244T19	•	•	•	•	•	0		
S80 (07-)	2010	TCM	D5244T19/TF-80SC	•	•	•	•	•	•		
S40 (04-)	2010	BCM		•	•	•	•	•	0		
S40 (04-)	2010	PSM		•	•	•	•	•	•		
S40 (04-)	2010	SUB		0	0	0	0	0	0		
S40 (04-)	2010	AEM		•	•	•	•	•	•		
S40 (04-)	2010	PAM		•	•	•	•	•	0		
S40 (04-)	2010	AUD		•	•	•	•	0	0		



NOTES:

• This function is supported.
** This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2010	SRS		•	•	•	•	•	0		
S40 (04-)	2010	DDM		•	•	•	•	•	•		
S40 (04-)	2010	PDM		•	•	•	•	•	•		
S40 (04-)	2010	AUU		•	•	•	•	•	0		
S40 (04-)	2010	TRM		•	•	•	•	•	0		
S40 (04-)	2010	SWM		•	•	•	•	•	0		
S40 (04-)	2010	IAM		•	•	•	•	•	•		
S40 (04-)	2010	RDAR		•	•	•	•	•	0		
S40 (04-)	2010	KVM		•	•	•	•	•	•		
S40 (04-)	2010	BPM		•	•	•	•	•	0		
S40 (04-)	2010	CPM		•	•	•	•	•	•		
S40 (04-)	2010	ICM		•	•	•	•	•	•		
S40 (04-)	2010	MMM		•	•	•	•	•	•		
S40 (04-)	2010	PHM		•	•	•	•	•	0		
S40 (04-)	2010	HCM		•	•	•	•	•	0		
S40 (04-)	2010	CCM		•	•	•	•	•	0		
S40 (04-)	2010	EPS		•	•	•	•	•	0		
S40 (04-)	2010	CEM		•	•	•	•	•	•		
S40 (04-)	2010	CEM-HS		•	•	•	•	•	•		
S40 (04-)	2010	ADM	D4164T	•	•	•	•	•	0		
S40 (04-)	2010	ECM	D4164T	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B4184S11	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B4204S3	•	•	•	•	•	•		
S40 (04-)	2010	ECM	D5244T9	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B5254T7	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B5244S4	•	•	•	•	•	•		
S40 (04-)	2010	ECM	D5244T8	•	•	•	•	•	•		
S40 (04-)	2010	ADM	D4204T	•	•	•	•	•	0		
S40 (04-)	2010	ECM	D4204T	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B4184S8	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B5244S7	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B4164S3	•	•	•	•	•	•		
S40 (04-)	2010	ECM	D5244T13	•	•	•	•	•	•		
S40 (04-)	2010	TCM	MPS6	•	•	•	•	•	0		
S40 (04-)	2010	DEM	AW50/51 AWD	•	•	•	•	•	0		
S40 (04-)	2010	TCM	AW50/51 AWD	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2010	DEM	M66 AWD	•	•	•	•	•	0		
S40 (04-)	2010	TCM	AW55-50/51SN	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B4204S3/MPS6	•	•	•	•	•	•		
S40 (04-)	2010	ECM	D4204T/MPS6	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B4204S4	•	•	•	•	•	•		
S40 (04-)	2010	ECM	B5244S5	•	•	•	•	•	•		
C70 (06-)	2010	BCM		•	•	•	•	•	0		
C70 (06-)	2010	AEM		•	•	•	•	•	•		
C70 (06-)	2010	EPS		•	•	•	•	•	0		
C70 (06-)	2010	PAM		•	•	•	•	•	0		
C70 (06-)	2010	AUD		•	•	•	•	0	0		
C70 (06-)	2010	DDM		•	•	•	•	•	•		
C70 (06-)	2010	PDM		•	•	•	•	•	•		
C70 (06-)	2010	PSL		•	•	•	•	•	0		
C70 (06-)	2010	PSR		•	•	•	•	•	0		
C70 (06-)	2010	AUU		•	•	•	•	•	0		
C70 (06-)	2010	TRM		•	•	•	•	•	0		
C70 (06-)	2010	SRS		•	•	•	•	•	0		
C70 (06-)	2010	SWM		•	•	•	•	•	0		
C70 (06-)	2010	IAM		•	•	•	•	•	•		
C70 (06-)	2010	SUB		•	•	•	•	0	0		
C70 (06-)	2010	RDAR		•	•	•	•	•	0		
C70 (06-)	2010	KVM		•	•	•	•	•	•		
C70 (06-)	2010	BPM		•	•	•	•	•	0		
C70 (06-)	2010	CPM		•	•	•	•	•	•		
C70 (06-)	2010	ICM		•	•	•	•	•	•		
C70 (06-)	2010	CRM		•	•	•	•	•	0		
C70 (06-)	2010	MMM		•	•	•	•	•	•		
C70 (06-)	2010	PHM		•	•	•	•	•	0		
C70 (06-)	2010	HCM		•	•	•	•	•	0		
C70 (06-)	2010	CCM		•	•	•	•	•	0		
C70 (06-)	2010	ECM	B5244S4	•	•	•	•	•	•		
C70 (06-)	2010	ECM	B5244S5	•	•	•	•	•	•		
C70 (06-)	2010	ECM	D5244T9	•	•	•	•	•	•		
C70 (06-)	2010	ECM	D5244T13	•	•	•	•	•	•		
C70 (06-)	2010	ECM	B5254T7	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2010	ADM	D4204T	•	•	•	•	•	0		
C70 (06-)	2010	ECM	D4204T	•	•	•	•	•	•		
C70 (06-)	2010	ECM	D5244T8	•	•	•	•	•	•		
C70 (06-)	2010	TCM	AW55-50/51SN	•	•	•	•	•	•		
C70 (06-)	2010	TCM	MPS6	•	•	•	•	•	0		
C70 (06-)	2010	ECM	D4204T/MPS6	•	•	•	•	•	•		
C30	2010	BCM		•	•	•	•	•	0		
C30	2010	AEM		•	•	•	•	•	•		
C30	2010	PAM		•	•	•	•	•	0		
C30	2010	AUD		•	•	•	•	0	0		
C30	2010	SRS		•	•	•	•	•	0		
C30	2010	DDM		•	•	•	•	•	•		
C30	2010	PDM		•	•	•	•	•	•		
C30	2010	PSL		•	•	•	•	•	0		
C30	2010	PSR		•	•	•	•	•	0		
C30	2010	AUU		•	•	•	•	•	0		
C30	2010	TRM		•	•	•	•	•	0		
C30	2010	SWM		•	•	•	•	•	0		
C30	2010	IAM		•	•	•	•	•	•		
C30	2010	RDAR		•	•	•	•	•	0		
C30	2010	KVM		•	•	•	•	•	•		
C30	2010	BPM		•	•	•	•	•	0		
C30	2010	CPM		•	•	•	•	•	•		
C30	2010	ICM		•	•	•	•	•	•		
C30	2010	MMM		•	•	•	•	•	•		
C30	2010	PHM		•	•	•	•	•	0		
C30	2010	HCM		•	•	•	•	•	0		
C30	2010	CCM		•	•	•	•	•	0		
C30	2010	EPS		•	•	•	•	•	0		
C30	2010	ECM	B4204S3	•	•	•	•	•	•		
C30	2010	ECM	D5244T9	•	•	•	•	•	•		
C30	2010	ADM	D4164T	•	•	•	•	•	0		
C30	2010	ECM	D4164T	•	•	•	•	•	•		
C30	2010	ECM	B4184S11	•	•	•	•	•	•		
C30	2010	ECM	D5244T13	•	•	•	•	•	•		
C30	2010	ECM	B5254T7	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	0ther
C30	2010	ECM	D5244T8	11110.		D 10	1.1 ame	Data	Test	Pulle CIOII	
C30	2010	ECM	B4184S8	•	•	•	•	•	•		
C30	2010	ECM	B4164S3	•	•	•	•	•	•		
C30	2010	ECM	B5244S4	•	•	•	•	•	•		
C30	2010	TCM	AW55-50/51SN	•	•	•	•	•	•		
C30	2010	TCM	MPS6	•	•	•	•	•	0		
C30	2010	ADM	D4204T	•	•	•	•	•	0		
C30	2010	ECM	D4204T	•	•	•	•	•	•		
C30	2010	ECM	B4204S3/MPS6	•	•	•	•	•	•		
C30	2010	ECM	D4204T/MPS6	•	•	•	•	•	•		
C30	2010	ECM	B4204S4	•	•	•	•	•	•		
XC90	2005	AEM	AEM	•	•	•	•	•	•		
XC90	2005	ATM	ATM	•	•	•	0	•	0		
XC90	2005	AUD	AUD	•	•	•	•	0	0		
XC90	2005	MP2	MP2	•	•	•	•	•	•		
XC90	2005	CEM	CEM	•	•	•	•	•	•	27, 28, 150, 151, 29, 30, 31, 32	Immobiliser(Live Data)
XC90	2005	DIM	DIM	•	•	•	•	•	•	33, 34, 35, 36, 37	
XC90	2005	ICM	ICM	•	•	•	•	•	•		
XC90	2005	MP1	MP1	•	•	•	•	•	•		
XC90	2005	MMM	MMM	•	•	•	•	0	0		
XC90	2005	PHM	PHM	•	•	•	•	•	0		
XC90	2005	REM	REM	•	•	•	•	•	•	39, 40	
XC90	2005	SAS	SAS	•	•	•	•	•	0		
XC90	2005	SAS	SAS	•	•	•	•	•	0		
XC90	2005	CCM	CCM	•	•	•	•	•	0	43, 44	
XC90	2005	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
XC90	2005	PDM	PDM	•	•	•	•	•	•	46, 47	
XC90	2005	PSM	PSM	•	•	•	•	•	•	48	
V70 (00-)	2005	Petrol	B5204T5	•	•	•	•	•	•	2, 3, 4, 5	
V70 (00-)	2005	Petrol	B5244S	•	•	•	•	•	•	88, 6	
V70 (00-)	2005	Petrol	B5244S2	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00–)	2005	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2005	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2005	Petrol	B5244T4	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (00-)	2005	Petrol	B5244T5	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
V70 (00-)	2005	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
V70 (00-)	2005	Petrol	B5254T4	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
V70 (00-)	2005	Diesel	D5244T	•	•	•	0	•	•	7	
V70 (00-)	2005	Diesel	D5244T2	•	•	•	0	•	•	7	
V70 (00-)	2005	Diesel	D5244T3	•	•	•	0	•	•	7	
V70 (00-)	2005	AEM	AEM	•	•	•	•	•	•		
V70 (00-)	2005	AUM	AUM	•	•	•	•	•	0		
V70 (00-)	2005	CEM	CEM	•	•	•	•	•	•	27, 28, 150, 151, 29, 30, 31, 32	
V70 (00-)	2005	DIM	DIM	•	•	•	•	•	•	33, 35, 36, 37	
V70 (00-)	2005	PHM	PHM	•	•	•	•	•	0		
V70 (00-)	2005	REM	REM	•	•	•	•	•	•	39, 40	
V70 (00-)	2005	RTI	RTI	•	•	•	•	0	0		
V70 (00-)	2005	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24, 25	
V70 (00-)	2005	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 (00-)	2005	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
V70 (00-)	2005	DEM	DEM	•	•	•	•	•	0	ĺ	
V70 (00-)	2005	DEM	DEM	•	•	•	•	•	0		
V70 (00-)	2005	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
V70 (00-)	2005	SAS	SAS	•	•	•	•	•	0		
V70 (00-)	2005	SUM	SUM	•	•	•	•	•	0		
V70 (00-)	2005	CCM	CCM	•	•	•	•	•	0	43, 44	
V70 (00-)	2005	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
V70 (00-)	2005	PDM	PDM	•	•	•	•	•	•	46	
V70 (00-)	2005	PSM	PSM	•	•	•	•	•	•	48	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-)	2005	SRS	SRS	•	•	•	•	•	0		
V70 XC(01-)/XC70	2005	Petrol	B5244T4	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 XC(01-)/XC70	2005	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
V70 XC(01-)/XC70	2005	Diesel	D5244T	•	•	•	0	•	•	7	
V70 XC(01-)/XC70	2005	AEM	AEM	•	•	•	•	•	•		
V70 XC(01-)/XC70	2005	AUM	AUM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2005	CEM	CEM	•	•	•	•	•	•	27, 28, 150, 151, 29, 30, 31, 32	
V70 XC(01-)/XC70	2005	DIM	DIM	•	•	•	•	•	•	33, 35, 36, 37	
V70 XC(01-)/XC70	2005	PHM	РНМ	•	•	•	•	•	0		
V70 XC(01-)/XC70	2005	REM	REM	•	•	•	•	•	•	39, 40	
V70 XC(01-)/XC70	2005	RTI	RTI	•	•	•	•	0	0		
V70 XC(01-)/XC70	2005	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24, 25	
V70 XC(01-)/XC70	2005	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 XC(01-)/XC70	2005	DEM	DEM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2005	DEM	DEM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2005	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
V70 XC(01-)/XC70	2005	SAS	SAS	•	•	•	•	•	0		
V70 XC(01-)/XC70	2005	SUM	SUM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2005	CCM	ССМ	•	•	•	•	•	0	43, 44	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70	2005	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
V70 XC(01-)/XC70	2005	PDM	PDM	•	•	•	•	•	•	46, 47	
V70 XC(01-)/XC70	2005	PSM	PSM	•	•	•	•	•	•	48	
V70 XC(01-)/XC70	2005	SRS	SRS	•	•	•	•	•	0		
V50	2005	Petrol	B4164S3	•	•	•	•	•	•		
V50	2005	Petrol	B4184S11	•	•	•	•	•	•		
V50	2005	Petrol	B5244S4	•	•	•	•	•	•	88, 6, 95	
V50	2005	Petrol	B5244S5	•	•	•	•	•	•	88, 6, 95	
V50	2005	Petrol	B5254T3	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
V50	2005	Diesel	D4164T	•	•	•	0	•	•	96, 97, 98, 99	
V50	2005	Diesel	D4204T	•	•	•	•	•	•	96, 100, 99, 97	
V50	2005	Diesel	D4204T2	•	•	•	•	•	•	96, 100, 99, 97	
V50	2005	AFM	AFM	•	•	•	•	•	0		
V50	2005	AEM	AEM	•	•	•	•	•	•		
V50	2005	AUD	AUD	•	•	•	•	0	0		
V50	2005	CEM	CEM	•	•	•	•	•	•	110, 27, 29, 31	
V50	2005	DIM	DIM	•	•	•	•	•	•	103, 35, 37, 104	
V50	2005	ICM	ICM	•	•	•	•	•	•		
V50	2005	IAM	IAM	•	•	•	•	•	•		
V50	2005	KVM	KVM	•	•	•	•	•	•		
V50	2005	MPM	MPM	•	•	•	•	•	•		
V50	2005	MMM	MMM	•	•	•	•	•	•		
V50	2005	PAM	PAM	•	•	•	•	•	0		
V50	2005	PHM	PHM	•	•	•	•	•	0		
V50	2005	SWM	SWM	•	•	•	0	•	0		
V50	2005	SUB	SUB	•	•	•	•	0	0		
V50	2005	TMC	TMC	•	•	•	•	•	0		
V50	2005	TCM	AW50/51AWD	•	•	•	•	•	•		
V50	2005	TCM	AW55-50/51SN	•	•	•	•	•	•		
V50	2005	ABS/BCM	ABS/BCM	•	•	•	•	•	•		
V50	2005	EPS	EPS	•	•	•	0	•	0		
V50	2005	CCM	CCM	•	•	•	•	•	0	44	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2005	DDM	DDM	•	•	•	0	•	•	46	
V50	2005	PDM	PDM	•	•	•	0	•	•	46	
V50	2005	PSM	PSM	•	•	•	•	•	•	109	
V50	2005	SRS	SRS	•	•	•	•	•	0		
V50	2005	TRM	TRM	•	•	•	•	•	0		
V50	2005	DEM	DEM	•	•	•	•	•	0		
V50	2005	GPS	GPS	•	•	•	•	•	0		
S80	2005	Petrol	B5204T5	•	•	•	•	•	•	2, 3, 4, 5	
S80	2005	Petrol	B5244S	•	•	•	•	•	•	88, 6	
S80	2005	Petrol	B5244S2	•	•	•	•	•	•		
S80	2005	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2005	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2005	Petrol	B5244T4	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80	2005	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
S80	2005	Petrol	B6294S2	•	•	•	•	•	•	2, 3, 4, 5	
S80	2005	Petrol	B6294T	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
S80	2005	Diesel	D5244T	•	•	•	0	•	•	7	
S80	2005	Diesel	D5244T2	•	•	•	0	•	•	7	
S80	2005	AEM	AEM	•	•	•	•	•	•		
S80	2005	AUM	AUM	•	•	•	•	•	0		
S80	2005	DIM	DIM	•	•	•	•	•	•	33, 35, 36, 37	
S80	2005	PHM	PHM	•	•	•	•	•	0		
S80	2005	REM	REM	•	•	•	•	•	•	39, 40	
S80	2005	RTI	RTI	•	•	•	•	0	0		
S80	2005	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24, 25	
S80	2005	TCM	4T65EV	•	•	•	•	•	•	10, 11	
S80	2005	TCM	4T65EV-GT	•	•	•	•	•	•	10, 11	
S80	2005	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S80	2005	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S80	2005	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2005	SAS	SAS	11110.	•	DIC ●	Гташе	рата	O	rune cron	
S80	2005	SUM	SUM	•	•			•	0		
S80	2005	CCM	CCM	•	•	•	•	•	0	43, 44	
S80	2005	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
S80	2005	PDM	PDM	•	•	•	•	•	•	46	
S80	2005	PSM	PSM	•	•	•	•	•	•	48	
S80	2005	SRS	SRS	•	•	•	•	•	0		
S80	2005	CEM	СЕМ	•	•	•	•	•	•	27, 28, 150, 151, 29, 30, 31, 32	
S60	2005	CEM	CEM	•	•	•	•	•	•	27, 28, 150, 151, 29, 30, 31, 32	
S60	2005	Petrol	B5204T5	•	•	•	•	•	•	2, 3, 4, 5	
S60	2005	Petrol	B5244S	•	•	•	•	•	•	88, 6	
S60	2005	Petrol	B5244S2	•	•	•	•	•	•		
S60	2005	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec.Ident.; Block DTC
S60	2005	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec.Ident.; Block DTC
S60	2005	Petrol	B5244T4	•	•	•	•	•	•	1, 2, 3, 4, 5	
S60	2005	Petrol	B5244T5	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
S60	2005	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
S60	2005	Petrol	B5254T4	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
S60	2005	Diesel	D5244T	•	•	•	0	•	•	7	
S60	2005	Diesel	D5244T2	•	•	•	0	•	•	7	
S60	2005	Diesel	D5244T3	•	•	•	0	•	•	7	
S60	2005	AEM	AEM	•	•	•	•	•	•		
S60	2005	AUM	AUM	•	•	•	•	•	0		
S60	2005	DIM	DIM	•	•	•	•	•	•	33, 35, 36, 37	
S60	2005	PHM	PHM	•	•	•	•	•	0		
S60	2005	REM	REM	•	•	•	•	•	•	39, 40	
S60	2005	RTI	RTI	•	•	•	•	0	0		
S60	2005	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24, 25	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2005	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S60	2005	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S60	2005	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
S60	2005	SAS	SAS	•	•	•	•	•	0		
S60	2005	SUM	SUM	•	•	•	•	•	0		
S60	2005	CCM	CCM	•	•	•	•	•	0	43, 44	
S60	2005	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
S60	2005	PDM	PDM	•	•	•	•	•	•	46, 47	
S60	2005	PSM	PSM	•	•	•	•	•	•	48	
S60	2005	SRS	SRS	•	•	•	•	•	0		
S60	2005	DEM	DEM	•	•	•	•	•	0		
S60	2005	DEM	DEM	•	•	•	•	•	0		
S40 (04-)	2005	CEM	CEM	•	•	•	•	•	•	110, 27, 29, 31	
S40 (04-)	2005	Petrol	B4164S3	•	•	•	•	•	•		
S40 (04-)	2005	Petrol	B4184S11	•	•	•	•	•	•		
S40 (04-)	2005	Petrol	B5244S4	•	•	•	•	•	•	88, 6, 95	
S40 (04-)	2005	Petrol	B5244S5	•	•	•	•	•	•	88, 6, 95	
S40 (04-)	2005	Petrol	B5254T3	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
S40 (04-)	2005	Diesel	D4164T	•	•	•	0	•	•	96, 97, 98, 99	
S40 (04-)	2005	Diesel	D4204T	•	•	•	•	•	•	96, 100, 99, 97	
S40 (04-)	2005	Diesel	D4204T2	•	•	•	•	•	•	96, 100, 99, 97	
S40 (04-)	2005	AFM	AFM	•	•	•	•	•	0		
S40 (04-)	2005	AEM	AEM	•	•	•	•	•	•		
S40 (04-)	2005	AUD	AUD	•	•	•	•	0	0		
S40 (04-)	2005	DEM	DEM	•	•	•	•	•	0		
S40 (04-)	2005	DIM	DIM	•	•	•	•	•	•	103, 35, 37, 104	
S40 (04-)	2005	ICM	ICM	•	•	•	•	•	•		
S40 (04-)	2005	IAM	IAM	•	•	•	•	•	•		
S40 (04-)	2005	KVM	KVM	•	•	•	•	•	•		
S40 (04-)	2005	MPM	MPM	•	•	•	•	•	•		
S40 (04-)	2005	MMM	MMM	•	•	•	•	•	•		
S40 (04-)	2005	PAM	PAM	•	•	•	•	•	0		
S40 (04-)	2005	PHM	PHM	•	•	•	•	•	0		
S40 (04-)	2005	SWM	SWM	•	•	•	0	•	0		
S40 (04-)	2005	SUB	SUB	•	•	•	•	0	0		



NOTES:

• This function is supported.

imes This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2005	TMC	TMC	•	•	•	•	•	0		
S40 (04-)	2005	TCM	AW50/51AWD	•	•	•	•	•	•		
S40 (04-)	2005	TCM	AW55-50/51SN	•	•	•	•	•	•		
S40 (04-)	2005	ABS/BCM	ABS/BCM	•	•	•	•	•	•		
S40 (04-)	2005	EPS	EPS	•	•	•	0	•	0		
S40 (04-)	2005	CCM	CCM	•	•	•	•	•	0	44	
S40 (04-)	2005	DDM	DDM	•	•	•	0	•	•	46	
S40 (04-)	2005	PDM	PDM	•	•	•	0	•	•	46	
S40 (04-)	2005	PSM	PSM	•	•	•	•	•	•	109	
S40 (04-)	2005	SRS	SRS	•	•	•	•	•	0		
S40 (04-)	2005	TRM	TRM	•	•	•	•	•	0		
S40 (04-)	2005	GPS	GPS	•	•	•	•	•	0		
C70 Conv	2005	Petrol	B5204T4	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2005	Petrol	B5234T9	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2005	Petrol	B5244T7	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2005	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Conv	2005	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Conv	2005	RTI	RTI	•	•	•	0	•	•		
C70 Conv	2005	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Conv	2005	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Conv	2005	Cab control system	Cab control system	•	•	•	0	•	0		
C70 Conv	2005	CCM	CCM	•	•	•	0	•	0		
C70 Conv	2005	CPM	CPM	•	•	•	0	•	0		
C70 Conv	2005	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
C70 Conv	2005	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Conv	2005	Rollover protection	Rollover protection	•	•	•	0	•	•		
C70 Conv	2005	SRS	SRS	•	•	•	0	•	0		
XC90	2004	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	
XC90	2004	Petrol	B6294T	•	•	•	•	•	•	1, 2, 3, 4, 50	
XC90	2004	Diesel	D5244T	•	•	•	0	•	•	7	
XC90	2004	AEM	AEM	•	•	•	•	•	•		
XC90	2004	ATM	ATM	•	•	•	0	•	0		
XC90	2004	AUD	AUD	•	•	•	•	0	0		
XC90	2004	MP2	MP2	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2004	CEM	СЕМ	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
XC90	2004	DIM	DIM	•	•	•	•	•	•	33, 34, 35, 36, 37	
XC90	2004	ICM	ICM	•	•	•	•	•	•		
XC90	2004	MP1	MP1	•	•	•	•	•	•		
XC90	2004	MMM	MMM	•	•	•	•	0	0		
XC90	2004	PHM	PHM	•	•	•	•	0	0		
XC90	2004	REM	REM	•	•	•	•	•	•	55	
XC90	2004	SWM	SWM	•	•	•	•	•	0		
XC90	2004	SUB	SUB	•	•	•	•	0	0		
XC90	2004	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
XC90	2004	TCM	4T65AWD	•	•	•	•	•	•	10, 11	
XC90	2004	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
XC90	2004	DEM	DEM	•	•	•	0	•	0		
XC90	2004	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
XC90	2004	SAS	SAS	•	•	•	0	•	0		
XC90	2004	CCM	ССМ	•	•	•	•	•	0	41, 56, 56, 58	
XC90	2004	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
XC90	2004	PDM	PDM	•	•	•	•	•	•	47, 59	
XC90	2004	PSM	PSM	•	•	•	•	•	•	48, 60	
XC90	2004	SRS	SRS	•	•	•	•	•	0		
V70 (00-)	2004	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2004	Petrol	B5234T3	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2004	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2004	Petrol	B5244S	•	•	•	•	•	•	88, 6	
V70 (00-)	2004	Petrol	B5244S2	•	•	•	•	•	•		
V70 (00-)	2004	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2004	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2004	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2004	Petrol	B5254T4	•	•	•	•	•	•	1, 2, 3, 4, 5, 50	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-)	2004	Diesel	D5244T	•	•	•	0	•	•	7	
V70 (00-)	2004	Diesel	D5244T2	•	•	•	0	•	•	7	
V70 (00-)	2004	AEM	AEM	•	•	•	•	•	•		
V70 (00-)	2004	AUM	AUM	•	•	•	•	•	0		
V70 (00-)	2004	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70 (00-)	2004	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
V70 (00-)	2004	PHM	PHM	•	•	•	•	•	0		
V70 (00-)	2004	REM	REM	•	•	•	•	•	•	55	
V70 (00-)	2004	RTI	RTI	•	•	•	•	0	0		
V70 (00-)	2004	SWM	SWM	•	•	•	•	•	0		
V70 (00-)	2004	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 (00-)	2004	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 (00-)	2004	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
V70 (00-)	2004	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
V70 (00-)	2004	SAS	SAS	•	•	•	0	•	0		
V70 (00-)	2004	SUM	SUM	•	•	•	•	•	0		
V70 (00-)	2004	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
V70 (00-)	2004	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
V70 (00-)	2004	PDM	PDM	•	•	•	•	•	•	47, 59	
V70 (00-)	2004	PSM	PSM	•	•	•	•	•	•	48, 60	
V70 (00-)	2004	SRS	SRS	•	•	•	•	•	0		
V70 (00-)	2004	DEM	DEM	•	•	•	0	•	0		
V70 (00-)	2004	DEM	DEM	•	•	•	0	•	0		
V70 XC(01-)/XC70	2004	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 XC(01-)/XC70	2004	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 XC(01-)/XC70	2004	Diesel	D5244T	•	•	•	0	•	•	7	
V70 XC(01-)/XC70	2004	AEM	AEM	•	•	•	•	•	•		
V70 XC(01-)/XC70	2004	AUM	AUM	•	•	•	•	•	0		
V70 XC (01-) /XC70	2004	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live



NOTES:

- This function is supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70	2004	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
V70 XC(01-)/XC70	2004	PHM	РНМ	•	•	•	•	•	0		
V70 XC(01-)/XC70	2004	REM	REM	•	•	•	•	•	•	55	
V70 XC(01-)/XC70	2004	RTI	RTI	•	•	•	•	0	0		
V70 XC(01-)/XC70	2004	SWM	SWM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2004	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 XC(01-)/XC70	2004	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 XC(01-)/XC70	2004	DEM	DEM	•	•	•	0	•	0		
V70 XC(01-)/XC70	2004	DEM	DEM	•	•	•	0	•	0		
V70 XC(01-)/XC70	2004	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
V70 XC(01-)/XC70	2004	SAS	SAS	•	•	•	0	•	0		
V70 XC(01-)/XC70	2004	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
V70 XC(01-)/XC70	2004	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
V70 XC(01-)/XC70	2004	PDM	PDM	•	•	•	•	•	•	47, 59	
V70 XC(01-)/XC70	2004	PSM	PSM	•	•	•	•	•	•	48, 60	
V70 XC(01-)/XC70	2004	SRS	SRS	•	•	•	•	•	0		
V50	2004	Petrol	B5244S4	•	•	•	•	•	•	88, 6, 95	
V50	2004	Petrol	B5244S5	•	•	•	•	•	•	88, 6, 95	
V50	2004	Petrol	B5254T3	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
V50	2004	Diesel	D4204T	•	•	•	•	•	•	96, 100, 97	
V50	2004	Diesel	D4204T2	•	•	•	•	•	•	96, 100, 97	
V50	2004	AFM	AFM	•	•	•	•	•	0		
V50	2004	AEM	AEM	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	0ther
V50	2004	AUD	AUD	•	•	•	•	0	0		
V50	2004	CEM	CEM	•	•	•	0	•	•	110, 27	
V50	2004	DIM	DIM	•	•	•	•	•	•	103, 35, 37, 104	
V50	2004	ICM	ICM	•	•	•	•	•	•		
V50	2004	MPM	MPM	•	•	•	•	•	•		
V50	2004	MMM	MMM	•	•	•	•	•	•		
V50	2004	PHM	PHM	•	•	•	•	•	0		
V50	2004	SWM	SWM	•	•	•	0	•	0		
V50	2004	SUB	SUB	•	•	•	•	0	0		
V50	2004	TMC	TMC	•	•	•	•	•	0		
V50	2004	TCM	AW55-50/51SN	•	•	•	•	•	•		
V50	2004	ABS/BCM	ABS/BCM	•	•	•	•	•	•		
V50	2004	CCM	CCM	•	•	•	•	•	0	44	
V50	2004	DDM	DDM	•	•	•	0	•	•	46, 109	
V50	2004	PDM	PDM	•	•	•	0	•	•	46	
V50	2004	PSM	PSM	•	•	•	•	•	•	109	
V50	2004	SRS	SRS	•	•	•	•	•	0		
V50	2004	TRM	TRM	•	•	•	•	•	0		
V50	2004	EPS	EPS	•	•	•	0	•	0		
V50	2004	GPS	GPS	•	•	•	•	•	0		
V40	2004	Petrol	B4164S2	•	•	•	0	•	•	113, 1	
V40	2004	Petrol	B4184S10	•	•	•	0	•	•	113, 1	
V40	2004	Petrol	B4184S2	•	•	•	0	•	•	113, 1	
V40	2004	Petrol	B4184S3	•	•	•	0	•	•	113, 1	
V40	2004	Petrol	B4184S9	•	•	•	0	•	•	113, 1	
V40	2004	Petrol	B4184SJ	•	•	•	0	•	•	117	
V40	2004	Petrol	B4204S2	•	•	•	0	•	•	113, 1	
V40	2004	Petrol	B4204T3	•	•	•	0	•	•	118, 1	
V40	2004	Diesel	D4192T3(Anti-spin system)	•	•	•	0	•	•		
V40	2004	Diesel	D4192T4(Anti-spin system)	•	•	•	0	•	•		
V40	2004	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
V40	2004	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 126	2
V40	2004	Gas discharge light module	Gas discharge light module	•	•	•	0	•	•		
V40	2004	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V40	2004	TCM	AW55-50/51SN	•	•	•	0	•	•	130, 131	
V40	2004	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	2004	CCM	CCM	•	•	•	0	•	•	132, 133, 81	
V40	2004	CPM	CPM	•	•	•	0	•	0	21	
V40	2004	SRS	SRS	•	•	•	0	•	0		
S80	2004	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2004	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2004	Petrol	B5244S	•	•	•	•	•	•	6	
S80	2004	Petrol	B5244S2	•	•	•	•	•	•		
S80	2004	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2004	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2004	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2004	Petrol	B6294S2	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2004	Petrol	B6294T	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2004	Diesel	D5244T	•	•	•	0	•	•	7	
S80	2004	Diesel	D5244T2	•	•	•	0	•	•	7	
S80	2004	AEM	AEM	•	•	•	•	•	•		
S80	2004	AUM	AUM	•	•	•	•	•	0		
S80	2004	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
S80	2004	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S80	2004	PHM	PHM	•	•	•	•	•	0		
S80	2004	REM	REM	•	•	•	•	•	•	55	
S80	2004	RTI	RTI	•	•	•	•	0	0		
S80	2004	SWM	SWM	•	•	•	•	•	0		
S80	2004	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S80	2004	TCM	4T65EV	•	•	•	•	•	•	10, 11	
S80	2004	TCM	4T65EV-GT	•	•	•	•	•	•	10, 11	
S80	2004	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S80	2004	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S80	2004	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU	Read DTC	Clear	Freeze	Live	Active	Special	Other
				Info.	Read DIC	DTC	Frame	Data	Test	Function	Other
S80	2004	SAS	SAS	•	•	•	0	•	0		
S80	2004	SUM	SUM	•	•	•	•	•	0		
S80	2004	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S80	2004	DDM	DDM	•	•	•	•	•	•	47, 59	
S80	2004	PDM	PDM	•	•	•	•	•	•	59	
S80	2004	PSM	PSM	•	•	•	•	•	•	48, 60	
S80	2004	SRS	SRS	•	•	•	•	•	0		
S60	2004	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	
S60	2004	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 4, 50	
S60	2004	Petrol	B5234T3	•	•	•	•	•	•	1, 2, 3, 4, 50	
S60	2004	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
S60	2004	Petrol	B5244S	•	•	•	•	•	•	88, 6	
S60	2004	Petrol	B5244S2	•	•	•	•	•	•	6	
S60	2004	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec.Ident.; Block DTC
S60	2004	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec.Ident.; Block DTC
S60	2004	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	
S60	2004	Petrol	B5254T4	•	•	•	•	•	•	1, 2, 3, 4, 5, 50	
S60	2004	Diesel	D5244T	•	•	•	0	•	•	7	
S60	2004	Diesel	D5244T2	•	•	•	0	•	•	7	
S60	2004	AEM	AEM	•	•	•	•	•	•		
S60	2004	AUM	AUM	•	•	•	•	•	0		
S60	2004	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S60	2004	PHM	PHM	•	•	•	•	•	0		
S60	2004	REM	REM	•	•	•	•	•	•	55	
S60	2004	RTI	RTI	•	•	•	•	0	0		
S60	2004	SWM	SWM	•	•	•	•	•	0		
S60	2004	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S60	2004	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S60	2004	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S60	2004	DEM	DEM	•	•	•	0	•	0		
S60	2004	DEM	DEM	•	•	•	0	•	0		
S60	2004	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	



NOTES:

- This function is supported.
 ** This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2004	SAS	SAS	•	•	•	0	•	0		
S60	2004	SUM	SUM	•	•	•	•	•	0		
S60	2004	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S60	2004	DDM	DDM	•	•	•	•	•	•	47, 48, 59	
S60	2004	PDM	PDM	•	•	•	•	•	•	47, 59	
S60	2004	PSM	PSM	•	•	•	•	•	•	48, 60	
S60	2004	SRS	SRS	•	•	•	•	•	0		
S40 (04-)	2004	CEM	CEM	•	•	•	0	•	•	110, 27	
S40 (04-)	2004	EPS	EPS	•	•	•	0	•	0		
S40 (04-)	2004	Petrol	B5244S4	•	•	•	•	•	•	88, 6, 95	
S40 (04-)	2004	Petrol	B5244S5	•	•	•	•	•	•	88, 6, 95	
S40 (04-)	2004	Petrol	B5254T3	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
S40 (04-)	2004	Diesel	D4204T	•	•	•	•	•	•	96, 100, 97	
S40 (04-)	2004	Diesel	D4204T2	•	•	•	•	•	•	96, 100, 97	
S40 (04-)	2004	AFM	AFM	•	•	•	•	•	0		
S40 (04-)	2004	AEM	AEM	•	•	•	•	•	•		
S40 (04-)	2004	AUD	AUD	•	•	•	•	0	0		
S40 (04-)	2004	DIM	DIM	•	•	•	•	•	•	103, 35, 37, 104	
S40 (04-)	2004	ICM	ICM	•	•	•	•	•	•		
S40 (04-)	2004	MPM	MPM	•	•	•	•	•	•		
S40 (04-)	2004	MMM	MMM	•	•	•	•	•	•		
S40 (04-)	2004	PHM	PHM	•	•	•	•	•	0		
S40 (04-)	2004	SWM	SWM	•	•	•	0	•	0		
S40 (04-)	2004	SUB	SUB	•	•	•	•	0	0		
S40 (04-)	2004	TMC	TMC	•	•	•	•	•	0		
S40 (04-)	2004	TCM	AW55-50/51SN	•	•	•	•	•	•		
S40 (04-)	2004	ABS/BCM	ABS/BCM	•	•	•	•	•	•		
S40 (04-)	2004	CCM	CCM	•	•	•	•	•	0	44	
S40 (04-)	2004	DDM	DDM	•	•	•	0	•	•	46, 109	
S40 (04-)	2004	PDM	PDM	•	•	•	0	•	•	46	
S40 (04-)	2004	PSM	PSM	•	•	•	•	•	•	109	
S40 (04-)	2004	SRS	SRS	•	•	•	•	•	0		
S40 (04-)	2004	TRM	TRM	•	•	•	•	•	0		
S40 (04-)	2004	GPS	GPS	•	•	•	•	•	0		
S40 (-04)	2004	Petrol	B4164S2	•	•	•	0	•	•	113, 1	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU	Read DTC	Clear	Freeze	Live	Active	Special	Other
	Tear			Info.	Read DIC	DTC	Frame	Data	Test	Function	Other
S40 (-04)	2004	Petrol	B4184S10	•	•	•	0	•	•	113, 1	
S40 (-04)	2004	Petrol	B4184S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2004	Petrol	B4184S3	•	•	•	0	•	•	113, 1	
S40 (-04)	2004	Petrol	B4184S9	•	•	•	0	•	•	113, 1	
S40 (-04)	2004	Petrol	B4184SJ	•	•	•	0	•	•	117	
S40 (-04)	2004	Petrol	B4204S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2004	Petrol	B4204T3	•	•	•	0	•	•	118, 1	
S40 (-04)	2004	Diesel	D4192T3(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2004	Diesel	D4192T4(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2004	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
S40 (-04)	2004	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 12 6	
S40 (-04)	2004	Gas discharge light module	Gas discharge light module	•	•	•	0	•	•		
S40 (-04)	2004	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
S40 (-04)	2004	TCM	AW55-50/51SN	•	•	•	0	•	•	130, 131	
S40 (-04)	2004	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S40 (-04)	2004	CCM	CCM	•	•	•	0	•	0	132, 133, 81	
S40 (-04)	2004	CPM	CPM	•	•	•	0	•	0	21	
S40 (-04)	2004	SRS	SRS	•	•	•	0	•	0		
C70 Conv	2004	Petrol	B5204T4	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2004	Petrol	B5234T9	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2004	Petrol	B5244T7	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2004	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Conv	2004	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Conv	2004	RTI	RTI	•	•	•	0	•	•		
C70 Conv	2004	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Conv	2004	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Conv	2004	Cab control system	Cab control system	•	•	•	0	•	0		
C70 Conv	2004	CCM	CCM	•	•	•	0	•	0		
C70 Conv	2004	CPM	CPM	•	•	•	0	•	0		
C70 Conv	2004	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
C70 Conv	2004	Power seat module, right	Power seat module, right	•	•	•	0	•	•		_
C70 Conv	2004	Rollover protection	Rollover protection	•	•	•	0	•	•		
C70 Conv	2004	SRS	SRS	•	•	•	0	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2003	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	
XC90	2003	Petrol	B6294T	•	•	•	•	•	•	1, 2, 3, 4, 50	
XC90	2003	Diesel	D5244T	•	•	•	0	•	•	7	
XC90	2003	AEM	AEM	•	•	•	•	•	•		
XC90	2003	ATM	ATM	•	•	•	0	•	0		
XC90	2003	AUD	AUD	•	•	•	•	0	0		
XC90	2003	MP2	MP2	•	•	•	•	•	•		
XC90	2003	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
XC90	2003	DIM	DIM	•	•	•	•	•	•	33, 34, 35, 36, 37	
XC90	2003	ICM	ICM	•	•	•	•	•	•		
XC90	2003	MP1	MP1	•	•	•	•	•	•		
XC90	2003	MMM	MMM	•	•	•	•	0	0		
XC90	2003	PHM	PHM	•	•	•	•	•	0		
XC90	2003	REM	REM	•	•	•	•	•	•	55	
XC90	2003	SWM	SWM	•	•	•	•	•	0		
XC90	2003	SUB	SUB	•	•	•	•	0	0		
XC90	2003	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
XC90	2003	TCM	4T65AWD	•	•	•	•	•	•	10, 11	
XC90	2003	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
XC90	2003	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
XC90	2003	SAS	SAS	•	•	•	0	•	0		
XC90	2003	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
XC90	2003	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
XC90	2003	PDM	PDM	•	•	•	•	•	•	47, 59	
XC90	2003	PSM	PSM	•	•	•	•	•	•	48, 60	
XC90	2003	SRS	SRS	•	•	•	•	•	0		
XC90	2003	DEM	DEM	•	•	•	0	•	0		
V70 (00-)	2003	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2003	Petrol	B5234T3	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2003	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2003	Petrol	B5244S	•	•	•	•	•	•	88, 6	
V70 (00-)	2003	Petrol	B5244S2	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-)	2003	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2003	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2003	Petrol	B5244T3	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2003	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2003	Diesel	D5244T	•	•	•	0	•	•	7	
V70 (00-)	2003	Diesel	D5244T2	•	•	•	0	•	•	7	
V70 (00-)	2003	AEM	AEM	•	•	•	•	•	•		
V70 (00-)	2003	AUM	AUM	•	•	•	•	•	0		
V70 (00-)	2003	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70 (00-)	2003	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
V70 (00-)	2003	PHM	PHM	•	•	•	•	•	0		
V70 (00-)	2003	REM	REM	•	•	•	•	•	•	55	
V70 (00-)	2003	RTI	RTI	•	•	•	•	0	0		
V70 (00-)	2003	SWM	SWM	•	•	•	•	•	0		
V70 (00-)	2003	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 (00-)	2003	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 (00-)	2003	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
V70 (00-)	2003	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
V70 (00-)	2003	SAS	SAS	•	•	•	0	•	0		
V70 (00-)	2003	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
V70 (00-)	2003	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
V70 (00-)	2003	PDM	PDM	•	•	•	•	•	•	47, 59	
V70 (00-)	2003	PSM	PSM	•	•	•	•	•	•	48, 60	
V70 (00-)	2003	SRS	SRS	•	•	•	•	•	0		
V70 (00-)	2003	DEM	DEM	•	•	•	0	•	0		
V70 XC(01-)/XC70	2003	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 XC(01-)/XC70	2003	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	



NOTES:

- This function is supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70	2003	Diesel	D5244T	•	•	•	0	•	•	7	
V70 XC(01-)/XC70	2003	AEM	AEM	•	•	•	•	•	•		
V70 XC(01-)/XC70	2003	AUM	AUM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2003	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70 XC(01-)/XC70	2003	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
V70 XC(01-)/XC70	2003	PHM	РНМ	•	•	•	•	•	0		
V70 XC(01-)/XC70	2003	REM	REM	•	•	•	•	•	•	55	
V70 XC(01-)/XC70	2003	RTI	RTI	•	•	•	•	0	0		
V70 XC(01-)/XC70	2003	SWM	SWM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2003	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 XC(01-)/XC70	2003	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 XC(01-)/XC70	2003	DEM	DEM	•	•	•	0	•	0		
V70 XC(01-)/XC70	2003	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
V70 XC(01-)/XC70	2003	SAS	SAS	•	•	•	0	•	0		
V70 XC(01-)/XC70	2003	CCM	ССМ	•	•	•	•	•	0	41, 56, 56, 58	
V70 XC(01-)/XC70	2003	DDM	DDM	•	•	•	•	•	•	46, 47, 48	
V70 XC(01-)/XC70	2003	PDM	PDM	•	•	•	•	•	•	47, 59	
V70 XC (01-) /XC70	2003	PSM	PSM	•	•	•	•	•	•	48, 60	
V70 XC(01-)/XC70	2003	SRS	SRS	•	•	•	•	•	0		
V40	2003	Petrol	B4164S2	•	•	•	0	•	•	113, 1	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V40	2003	Petrol	B4184S10	•	•	•	0	•	•	113, 1	
V40	2003	Petrol	B4184S2	•	•	•	0	•	•	113, 1	
V40	2003	Petrol	B4184S3	•	•	•	0	•	•	113, 1	
V40	2003	Petrol	B4184S9	•	•	•	0	•	•	113, 1	
V40	2003	Petrol	B4184SJ	•	•	•	0	•	•	117	
V40	2003	Petrol	B4204S2	•	•	•	0	•	•	113, 1	
V40	2003	Petrol	B4204T3	•	•	•	0	•	•	118, 1	
V40	2003	Petrol	B4204T5	•	•	•	0	•	•	118, 1	
V40	2003	Diesel	D4192T3(Anti-spin system)	•	•	•	0	•	0		
V40	2003	Diesel	D4192T4(Anti-spin system)	•	•	•	0	•	0		
V40	2003	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
V40	2003	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 12 6	
V40	2003	Gas discharge light module	Gas discharge light module	•	•	•	0	•	•		
V40	2003	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
V40	2003	TCM	AW55-50/51SN	•	•	•	0	•	•	130, 131	
V40	2003	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	2003	CCM	CCM	•	•	•	0	•	•	132, 133, 81	
V40	2003	CPM	CPM	•	•	•	0	•	0	21	
V40	2003	SRS	SRS	•	•	•	0	•	0		
S80	2003	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	
S80	2003	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2003	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2003	Petrol	B5244S	•	•	•	•	•	•	6	
S80	2003	Petrol	B5244S2	•	•	•	•	•	•		
S80	2003	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2003	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2003	Petrol	B5244T3	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2003	Petrol	B6294S2	•	•	•	•	•	•	1, 2, 3, 4, 50	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2003	Petrol	B6294T	•	•	•	•	•	•	1, 2, 3, 4, 50	
S80	2003	Diesel	D5244T	•	•	•	0	•	•	7	
S80	2003	Diesel	D5244T2	•	•	•	0	•	•	7	
S80	2003	AEM	AEM	•	•	•	•	•	•		
S80	2003	AUM	AUM	•	•	•	•	•	0		
S80	2003	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S80	2003	PHM	PHM	•	•	•	•	•	0		
S80	2003	REM	REM	•	•	•	•	•	•	55	
S80	2003	RTI	RTI	•	•	•	•	0	0		
S80	2003	SWM	SWM	•	•	•	•	•	0		
S80	2003	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S80	2003	TCM	4T65EV	•	•	•	•	•	•	10, 11	
S80	2003	TCM	4T65EV-GT	•	•	•	•	•	•	10, 11	
S80	2003	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S80	2003	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S80	2003	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
S80	2003	SAS	SAS	•	•	•	0	•	0		
S80	2003	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S80	2003	DDM	DDM	•	•	•	•	•	•	47, 59	
S80	2003	PDM	PDM	•	•	•	•	•	•	59	
S80	2003	PSM	PSM	•	•	•	•	•	•	48, 60	
S80	2003	SRS	SRS	•	•	•	•	•	0		
S60	2003	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	
S60	2003	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 4, 50	
S60	2003	Petrol	B5234T3	•	•	•	•	•	•	1, 2, 3, 4, 50	
S60	2003	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
S60	2003	Petrol	B5244S	•	•	•	•	•	•	88, 6	
S60	2003	Petrol	B5244S2	•	•	•	•	•	•		
S60	2003	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec.Ident.; Block DTC
S60	2003	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec.Ident.; Block DTC
S60	2003	Petrol	B5244T3	•	•	•	•	•	•	1, 2, 3, 4, 50	
S60	2003	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 50	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2003	Diesel	D5244T	•	•	•	0	•	•	7	
S60	2003	Diesel	D5244T2	•	•	•	0	•	•	7	
S60	2003	AEM	AEM	•	•	•	•	•	•		
S60	2003	AUM	AUM	•	•	•	•	•	0		
S60	2003	DEM	DEM	•	•	•	0	•	0		
S60	2003	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S60	2003	PHM	PHM	•	•	•	•	•	0		
S60	2003	REM	REM	•	•	•	•	•	•	55	
S60	2003	RTI	RTI	•	•	•	•	0	0		
S60	2003	SWM	SWM	•	•	•	•	•	0		
S60	2003	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S60	2003	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S60	2003	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S60	2003	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
S60	2003	SAS	SAS	•	•	•	0	•	0		
S60	2003	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S60	2003	DDM	DDM	•	•	•	•	•	•	47, 48, 59	
S60	2003	PDM	PDM	•	•	•	•	•	•	47, 59	
S60	2003	PSM	PSM	•	•	•	•	•	•	48, 60	
S60	2003	SRS	SRS	•	•	•	•	•	0		
S40 (-04)	2003	Petrol	B4164S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2003	Petrol	B4184S10	•	•	•	0	•	•	113, 1	
S40 (-04)	2003	Petrol	B4184S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2003	Petrol	B4184S3	•	•	•	0	•	•	113, 1	
S40 (-04)	2003	Petrol	B4184S9	•	•	•	0	•	•	113, 1	
S40 (-04)	2003	Petrol	B4184SJ	•	•	•	0	•	•	117	
S40 (-04)	2003	Petrol	B4204S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2003	Petrol	B4204T3	•	•	•	0	•	•	118, 1	
S40 (-04)	2003	Petrol	B4204T5	•	•	•	0	•	•	118, 1	
S40 (-04)	2003	Diesel	D4192T3(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2003	Diesel	D4192T4(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2003	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
S40 (-04)	2003	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 12 6	
S40 (-04)	2003	Gas discharge light module	Gas discharge light module	•	•	•	0	•	•		
S40 (-04)	2003	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (-04)	2003	TCM	AW55-50/51SN	•	•	•	0	•	•	130, 131	
S40 (-04)	2003	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S40 (-04)	2003	CCM	CCM	•	•	•	0	•	•	132, 133, 81	
S40 (-04)	2003	CPM	CPM	•	•	•	0	•	0	21	
S40 (-04)	2003	SRS	SRS	•	•	•	0	•	0		
C70 Conv	2003	Petrol	B5204T4	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2003	Petrol	B5234T9	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2003	Petrol	B5244T7	•	•	•	•	•	•	1, 2, 3, 50	
C70 Conv	2003	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Conv	2003	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Conv	2003	RTI	RTI	•	•	•	0	•	•		
C70 Conv	2003	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Conv	2003	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Conv	2003	Cab control system	Cab control system	•	•	•	0	•	0		
C70 Conv	2003	CCM	CCM	•	•	•	0	•	0		
C70 Conv	2003	CPM	CPM	•	•	•	0	•	0		
C70 Conv	2003	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
C70 Conv	2003	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Conv	2003	Rollover protection	Rollover protection	•	•	•	0	•	•		
C70 Conv	2003	SRS	SRS	•	•	•	0	•	0		
V70 (00-)	2002	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 50	
V70 (00-)	2002	Petrol	B5234T3	•	•	•	•	•	•	1, 2, 3, 50	
V70 (00-)	2002	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 4, 50	
V70 (00-)	2002	Petrol	B5244S	•	•	•	•	•	•	88, 6, 89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2002	Petrol	B5244S2	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2002	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-)	2002	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2002	Petrol	B5244T3	•	•	•	•	•	•	1, 2, 3, 50	
V70 (00-)	2002	Diesel	D5244T	•	•	•	0	•	•	90, 7	
V70 (00-)	2002	Diesel	D5244T2	•	•	•	0	•	•	90, 7	
V70 (00-)	2002	AEM	AEM	•	•	•	•	•	•		
V70 (00-)	2002	AUM	AUM	•	•	•	•	•	0		
V70 (00-)	2002	CEM	СЕМ	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70 (00-)	2002	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
V70 (00-)	2002	PHM	PHM	•	•	•	•	•	0		
V70 (00-)	2002	REM	REM	•	•	•	•	•	•	55	
V70 (00-)	2002	RTI	RTI	•	•	•	•	0	0		
V70 (00-)	2002	SWM	SWM	•	•	•	•	•	0		
V70 (00-)	2002	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 (00-)	2002	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 (00-)	2002	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
V70 (00-)	2002	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
V70 (00-)	2002	SAS	SAS	•	•	•	0	•	0		
V70 (00-)	2002	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
V70 (00-)	2002	DDM	DDM	•	•	•	•	•	•	59	
V70 (00-)	2002	PDM	PDM	•	•	•	•	•	•	59	
V70 (00-)	2002	PSM	PSM	•	•	•	•	•	•	48, 60	
V70 (00-)	2002	SRS	SRS	•	•	•	•	•	0		
V70 XC(01-)/XC70	2002	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 50	
V70 XC(01-)/XC70	2002	Petrol	B5244T3	•	•	•	•	•	•	1, 2, 3, 50	
V70 XC(01-)/XC70	2002	AEM	AEM	•	•	•	•	•	•		
V70 XC(01-)/XC70	2002	AUM	AUM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2002	CEM	СЕМ	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70 XC(01-)/XC70	2002	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70	2002	РНМ	РНМ	•	•	•	•	•	0		
V70 XC(01-)/XC70	2002	REM	REM	•	•	•	•	•	•	55	
V70 XC(01-)/XC70	2002	RTI	RTI	•	•	•	•	0	0		
V70 XC(01-)/XC70	2002	SWM	SWM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2002	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 XC(01-)/XC70	2002	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 XC(01-)/XC70	2002	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
V70 XC(01-)/XC70	2002	SAS	SAS	•	•	•	0	•	0		
V70 XC(01-)/XC70	2002	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
V70 XC(01-)/XC70	2002	DDM	DDM	•	•	•	•	•	•	59	
V70 XC(01-)/XC70	2002	PDM	PDM	•	•	•	•	•	•	59	
V70 XC(01-)/XC70	2002	PSM	PSM	•	•	•	•	•	•	48, 60	
V70 XC(01-)/XC70	2002	SRS	SRS	•	•	•	•	•	0		
V40	2002	Petrol	B4164S2	•	•	•	0	•	•	113, 1	
V40	2002	Petrol	B4184S10	•	•	•	0	•	•	113, 1	
V40	2002	Petrol	B4184S2	•	•	•	0	•	•	113, 1	
V40	2002	Petrol	B4184S3	•	•	•	0	•	•	113, 1	
V40	2002	Petrol	B4184S9	•	•	•	0	•	•	113, 1	
V40	2002	Petrol	B4184SJ	•	•	•	0	•	•	117	
V40	2002	Petrol	B4204S2	•	•	•	0	•	•	113, 1	
V40	2002	Petrol	B4204T3	•	•	•	0	•	•	118, 1	
V40	2002	Petrol	B4204T5	•	•	•	0	•	•	118, 1	
V40	2002	Diesel	D4192T3 (Anti-spin system)	•	•	•	0	•	0		
V40	2002	Diesel	D4192T4(Anti-spin system)	•	•	•	0	•	0		
V40	2002	Anti-spin system	Anti-spin system	•	•	•	0	•	0		



NOTES:

• This function is supported.

imes This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V40	2002	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 12 6	
V40	2002	Gas discharge light module	Gas discharge light module	•	•	•	0	•	•		
V40	2002	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
V40	2002	TCM	AW55-50/51SN	•	•	•	0	•	•	130, 131	
V40	2002	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	2002	CCM	CCM	•	•	•	0	•	•	132, 133, 81	
V40	2002	CPM	CPM	•	•	•	0	•	0	21	
V40	2002	SRS	SRS	•	•	•	0	•	0		
S80	2002	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	
S80	2002	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 50	
S80	2002	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 50	
S80	2002	Petrol	B5244S	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.; Block DTC
S80	2002	Petrol	B5244S2	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.; Block DTC
S80	2002	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2002	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2002	Petrol	B5244T3	•	•	•	•	•	•	1, 2, 3, 50	
S80	2002	Petrol	B6294S2	•	•	•	•	•	•	1, 2, 4, 50	
S80	2002	Petrol	B6294T	•	•	•	•	•	•	1, 2, 4, 50	
S80	2002	Diesel	D5244T	•	•	•	0	•	•	90, 7	
S80	2002	Diesel	D5244T2	•	•	•	0	•	•	90, 7	
S80	2002	AEM	AEM	•	•	•	•	•	•		
S80	2002	AUM	AUM	•	•	•	•	•	0		
S80	2002	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	



NOTES:

- This function is supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2002	PHM	PHM	11110.	•	DIC ●	Prame	Data	O	Pulic Cloil	
S80	2002	REM	REM		•	•	•	•	•	55	
S80	2002	RTI	RTI		•		•	0	0	00	
S80	2002	SWM	SWM	•	•	•	•	•	0		
S80	2002	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S80	2002	TCM	4T65EV	•	•	•	•	•	•	10, 11	
S80	2002	TCM	4T65EV-GT	•	•	•	•	•	•	10, 11	
S80	2002	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S80	2002	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S80	2002	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
S80	2002	SAS	SAS	•	•	•	0	•	0		
S80	2002	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S80	2002	DDM	DDM	•	•	•	•	•	•	59	
S80	2002	PDM	PDM	•	•	•	•	•	•	59	
S80	2002	PSM	PSM	•	•	•	•	•	•	48, 60	
S80	2002	SRS	SRS	•	•	•	•	•	0		
S60	2002	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	
S60	2002	Petrol	B5204T5	•	•	•	•	•	•	1, 2, 3, 50	
S60	2002	Petrol	B5234T3	•	•	•	•	•	•	1, 2, 3, 50	
S60	2002	Petrol	B5234T7	•	•	•	•	•	•	1, 2, 3, 50	
S60	2002	Petrol	B5244S	•	•	•	•	•	•	88, 6, 89	Extend DTC; Elec. Ident.; Block DTC
S60	2002	Petrol	B5244S2	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.; Block DTC
S60	2002	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S60	2002	Petrol	B5244SG2	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S60	2002	Petrol	B5244T3	•	•	•	•	•	•	1, 2, 3, 50	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU	Read DTC	Clear	Freeze	Live	Active	Special	Other
				Info.		DTC	Frame	Data	Test	Function	0 01101
S60	2002	Diesel	D5244T	•	•	•	0	•	•	90, 7	
S60	2002	Diesel	D5244T2	•	•	•	0	•	•	90, 7	
S60	2002	AEM	AEM	•	•	•	•	•	•		
S60	2002	AUM	AUM	•	•	•	•	•	0		
S60	2002	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S60	2002	PHM	PHM	•	•	•	•	•	0		
S60	2002	REM	REM	•	•	•	•	•	•	55	
S60	2002	RTI	RTI	•	•	•	•	0	0		
S60	2002	SWM	SWM	•	•	•	•	•	0		
S60	2002	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S60	2002	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S60	2002	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S60	2002	ABS/BCM	ABS/BCM	•	•	•	•	•	•	62, 63	
S60	2002	SAS	SAS	•	•	•	0	•	0		
S60	2002	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S60	2002	DDM	DDM	•	•	•	•	•	•	59	
S60	2002	PDM	PDM	•	•	•	•	•	•	559	
S60	2002	PSM	PSM	•	•	•	•	•	•	48, 60	
S60	2002	SRS	SRS	•	•	•	•	•	0		
S40 (-04)	2002	Petrol	B4164S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2002	Petrol	B4184S10	•	•	•	0	•	•	113, 1	
S40 (-04)	2002	Petrol	B4184S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2002	Petrol	B4184S3	•	•	•	0	•	•	113, 1	
S40 (-04)	2002	Petrol	B4184S9	•	•	•	0	•	•	113, 1	
S40 (-04)	2002	Petrol	B4184SJ	•	•	•	0	•	•	117	
S40 (-04)	2002	Petrol	B4204S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2002	Petrol	B4204T3	•	•	•	0	•	•	118, 1	
S40 (-04)	2002	Petrol	B4204T5	•	•	•	0	•	•	118, 1	
S40 (-04)	2002	Diesel	D4192T3(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2002	Diesel	D4192T4(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2002	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
S40 (-04)	2002	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 12 6	
S40 (-04)	2002	Gas discharge light module	Gas discharge light module	•	•	•	0	•	•		
S40 (-04)	2002	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
S40 (-04)	2002	TCM	AW55-50/51SN	•	•	•	0	•	•	130, 131	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (-04)	2002	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S40 (-04)	2002	CCM	CCM	•	•	•	0	•	•	132, 133, 81	
S40 (-04)	2002	CPM	CPM	•	•	•	0	•	0	21	
S40 (-04)	2002	SRS	SRS	•	•	•	0	•	0		
C70 Coupe	2002	Petrol	B5204T4	•	•	•	•	•	•	50	Elec. Ident.
C70 Coupe	2002	Petrol	B5234T3	•	•	•	•	•	•	50	Elec. Ident.
C70 Coupe	2002	Petrol	B5244T	•	•	•	•	•	•	50	Elec. Ident.
C70 Coupe	2002	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Coupe	2002	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Coupe	2002	RTI	RTI	•	•	•	0	•	•		
C70 Coupe	2002	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Coupe	2002	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Coupe	2002	CCM	CCM	•	•	•	0	•	0		
C70 Coupe	2002	CPM	CPM	•	•	•	0	•	0		
C70 Coupe	2002	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
C70 Coupe	2002	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Coupe	2002	SRS	SRS	•	•	•	0	•	0		
C70 Conv	2002	Petrol	B5204T4	•	•	•	•	•	•	50	Elec. Ident.
C70 Conv	2002	Petrol	B5234T3	•	•	•	•	•	•	50	Elec. Ident.
C70 Conv	2002	Petrol	B5244T	•	•	•	•	•	•	50	Elec. Ident.
C70 Conv	2002	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Conv	2002	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Conv	2002	RTI	RTI	•	•	•	0	•	•		
C70 Conv	2002	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Conv	2002	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Conv	2002	Cab control system	Cab control system	•	•	•	0	•	0		
C70 Conv	2002	CCM	CCM	•	•	•	0	•	0		
C70 Conv	2002	CPM	CPM	•	•	•	0	•	0		
C70 Conv	2002	Power seat module, left	Power seat module, left	•	•	•	0	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Conv	2002	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Conv	2002	Rollover protection	Rollover protection	•	•	•	0	•	•		
C70 Conv	2002	SRS	SRS	•	•	•	0	•	0		
V70 (00-)	2001	Petrol	B5204T5	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (00-)	2001	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (00-)	2001	Petrol	B5234T7	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (00-)	2001	Petrol	B5244S	•	•	•	•	•	•	88, 6, 89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2001	Petrol	B5244S2	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2001	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
V70 (00-)	2001	Petrol	B5244T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (00-)	2001	Diesel	D5244T	•	•	•	0	•	•	90, 7	1
V70 (00-)	2001	Diesel	D5252T MSA 15.8	•	0	0	•	•	•	91, 92	
V70 (00-)	2001	AEM	AEM	•	•	•	•	•	•		
V70 (00-)	2001	AUM	AUM	•	•	•	•	•	0		
V70 (00-)	2001	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70 (00-)	2001	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
V70 (00-)	2001	PHM	PHM	•	•	•	•	•	0		
V70 (00-)	2001	REM	REM	•	•	•	•	•	•		
V70 (00-)	2001	RTI	RTI	•	•	•	•	0	0		
V70 (00-)	2001	SWM	SWM	•	•	•	•	•	0		
V70 (00-)	2001	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 (00-)	2001	TCM	AW50/51AWD	•	•	•	0	•	•	10, 11	
V70 (00-)	2001	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	



NOTES:

- This function is supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-)	2001	ABS/BCM	ABS/BCM	11110.	•	D 10	1.1 ame	Data	1est	runc tron	
V70 (00-)	2001	SAS	SAS	•	•	•	0	•	0		
V70 (00-)	2001	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
V70 (00-)	2001	DDM	DDM	•	•	•	•	•	•	47, 59	
V70 (00-)	2001	PDM	PDM	•	•	•	•	•	•	47, 59	
V70 (00-)	2001	PSM	PSM	•	•	•	•	•	•	48, 60	
V70 (00-)	2001	SRS	SRS	•	•	•	•	•	0		
V70 XC(01-)/XC70	2001	Petrol	B5234T7	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 XC(01-)/XC70	2001	Petrol	B5244T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 XC(01-)/XC70	2001	AEM	AEM	•	•	•	•	•	•		
V70 XC(01-)/XC70	2001	AUM	AUM	•	•	•	•	0	0		
V70 XC(01-)/XC70	2001	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70 XC(01-)/XC70	2001	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
V70 XC(01-)/XC70	2001	PHM	РНМ	•	•	•	•	•	0		
V70 XC(01-)/XC70	2001	REM	REM	•	•	•	•	•	•		
V70 XC(01-)/XC70	2001	RTI	RTI	•	•	•	•	0	0		
V70 XC(01-)/XC70	2001	SWM	SWM	•	•	•	•	•	0		
V70 XC(01-)/XC70	2001	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 XC(01-)/XC70	2001	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 XC(01-)/XC70	2001	ABS/BCM	ABS/BCM	•	•	•	•	•	•		DSTC(Live Data); DSTC(Active Test)
V70 XC(01-)/XC70	2001	SAS	SAS	•	•	•	0	•	0		
V70 XC(01-)/XC70	2001	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70	2001	DDM	DDM	•	•	•	•	•	•	47, 59	
V70 XC(01-)/XC70	2001	PDM	PDM	•	•	•	•	•	•	47, 59	
V70 XC(01-)/XC70	2001	PSM	PSM	•	•	•	•	•	•	48, 60	
V70 XC(01-)/XC70	2001	SRS	SRS	•	•	•	•	•	0		
V40	2001	Petrol	B4164S2	•	•	•	0	•	•	113, 1	
V40	2001	Petrol	B4184S10	•	•	•	0	•	•	113, 1	
V40	2001	Petrol	B4184S2	•	•	•	0	•	•	113, 1	
V40	2001	Petrol	B4184S3	•	•	•	0	•	•	113, 1	
V40	2001	Petrol	B4184S9	•	•	•	0	•	•	113, 1	
V40	2001	Petrol	B4184SJ	•	•	•	0	•	•	117	
V40	2001	Petrol	B4184SM	•	•	•	0	•	•	134, 135	
V40	2001	Petrol	B4204S2	•	•	•	0	•	•	113, 1	
V40	2001	Petrol	B4204T3	•	•	•	0	•	•	118, 1	
V40	2001	Petrol	B4204T5	•	•	•	0	•	•	118, 1	
V40	2001	Diesel	D4192T3(Anti-spin system)	•	•	•	0	•	0		
V40	2001	Diesel	D4192T4(Anti-spin system)	•	•	•	0	•	0		
V40	2001	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
V40	2001	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 12 6	
V40	2001	Gas discharge light module	Gas discharge light module	•	•	•	0	•	•		
V40	2001	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
V40	2001	TCM	AW55-50/51SN	•	•	•	0	•	•	130, 131	
V40	2001	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	2001	CCM	CCM	•	•	•	0	•	•	132, 133, 81	
V40	2001	CPM	CPM	•	•	•	0	•	0	21	
V40	2001	SRS	SRS	•	•	•	0	•	0		
S80	2001	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	
S80	2001	Petrol	B5204T5	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2001	Petrol	B5234T7	•	•	•	•	•	•	1, 50	Elec. Ident.



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2001	Petrol	B5244S	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.; Block DTC
S80	2001	Petrol	B5244S2	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.; Block DTC
S80	2001	Petrol	B5244SG	•	•	•	•	•	•	89	Extend DTC; Elec. Ident.; Block DTC
S80	2001	Petrol	B5244T3	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2001	Petrol	B6284T	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2001	Petrol	B6294S	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2001	Diesel	D5244T	•	•	•	0	•	•	90, 7	
S80	2001	Diesel	D5252T MSA 15.8	•	0	0	•	•	•	91, 92	
S80	2001	AEM	AEM	•	•	•	•	•	•	Í	
S80	2001	AUM	AUM	•	•	•	•	•	0		
S80	2001	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S80	2001	PHM	PHM	•	•	•	•	•	0		
S80	2001	REM	REM	•	•	•	•	•	•		
S80	2001	RTI	RTI	•	•	•	•	0	0		
S80	2001	SWM	SWM	•	•	•	•	•	0		
S80	2001	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S80	2001	TCM	4T65EV	•	•	•	•	•	•	10, 11	
S80	2001	TCM	4T65EV-GT	•	•	•	•	•	•	10, 11	
S80	2001	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S80	2001	TCM	AW50-42	•	•	•	•	•	•	10, 11	
S80	2001	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S80	2001	ABS/BCM	ABS/BCM	•	•	•	•	•	•		DSTC(Live Data); DSTC(Active Test)
S80	2001	SAS	SAS	•	•	•	0	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2001	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S80	2001	DDM	DDM	•	•	•	•	•	•	59	
S80	2001	PDM	PDM	•	•	•	•	•	•	59	
S80	2001	PSM	PSM	•	•	•	•	•	•	48, 60	
S80	2001	SRS	SRS	•	•	•	•	•	0		
S60	2001	CEM	CEM	•	•	•	•	•	•	27, 51, 40, 30, 32	
S60	2001	Petrol	B5204T5	•	•	•	•	•	•	1, 50	Elec. Ident.
S60	2001	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
S60	2001	Petrol	B5234T7	•	•	•	•	•	•	1, 50	Elec. Ident.
S60	2001	Petrol	B5244S	•	•	•	•	•	•	88, 6, 89	Extend DTC; Elec. Ident.; Block DTC
S60	2001	Petrol	B5244S2	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.; Block DTC
S60	2001	Petrol	B5244T3	•	•	•	•	•	•	1, 50	Elec. Ident.
S60	2001	Diesel	D5244T	•	•	•	0	•	•	90, 7	
S60	2001	AEM	AEM	•	•	•	•	•	•		
S60	2001	AUM	AUM	•	•	•	•	•	0		
S60	2001	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S60	2001	PHM	PHM	•	•	•	•	•	0		
S60	2001	REM	REM	•	•	•	•	•	•		
S60	2001	RTI	RTI	•	•	•	•	0	0		
S60	2001	SWM	SWM	•	•	•	•	•	0		
S60	2001	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S60	2001	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S60	2001	ABS/BCM	ABS/BCM	•	•	•	•	•	•		
S60	2001	SAS	SAS	•	•	•	0	•	0		
S60	2001	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S60	2001	DDM	DDM	•	•	•	•	•	•	47, 59	
S60	2001	PDM	PDM	•	•	•	•	•	•	47, 59	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2001	PSM	PSM	•	•	•	•	•	•	48, 60	
S60	2001	SRS	SRS	•	•	•	•	•	0		
S40 (-04)	2001	Petrol	B4164S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2001	Petrol	B4184S10	•	•	•	0	•	•	113, 1	
S40 (-04)	2001	Petrol	B4184S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2001	Petrol	B4184S3	•	•	•	0	•	•	113, 1	
S40 (-04)	2001	Petrol	B4184S9	•	•	•	0	•	•	113, 1	
S40 (-04)	2001	Petrol	B4184SJ	•	•	•	0	•	•	117	
S40 (-04)	2001	Petrol	B4184SM	•	•	•	0	•	•	134, 135	
S40 (-04)	2001	Petrol	B4204S2	•	•	•	0	•	•	113, 1	
S40 (-04)	2001	Petrol	B4204T3	•	•	•	0	•	•	118, 1	
S40 (-04)	2001	Petrol	B4204T5	•	•	•	0	•	•	118, 1	
S40 (-04)	2001	Diesel	D4192T3(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2001	Diesel	D4192T4(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2001	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
S40 (-04)	2001	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 126 6	2
S40 (-04)	2001	Gas discharge light module	Gas discharge light module	•	•	•	0	•	•		
S40 (-04)	2001	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
S40 (-04)	2001	TCM	AW55-50/51SN	•	•	•	0	•	•	130, 131	
S40 (-04)	2001	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S40 (-04)	2001	CCM	CCM	•	•	•	0	•	•	132, 133, 81	
S40 (-04)	2001	CPM	CPM	•	•	•	0	•	0	21	
S40 (-04)	2001	SRS	SRS	•	•	•	0	•	0		
C70 Coupe	2001	Petrol	B5204T4	•	•	•	•	•	•	50	Elec. Ident.
C70 Coupe	2001	Petrol	B5234T3	•	•	•	•	•	•	50	Elec. Ident.
C70 Coupe	2001	Petrol	B5244T	•	•	•	•	•	•	50	Elec. Ident.
C70 Coupe	2001	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Coupe	2001	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Coupe	2001	RTI	RTI	•	•	•	0	•	•		
C70 Coupe	2001	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Coupe	2001	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Coupe	2001	CCM	CCM	•	•	•	0	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Coupe	2001	CPM	CPM	•	•	•	0	•	0		
C70 Coupe	2001	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
C70 Coupe	2001	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Coupe	2001	SRS	SRS	•	•	•	0	•	0		
C70 Conv	2001	Petrol	B5204T4	•	•	•	•	•	•	50	Elec. Ident.
C70 Conv	2001	Petrol	B5234T3	•	•	•	•	•	•	50	Elec. Ident.
C70 Conv	2001	Petrol	B5244T	•	•	•	•	•	•	50	Elec. Ident.
C70 Conv	2001	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Conv	2001	Lock and alarm	Lock and alarm	•		•	0	•	•	80, 81, 40	
C70 Conv	2001	RTI	RTI	•	•	•	0	•	•		
C70 Conv	2001	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Conv	2001	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Conv	2001	Cab control system	Cab control system	•	•	•	0	•	0		
C70 Conv	2001	CCM	CCM	•	•	•	0	•	0		
C70 Conv	2001	CPM	CPM	•	•	•	0	•	0		
C70 Conv	2001	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
C70 Conv	2001	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Conv	2001	Rollover protection	Rollover protection	•	•	•	0	•	•		
C70 Conv	2001	SRS	SRS	•	•	•	0	•	0		
V70 (00-)	2000	Petrol	B5204T5	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (00-)	2000	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (00-)	2000	Petrol	B5244T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (00-)	2000	Diesel	D5252T MSA 15.8	•	0	0	•	•	•	91, 92	
V70 (00-)	2000	AUM	AUM	•	•	•	•	•	0		
V70 (00-)	2000	CEM	CEM	•	•	•	•	•	•	27, 21, 32	Immobiliser(Live Data)
V70 (00-)	2000	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
V70 (00-)	2000	PHM	PHM	•	•	•	•	0	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-)	2000	REM	REM	•	•	•	•	•	•		
V70 (00-)	2000	RTI	RTI	•	•	•	•	0	0		
V70 (00-)	2000	SWM	SWM	•	•	•	•	•	0		
V70 (00-)	2000	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
V70 (00-)	2000	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
V70 (00-) V70 (00-)	2000	TCM ABS/BCM	AW55-50/51SN ABS/BCM	•	•	•	•	•	•	10, 11	DSTC(Live Data); DSTC(Active Test)
V70 (00-)	2000	SAS	SAS	•	•	•	0	•	0		
V70 (00-)	2000	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
V70 (00-)	2000	DDM	DDM	•	•	•	•	•	•	47, 59	
V70 (00-)	2000	PDM	PDM	•	•	•	•	•	•	47, 59	
V70 (00-)	2000 2000	PSM SRS	PSM SRS	•	•	•	•	•	0	48, 60	
V70 (00-) V70 (-00)	2000	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (-00)	2000	Petrol	B5204T4	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (-00)	2000	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (-00)	2000	Petrol	B5234T7	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (-00)	2000	Petrol	B5244S	•	•	•	0	•	•	88, 6, 89	Extend DTC; Elec. Ident.
V70 (-00)	2000	Petrol	B5244S2	•	•	•	0	•	•	88, 6, 89	Extend DTC; Elec. Ident.
V70 (-00)	2000	Petrol	B5244SG	•	•	•	0	•	0		Elec. Ident.
V70 (-00)	2000	Petrol	B5244SG2	•	•	•	0	•	0		Elec. Ident.
V70 (-00)	2000	Petrol	B5244T	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (-00)	2000	Petrol	B5244T2	•	•	•	•	•	•	1, 50	Elec. Ident.



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (-00)	2000	Diesel	D5252T MSA 15.8	•	0	0	0	•	•	91, 92	
V70 (-00)	2000	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
V70 (-00)	2000	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
V70 (-00)	2000	RTI	RTI	•	•	•	0	•	•		
V70 (-00)	2000	TCM	AW42AWD	•	•	•	0	•	•	10, 11	
V70 (-00)	2000	TCM	AW50/51AWD	•	•	•	0	•	•	10, 11	
V70 (-00)	2000	TCM	AW50-42	•	•	•	0	•	•	10, 11	
V70 (-00)	2000	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
V70 (-00)	2000	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V70 (-00)	2000	CCM	CCM	•	•	•	0	•	0		
V70 (-00)	2000	CPM	CPM	•	•	•	0	•	0		
V70 (-00)	2000	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
V70 (-00)	2000	Power seat module, right	Power seat module, Right	•	•	•	0	•	•		
V70 (-00)	2000	SRS	SRS	•	•	•	0	•	0		
V70 XC (-00)	2000	Petrol	B5244T	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 XC (-00)	2000	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
V70 XC (-00)	2000	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
V70 XC (-00)	2000	RTI	RTI	•	•	•	0	•	•		
V70 XC (-00)	2000	TCM	AW42AWD	•	•	•	0	•	•	10, 11	
V70 XC (-00)	2000	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V70 XC (-00)	2000	CCM	CCM	•	•	•	0	•	0		
V70 XC (-00)	2000	CPM	CPM	•	•	•	0	•	0		
V70 XC (-00)	2000	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
V70 XC (-00)	2000	Power seat module, Right	Power seat module, Right	•	•	•	0	•	•		
V70 XC (-00)	2000	SRS	SRS	•	•	•	0	•	0		
V40	2000	Petrol	B4164S2	•	•	•	0	•	•		
V40	2000	Petrol	B4184S2	•	•	•	0	•	•		
V40	2000	Petrol	B4184S3	•	•	•	0	•	•		
V40	2000	Petrol	B4184SM	•	•	•	0	•	•	134, 135	
V40	2000	Petrol	B4194T2	•	•	•	0	•	•		
V40	2000	Petrol	B4204S2	•	•	•	0	•	•		
V40	2000	Petrol	B4204T2	•	•	•	0	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU	Read DTC	Clear	Freeze	Live	Active	Special	Other
			17	Info.		DTC	Frame	Data	Test	Function	
V40	2000	Diesel	D4192T2 (Anti-spin system)	•	•	•	0	•	0		
V40	2000	Anti-spin system	Anti-spin system							121, 122, 81, 125, 12	
V40	2000	DIM	DIM	•	•	•	0	•	•	6	
V40	2000	Lock and alarm	Lock and alarm	•	•	•	0	•	0	80, 81, 40	
V40	2000	TCM	AW50-42	•	•	•	0	•	•		
V40	2000	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	2000	CCM	CCM	•	•	•	0	•	0		
V40	2000	CPM	CPM	•	•	•	0	•	0	21	
V40	2000	SRS	SRS	•	•	•	0	0	0		
S80	2000	CEM	CEM	•	•	•	•	•	•	27, 21, 32	
S80	2000	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2000	Petrol	B5204T4	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2000	Petrol	B5204T5	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2000	Petrol	B5234T7	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2000	Petrol	B5244S	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.
S80	2000	Petrol	B5244S2	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.
S80	2000	Petrol	B6284T	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2000	Petrol	B6294S	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	2000	Diesel	D5252T MSA 15.8	•	0	0	•	•	•	91, 92	
S80	2000	AUM	AUM	•	•	•	•	•	0		
S80	2000	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S80	2000	PHM	РНМ	•	•	•	•	0	0		
S80	2000	REM	REM	•	•	•	•	•	•		
S80	2000	RTI	RTI	•	•	•	•	0	0		
S80	2000	SWM	SWM	•	•	•	•	•	0		
S80	2000	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S80	2000	TCM	4T65EV	•	•	•	•	•	•	10, 11	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2000	TCM	4T65EV-GT	•	•	•	•	•	•	10, 11	
S80	2000	TCM	AW50-42	•	•	•	•	•	•	10, 11	
S80	2000	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S80	2000	ABS/BCM	ABS/BCM	•	•	•	•	•	•		DSTC(Live Data); DSTC(Active Test)
S80	2000	SAS	SAS	•	•	•	0	•	0		
S80	2000	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S80	2000	DDM	DDM	•	•	•	•	•	•	59	
S80	2000	PDM	PDM	•	•	•	•	•	•	59	
S80	2000	PSM	PSM	•	•	•	•	•	•	48,60	
S80	2000	SRS	SRS	•	•	•	•	•	0		
S70	2000	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
S70	2000	Petrol	B5204T4	•	•	•	•	•	•	1, 50	Elec. Ident.
S70	2000	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
S70	2000	Petrol	B5234T7	•	•	•	•	•	•	1, 50	Elec. Ident.
S70	2000	Petrol	B5244S	•	•	•	0	•	•	88, 6, 89	Extend DTC; Elec. Ident.
S70	2000	Petrol	B5244S2	•	•	•	0	•	•	88, 6, 89	Extend DTC; Elec. Ident.
S70	2000	Petrol	B5244SG	•	•	•	0	•	0		Elec. Ident.
S70	2000	Petrol	B5244SG2	•	•	•	0	•	0		Elec. Ident.
S70	2000	Petrol	B5244T	•	•	•	•	•	•	1, 50	Elec. Ident.
S70	2000	Diesel	D5252T MSA 15.8	•	0	0	0	•	•	91, 92	
S70	2000	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
S70	2000	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
S70	2000	RTI	RTI	•	•	•	0	•	•		
S70	2000	TCM	AW42AWD	•	•	•	0	•	•	10, 11	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S70	2000	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
S70	2000	TCM	AW50-42	•	•	•	0	•	•	10, 11	
S70	2000	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S70	2000	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S70	2000	CCM	CCM	•	•	•	0	•	0		
S70	2000	CPM	CPM	•	•	•	0	•	0		
S70	2000	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
S70	2000	Power seat module, right	Power seat module, Right	•	•	•	0	•	•		
S70	2000	SRS	SRS	•	•	•	0	•	0		
S40 (-04)	2000	Petrol	B4164S2	•	•	•	0	•	•		
S40 (-04)	2000	Petrol	B4184S2	•	•	•	0	•	•		
S40 (-04)	2000	Petrol	B4184S3	•	•	•	0	•	•		
S40 (-04)	2000	Petrol	B4184SM	•	•	•	0	•	•	134, 135	
S40 (-04)	2000	Petrol	B4194T2	•	•	•	0	•	•		
S40 (-04)	2000	Petrol	B4204S2	•	•	•	0	•	•		
S40 (-04)	2000	Petrol	B4204T2	•	•	•	0	•	•		
S40 (-04)	2000	Diesel	D4192T2(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	2000	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
S40 (-04)	2000	DIM	DIM	•	•	•	0	•	•	121, 122, 81, 125, 12 6	
S40 (-04)	2000	Lock and alarm	Lock and alarm	•	•	•	0	•	0	80, 81, 40	
S40 (-04)	2000	TCM	AW50-42	•	•	•	0	•	•		
S40 (-04)	2000	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S40 (-04)	2000	CCM	CCM	•	•	•	0	•	0		
S40 (-04)	2000	CPM	CPM	•	•	•	0	•	0	21	
S40 (-04)	2000	SRS	SRS	•	•	•	0	0	0		
C70 Coupe	2000	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Coupe	2000	Petrol	B5204T4	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Coupe	2000	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Coupe	2000	Petrol	B5244S	•	•	•	0	•	•	88, 6, 89	Extend DTC;Elec. Ident.



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Coupe	2000	Petrol	B5244T	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Coupe	2000	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Coupe	2000	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Coupe	2000	RTI	RTI	•	•	•	0	•	•		
C70 Coupe	2000	TCM	AW50-42	•	•	•	0	•	•	10, 11	
C70 Coupe	2000	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Coupe	2000	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Coupe	2000	CCM	CCM	•	•	•	0	•	0		
C70 Coupe	2000	CPM	CPM	•	•	•	0	•	0		
C70 Coupe	2000	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
C70 Coupe	2000	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Coupe	2000	SRS	SRS	•	•	•	0	•	0		
C70 Conv	2000	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Conv	2000	Petrol	B5204T4	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Conv	2000	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Conv	2000	Petrol	B5244S	•	•	•	0	•	•	88, 6, 89	Extend DTC;Elec. Ident.
C70 Conv	2000	Petrol	B5244T	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Conv	2000	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Conv	2000	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Conv	2000	RTI	RTI	•	•	•	0	•	•		
C70 Conv	2000	TCM	AW50-42	•	•	•	0	•	•	10, 11	
C70 Conv	2000	TCM	AW55-50/51SN	•	•	•	0	•	•	10, 11	
C70 Conv	2000	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Conv	2000	Cab control system	Cab control system	•	•	•	0	•	0		
C70 Conv	2000	CCM	CCM	•	•	•	0	•	0		
C70 Conv	2000	CPM	CPM	•	•	•	0	•	0		
C70 Conv	2000	Power seat module, left	Power seat module, left	•	•	•	0	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Conv	2000	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Conv	2000	Rollover protection	Rollover protection	•	•	•	0	•	•		
C70 Conv	2000	SRS	SRS	•	•	•	0	•	0		
V70 (-00)	1999	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 (-00)	1999	Petrol	B5204T4	•	•	•	•	•	•	1, 93	Elec. Ident.
V70 (-00)	1999	Petrol	B5234T3	•	•	•	•	•	•	1, 93	Elec. Ident.
V70 (-00)	1999	Petrol	B5234T7	•	•	•	•	•	•	1, 93	Elec. Ident.
V70 (-00)	1999	Petrol	B5234T8	•	•	•	0	•	•	1, 93	Elec. Ident.
V70 (-00)	1999	Petrol	B5254S DENSO	•	•	•	0	•	•	88, 6, 89	Extend DTC; Elec. Ident.
V70 (-00)	1999	Petrol	B5254T	•	•	•	•	•	•	1, 93	Elec. Ident.
V70 (-00)	1999	Diesel	D5252T MSA 15.7	•	•	•	0	•	•		
V70 (-00)	1999	Diesel	D5252T MSA 15.8	•	0	0	0	•	•	91, 92	
V70 (-00)	1999	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
V70 (-00)	1999	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
V70 (-00)	1999	RTI	RTI	•	•	•	0	•	•		
V70 (-00)	1999	TCM	AW42AWD	•	•	•	0	•	•		
V70 (-00)	1999	TCM	AW50-42	•	•	•	0	•	•		
V70 (-00)	1999	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V70 (-00)	1999	CCM	CCM	•	•	•	0	•	0		
V70 (-00)	1999	CPM	CPM	•	•	•	0	•	0		
V70 (-00)	1999	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
V70 (-00)	1999	Power seat module, right	Power seat module, Right	•	•	•	0	•	•		
V70 (-00)	1999	SRS	SRS	•	•	•	0	•	0		
V70 XC (-00)	1999	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
V70 XC (-00)	1999	Petrol	B5254T	•	•	•	•	•	•	1, 93	Elec. Ident.



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC (-00)	1999	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
V70 XC (-00)	1999	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
V70 XC (-00)	1999	RTI	RTI	•	•	•	0	•	•		
V70 XC (-00)	1999	TCM	AW42AWD	•	•	•	0	•	•		
V70 XC (-00)	1999	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V70 XC (-00)	1999	CCM	CCM	•	•	•	0	•	0		
V70 XC (-00)	1999	CPM	CPM	•	•	•	0	•	0		
V70 XC (-00)	1999	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
V70 XC (-00)	1999	Power seat module, Right	Power seat module, Right	•	•	•	0	•	•		
V70 XC (-00)	1999	SRS	SRS	•	•	•	0	•	0		
V40	1999	Petrol	B4164S(Anti-spin system)	•	•	•	0	•	0		
V40	1999	Petrol	B4184S(Anti-spin system)	•	•	•	0	•	0		
V40	1999	Petrol	B4184SM	•	•	•	0	•	•	134, 135	
V40	1999	Petrol	B4194T	•	•	•	0	•	•	113	
V40	1999	Petrol	B4204S(Anti-spin system)	•	•	•	0	•	0		
V40	1999	Petrol	B4204T	•	•	•	0	•	•	113	
V40	1999	Diesel	D4192T(Anti-spin system)	•	•	•	0	•	0		
V40	1999	Diesel	D4192T2(Anti-spin system)	•	•	•	0	•	0		
V40	1999	DIM	DIM	•	•	•	0	•	•	125, 126	
V40	1999	Lock and alarm	Lock and alarm	•	•	•	0	•	•	139	
V40	1999	TCM	AW50-42	•	•	•	0	•	•		
V40	1999	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	1999	CCM	CCM	•	•	•	0	•	0		
V40	1999	CPM	CPM	•	•	•	0	•	0	21	
V40	1999	SRS	SRS	•	•	•	0	0	0		
S80	1999	CEM	CEM	•	•	•	•	•	•	27, 21, 32	
S80	1999	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
S80	1999	Petrol	B5204T4	•	•	•	•	•	•	1, 93	Elec. Ident.
S80	1999	Petrol	B5244S	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	1999	Petrol	B5244S2	•	•	•	•	•	•	6, 89	Extend DTC; Elec. Ident.
S80	1999	Petrol	B6284T	•	•	•	•	•	•	1, 50	
S80	1999	Petrol	B6304S3	•	•	•	•	•	•	1, 93	
S80	1999	Diesel	D5252T MSA 15.8	•	0	0	•	•	•	91, 92	
S80	1999	AUM	AUM	•	•	•	•	0	0		
S80	1999	DIM	DIM	•	•	•	•	•	•	33, 35, 53, 37	
S80	1999	PHM	PHM	•	•	•	•	0	0		
S80	1999	REM	REM	•	•	•	•	•	•		
S80	1999	RTI	RTI	•	•	•	•	0	0		
S80	1999	SWM	SWM	•	•	•	•	•	0		
S80	1999	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24	
S80	1999	TCM	4T65EV	•	•	•	•	•	•	10, 11	
S80	1999	TCM	4T65EV-GT	•	•	•	•	•	•	10, 11	
S80	1999	TCM	AW50-42	•	•	•	0	•	•	10, 11	
S80	1999	TCM	AW55-50/51SN	•	•	•	•	•	•	10, 11	
S80	1999	ABS/BCM	ABS/BCM	•	•	•	0	•	•		DSTC(Live Data); DSTC(Active Test)
S80	1999	SAS	SAS	•	•	•	0	•	0		
S80	1999	CCM	CCM	•	•	•	•	•	0	41, 56, 56, 58	
S80	1999	DDM	DDM	•	•	•	•	•	•	59	
S80	1999	PDM	PDM	•	•	•	•	•	•	59	
S80	1999	PSM	PSM	•	•	•	•	•	•		
S80	1999	SRS	SRS	•	•	•	•	0	0		
S70	1999	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
S70	1999	Petrol	B5204T4	•	•	•	•	•	•	1, 93	Elec. Ident.
S70	1999	Petrol	B5234T3	•	•	•	•	•	•	1, 93	Elec. Ident.
S70	1999	Petrol	B5234T7	•	•	•	•	•	•	1, 93	Elec. Ident.
S70	1999	Petrol	B5254S DENSO	•	•	•	0	•	•	88, 6, 89	Extend DTC; Elec. Ident.



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S70	1999	Petrol	B5254T	•	•	•	•	•	•	1, 93	Elec. Ident.
S70	1999	Diesel	D5252T MSA 15.8	•	0	0	0	•	•	91, 92	
S70	1999	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
S70	1999	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
570	1999	RTI	RTI	•	•	•	0	•	•		
S70	1999	TCM	AW42AWD	•	•	•	0	•	•	10, 11	
S70	1999	TCM	AW50-42	•	•	•	0	•	•		
S70	1999	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S70	1999	CCM	CCM	•	•	•	0	•	0		
S70	1999	CPM	CPM	•	•	•	0	•	0		
S70	1999	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
S70	1999	Power seat module, right	Power seat module, Right	•	•	•	0	•	•		
S70	1999	SRS	SRS	•	•	•	0	•	0		
540 (-04)	1999	Petrol	B4164S(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	1999	Petrol	B4184S(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	1999	Petrol	B4184SM	•	•	•	0	•	•	134, 135	
S40 (-04)	1999	Petrol	B4194T	•	•	•	0	•	•	113	
S40 (-04)	1999	Petrol	B4204S(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	1999	Petrol	B4204T	•	•	•	0	•	•	113	
S40 (-04)	1999	Diesel	D4192T(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	1999	Diesel	D4192T2(Anti-spin system)	•	•	•	0	•	0		
S40 (-04)	1999	Anti-spin system	Anti-spin system	•	•	•	0	•	0		
540 (-04)	1999	DIM	DIM	•	•	•	0	•	•	125, 126	
540 (-04)	1999	Lock and alarm	Lock and alarm	•	•	•	0	•	•	139	
540 (-04)	1999	TCM	AW50-42	•	•	•	0	•	•		
540 (-04)	1999	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
540 (-04)	1999	CCM	CCM	•	•	•	0	•	0		
540 (-04)	1999	CPM	CPM	•	•	•	0	•	0	21	
S40 (-04)	1999	SRS	SRS	•	•	•	0	0	0		
C70 Coupe	1999	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Coupe	1999	Petrol	B5204T4	•	•	•	•	•	•	1, 93	Elec. Ident.



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Coupe	1999	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Coupe	1999	Petrol	B5254S DENSO	•	•	•	0	•	•	88, 6, 89	Extend DTC;Elec. Ident.
C70 Coupe	1999	Petrol	B5254T	•	•	•	•	•	•	1, 93	Elec. Ident.
C70 Coupe	1999	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Coupe	1999	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Coupe	1999	RTI	RTI	•	•	•	0	•	•		
C70 Coupe	1999	TCM	AW50-42	•	•	•	0	•	•		
C70 Coupe	1999	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Coupe	1999	CCM	CCM	•	•	•	0	•	0		
C70 Coupe	1999	CPM	CPM	•	•	•	0	•	0		
C70 Coupe	1999	Power seat module, left	Power seat module, left	•	•	•	0	•	•		
C70 Coupe	1999	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Coupe	1999	SRS	SRS	•	•	•	0	•	0		
C70 Conv	1999	Petrol	B5204T3	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Conv	1999	Petrol	B5204T4	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Conv	1999	Petrol	B5234T3	•	•	•	•	•	•	1, 50	Elec. Ident.
C70 Conv	1999	Petrol	B5254T	•	•	•	•	•	•	1, 93	Elec. Ident.
C70 Conv	1999	Combined instrument	Combined instrument	•	•	•	0	•	•	72, 73, 37, 32	
C70 Conv	1999	Lock and alarm	Lock and alarm	•	•	•	0	•	•	80, 81, 40	
C70 Conv	1999	RTI	RTI	•	•	•	0	•	•		
C70 Conv	1999	TCM	AW50-42	•	•	•	0	•	•		
C70 Conv	1999	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
C70 Conv	1999	Cab control system	Cab control system	•	•	•	0	•	0		
C70 Conv	1999	CCM	CCM	•	•	•	0	•	0		
C70 Conv	1999	CPM	CPM	•	•	•	0	•	0		
C70 Conv	1999	Power seat module, left	Power seat module, left	•	•	•	0	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Conv	1999	Power seat module, right	Power seat module, right	•	•	•	0	•	•		
C70 Conv	1999	Rollover protection	Rollover protection	•	•	•	0	•	•		
C70 Conv	1999	SRS	SRS	•	•	•	0	•	0		
XC90		9 TCM	TF-80SC AWD	•	•	•	•	•	•	1, 3, 81, 84, 85	
XC90		9 DEM	TF-80SC AWD	•	•	•	•	•	0		
XC90		9 DEM	M66 AWD	•	•	•	•	•	0		
XC90		9 BCM	D5244T5	•	•	•	•	•	•	86, 87	
XC90		9 SAS	D5244T5	•	•	•	•	•	0		
XC90	2009	HCM	D5244T5	•	•	•	•	•	0		
XC90	2009	9 ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
XC90	2009	Э СЕМ	D5244T5	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90		TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
XC90	2009	9 DEM	TF-80SC AWD	•	•	•	•	•	0		
XC90		9 DEM	M66 AWD	•	•	•	•	•	0		
XC90		9 BCM	D5244T4	•	•	•	•	•	•	86, 87	
XC90		9 SAS	D5244T4	•	•	•	•	•	0		
XC90	2009	HCM	D5244T4	•	•	•	•	•	0		
XC90	2009	e CEM	D5244T4	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2009	9 ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
XC90		7 TCM	TF-80SC AWD	•	•	•	•	•	•	1, 3, 81, 84, 85	
XC90		9 DEM	TF-80SC AWD	•	•	•	•	•	•		
XC90		9 BCM	B8444S	•	•	•	•	•	•	86, 87	
XC90		9 ECM	B8444S	•	•	•	•	•	•		
XC90		9 SAS	B8444S	•	•	•	•	•	0		
XC90	2009	HCM	B8444S	•	•	•	•	•	•		
XC90	2009	Э СЕМ	B8444S	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2009	9 TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
XC90	2009	9 DEM	TF-80SC AWD	•	•	•	•	•	•		
XC90	2009	9 BCM	B6324S	•	•	•	•	•	•	86, 87	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2009	SAS	B6324S	•	•	•	•	•	0		
XC90	2009	HCM	B6324S	•	•	•	•	•	•		
XC90	2009	ECM	B6324S	•	•	•	•	•	•	9	
XC90	2009	CEM	B6324S	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2009	DEM	TF-80SC AWD	•	•	•	•	•	0		
XC90	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 3, 81, 84, 85	
XC90	2009	BCM	B5254T2	•	•	•	•	•	•	86, 87	
XC90	2009	SAS	B5254T2	•	•	•	•	•	0		
XC90	2009	ECM	B5254T2	•	•	•	•	•	•	74	
XC90	2009	HCM	B5254T2	•	•	•	•	•	0		
XC90	2009	CEM	B5254T2	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2009	GPS		•	•	•	•	•	0		
XC90	2009	SRS		•	•	•	•	•	0	95	
XC90	2009	PSM		•	•	•	•	•	•	107	
XC90	2009	DDM		•	•	•	•	•	•	107, 108	
XC90	2009	PDM		•	•	•	•	•	•	108	
XC90	2009	AEM		•	•	•	•	•	•		
XC90	2009	REM		•	•	•	•	•	•		
XC90	2009	CPM		•	0	0	0	•	0	111, 112	
XC90	2009	RDAR		•	•	•	•	•	0		
XC90	2009			•	•	•	•	0	0		
XC90	2009	PAC		•	0	0	0	0	0		
XC90	2009	AUU		•	•	•	•	•	0		
XC90	2009	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
XC90	2009	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47, 118	
XC90	2009	UEM		•	•	•	•	•	•	119, 120, 128, 122, 1 23, 124	
XC90	2009			•	•	•	•	•	•		
XC90	2009	ICM		•	•	•	•	•	•		
XC90	2009			•	•	•	•	0	0		
XC90	2009			•	•	•	•	•	0		
XC90	2009		TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 85	
XC70 (08-)	2009	DEM	TF-80SC AWD	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2009		M66 AWD	•	•	•	•	•	•		
XC70 (08-)	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC70 (08-)	2009	ECM	D5244T5	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
XC70 (08-)	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC70 (08-)	2009	ECM	D5244T4	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
XC70 (08-)	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC70 (08-)	2009		B6324S	•	•	•	•	•	•	9	
XC70 (08-)	2009		TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC70 (08-)	2009		B6304T2	•	•	•	•	•	•	9	
XC70 (08-)	2009	POT		•	•	•	•	0	0		
XC70 (08-)	2009			•	•	•	•	•	•	10	
XC70 (08-)	2009			•	•	•	•	0	0		
XC70 (08-)	2009	PSM		•	•	•	•	•	•		
XC70 (08-)	2009	HLDF		•	•	•	•	•	0		
XC70 (08-)	2009			•	•	•	•	•	0		
XC70 (08-)	2009	DDM		•	•	•	•	•	•	12, 13	
XC70 (08-)	2009	PDM		•	•	•	•	•	•	12, 13	
XC70 (08-)	2009	PAM		•	•	•	•	•	0	14	
XC70 (08-)	2009	KVM		•	•	•	•	•	0	16, 17	
XC70 (08-)	2009			•	•	•	•	0	0		
XC70 (08-)	2009			•	•	•	•	•	•		
XC70 (08-)	2009	SUB		•	•	•	•	0	0		
XC70 (08-)	2009			•	•	•	•	•	0	23	
XC70 (08-)	2009	SRS		•	•	•	•	•	0	25, 26, 27	
XC70 (08-)	2009			•	•	•	•	•	•	10	
XC70 (08-)	2009	SAS		•	•	•	•	•	0		
XC70 (08-)	2009	CCM		•	•	•	•	•	•	28, 29, 30, 31, 32	
XC70 (08-)	2009	CEM		•	•	•	•	•	•	35, 39	
XC70 (08-)	2009	TRM		•	•	•	•	•	0		
XC70 (08-)	2009	PBM		•	•	•	•	•	0	43	
XC70 (08-)	2009			•	•	•	•	•	0		
XC70 (08-)	2009	DIM		•	•	•	•	•	0	47, 48, 49, 50, 51, 52	
XC70 (08-)	2009	PAC		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2009	RDAR		•	•	•	•	0	0		
XC70 (08-)	2009			•	•	•	•	0	0		
XC70 (08-)	2009			•	•	•	•	•	•		
XC70 (08-)	2009			•	•	•	•	•	0		
XC70 (08-)	2009			•	•	•	•	•	0		
XC60	2009		TF-80SC AWD	•	•	•	•	•	•		
XC60	2009		M66 AWD	•	•	•	•	•	•		
XC60	2009		TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC60	2009		TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC60	2009		TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC60	2009			•	•	•	•	•	•	10	
XC60	2009			•	•	•	•	•	•		
XC60	2009			•	•	•	•	•	0		
XC60	2009			•	•	•	•	•	•	12, 13	
XC60	2009			•	•	•	•	•	•	12, 13	
XC60	2009			•	•	•	•	•	0	14	
XC60	2009			•	•	•	•	•	0	16, 17	
XC60	2009			•	•	•	•	0	0		
XC60	2009	CPM		•	•	•	•	•	•		
XC60	2009	SUB		•	•	•	•	0	0		
XC60	2009			•	•	•	•	•	•	10	
XC60	2009			•	•	•	•	•	0		
XC60	2009			•	•	•	•	•	0		
XC60	2009			•	•	•	•	•	0	43	
XC60	2009			•	•	•	•	0	0		
XC60	2009			•	•	•	•	•	0		
XC60	2009		D5244T5	•	•	•	•	•	•		
XC60	2009		D5244T4	•	•	•	•	•	•		
XC60	2009		B6304T2	•	•	•	•	•	•	9	
XC60	2009			•	•	•	•	0	0		
XC60	2009			•	•	•	•	•	0	83	
XC60	2009			•	•	•	•	•	0		
XC60	2009	CEM		•	•	•	•	•	•	35, 39	
XC60	2009	CCM		•	•	•	•	•	•	28, 29, 30, 31, 32	
XC60	2009	ICM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC60	2009	POT		•	•	•	•	•	0		
XC60	2009	HLDF		•	•	•	•	•	0		
XC60	2009	IAM		•	•	•	•	0	0		
XC60	2009	DIM		•	•	•	•	•	0	47, 48, 49, 50, 51, 52	
XC60	2009	DABM		•	•	•	•	0	0		
XC60	2009	RDAR		•	•	•	•	•	0		
XC60	2009			•	•	•	•	•	0	25, 26, 27	
XC60	2009	FSM		•	•	•	•	•	0		
XC60	2009			•	•	•	•	•	0		
V70 (08-)	2009	DEM	TF-80SC AWD	•	•	•	•	•	•		
V70 (08-)	2009	DEM	M66 AWD	•	•	•	•	•	•		
V70 (08-)	2009	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2009	ECM	D5244T5	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
V70 (08-)	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2009	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2009	ECM	D5244T4	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
V70 (08-)	2009	ECM	D4204T	•	•	•	•	•	•	69, 70, 71	
V70 (08-)	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2009	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2009	ECM	B6324S	•	•	•	•	•	•	9	
V70 (08-)	2009		TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2009	ECM	B6304T2	•	•	•	•	•	•	9	
V70 (08-)	2009	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2009	ECM	B5254T8	•	•	•	•	•	•	74, 79	
V70 (08-)	2009		TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2009		B5254T6	•	•	•	•	•	•	74, 79	
V70 (08-)	2009		B4204S4	•	•	•	•	•	•	79	
V70 (08-)	2009		B4204S3	•	•	•	•	•	•	79	
V70 (08-)	2009			•	•	•	•	0	0		
V70 (08-)	2009			•	•	•	•	•	•	10	
V70 (08-)	2009			•	•	•	•	0	0		
V70 (08-)	2009	PSM		•	•	•	•	•	•		
V70 (08-)		HLDF		•	•	•	•	•	0		
V70 (08-)	2009	AUU		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (08-)	2009	DDM		•	•	•	•	•	•	12, 13	
V70 (08-)	2009	PDM		•	•	•	•	•	•	12, 13	
V70 (08-)	2009	PAM		•	•	•	•	•	0	14	
V70 (08-)	2009	KVM		•	•	•	•	•	0	16, 17	
V70 (08-)	2009			•	•	•	•	0	0		
V70 (08-)	2009	CPM		•	•	•	•	•	•		
V70 (08-)	2009	SUB		•	•	•	•	0	0		
V70 (08-)	2009	HCM		•	•	•	•	•	0	23	
V70 (08-)	2009	SRS		•	•	•	•	•	0	25, 26, 27	
V70 (08-)	2009	BCM		•	•	•	•	•	•	10	
V70 (08-)	2009	SAS		•	•	•	•	•	0		
V70 (08-)	2009	CCM		•	•	•	•	•	•	28, 29, 30, 31, 32	
V70 (08-)	2009	CEM		•	•	•	•	•	•	35, 39	
V70 (08-)	2009	TRM		•	•	•	•	•	0		
V70 (08-)	2009	PBM		•	•	•	•	•	0	43	
V70 (08-)	2009	FSM		•	•	•	•	•	0		
V70 (08-)	2009	DIM		•	•	•	•	•	0	47, 48, 49, 50, 51, 52	
V70 (08-)	2009	PAC		•	•	•	•	•	0		
V70 (08-)	2009	RDAR		•	•	•	•	0	0		
V70 (08-)	2009	MMM		•	•	•	•	0	0		
V70 (08-)	2009	ICM		•	•	•	•	•	•		
V70 (08-)	2009	BPM		•	•	•	•	•	0		
V70 (08-)	2009	PHM		•	•	•	•	•	0		
V50	2009	TCM	MPS6	•	•	•	•	•	0		
V50	2009		M66 AWD	•	•	•	•	•	0		
V50	2009		D5244T9	•	•	•	•	•	•		
V50	2009		D5244T8	•	•	•	•	•	•		
V50	2009		D5244T13	•	•	•	•	•	•		
V50	2009		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
V50		ADM	D4204T	•	•	•	•	•	0		
V50	2009		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
V50	2009		D4164T	•	•	•	•	•	0		
V50	2009		D4164T	•	•	•	•	•	•	69, 141	
V50	2009		B5254T7	•	•	•	•	•	•	74	
V50	2009	ECM	B5244S7	•	•	•	•	•	•	9	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2009	ECM	B5244S5	•	•	•	•	•	•	9	
V50	2009	ECM	B5244S4	•	•	•	•	•	•	9	
V50	2009	ECM	B4204S3	•	•	•	•	•	•	9	
V50	2009	ECM	B4184S8	•	•	•	•	•	•	9	
V50	2009		B4184S11	•	•	•	•	•	•	9	
V50	2009	ECM	B4164S3	•	•	•	•	•	•	9	
V50	2009	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
V50	2009	DEM	AW50/51 AWD	•	•	•	•	•	0		
V50	2009	TCM	AW50/51 AWD	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
V50	2009	PSM		•	•	•	•	•	•	145	
V50	2009	AEM		•	•	•	•	•	•	146	
V50	2009	KVM		•	•	•	•	•	•	147	
V50	2009	RDAR		•	•	•	•	•	0		
V50	2009	PHM		•	•	•	•	•	0		
V50	2009	CPM		•	•	•	•	•	•		
V50	2009			•	•	•	•	0	0		
V50	2009			•	•	•	•	•	0		
V50	2009			•	•	•	•	•	0		
V50	2009			•	•	•	•	•	0	95	
V50	2009			•	•	•	•	•	•	149, 150	
V50	2009			•	•	•	•	•	•	149, 150	
V50	2009			•	•	•	•	•	0		
V50	2009			•	•	•	•	•	0	23	
V50	2009	BCM		•	•	•	•	•	0	146, 111	
V50	2009	CCM		•	•	•	•	0	0	30, 113, 152, 32, 153	
V50	2009	SWM		•	•	•	•	•	0		
V50	2009			•	•	•	•	•	0		
V50	2009			•	•	•	•	•	0		
V50	2009	IAM		•	•	•	•	•	•		
V50	2009	СЕМ		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95, 35	
V50	2009	DIM		•	•	•	•	•	•	48, 161, 118, 46, 165 , 51	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2009			•	•	•	•	•	•	166, 167, 168	
V50	2009	MMM		•	•	•	•	0	0		
S80 (07-)	2009		TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2009	DEM	M66 AWD	•	•	•	•	•	•		
S80 (07-)	2009	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009	ECM	D5244T5	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
S80 (07-)	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009	ECM	D5244T4	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
S80 (07-)	2009	ECM	D4204T	•	•	•	•	•	•	69, 70, 71	
S80 (07-)	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009	ECM	B8444S	•	•	•	•	•	•	9	
S80 (07-)	2009	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009	ECM	B6324S	•	•	•	•	•	•	9	
S80 (07-)	2009		TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009		B6304T2	•	•	•	•	•	•	9	
S80 (07-)	2009		TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009	ECM	B5254T8	•	•	•	•	•	•	74, 79	
S80 (07-)	2009	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2009	ECM	B5254T6	•	•	•	•	•	•	74, 79	
S80 (07-)	2009	ECM	B4204S4	•	•	•	•	•	•	79	
S80 (07-)	2009		B4204S3	•	•	•	•	•	•	79	
S80 (07-)	2009	SUM		•	•	•	•	•	•	10	
S80 (07-)	2009			•	•	•	•	0	0		
S80 (07-)	2009			•	•	•	•	•	•		
S80 (07-)		HLDF		•	•	•	•	•	0		
S80 (07-)	2009			•	•	•	•	•	0		
S80 (07-)	2009			•	•	•	•	•	•	12, 13	
S80 (07-)	2009			•	•	•	•	•	•	12, 13	
S80 (07-)	2009			•	•	•	•	•	0	14	
S80 (07-)	2009			•	•	•	•	•	0	16, 17	
S80 (07-)	2009			•	•	•	•	0	0		
S80 (07-)	2009			•	•	•	•	•	•		
S80 (07-)	2009	HCM		•	•	•	•	•	0	23	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2009			•	•	•	•	•	•	10	
S80 (07-)	2009			•	•	•	•	•	0		
S80 (07-)	2009	SRS		•	•	•	•	•	0	25, 26, 27	
S80 (07-)	2009	CCM		•	•	•	•	•	•	28, 29, 30, 31, 32	
S80 (07-)	2009			•	•	•	•	•	•	35, 39	
S80 (07-)	2009			•	•	•	•	•	0		
S80 (07-)	2009			•	•	•	•	•	0	43	
S80 (07-)	2009	FSM		•	•	•	•	•	0		
S80 (07-)	2009	DIM		•	•	•	•	•	0	47, 48, 49, 50, 51, 52	
S80 (07-)	2009	PAC		•	•	•	•	•	0		
S80 (07-)		RDAR		•	•	•	•	0	0		
S80 (07-)	2009			•	•	•	•	0	0		
S80 (07-)	2009			•	•	•	•	•	•		
S80 (07-)	2009			•	•	•	•	•	0		
S80 (07-)	2009	PHM		•	•	•	•	•	0		
S60	2009	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
S60	2009	DEM	M66 AWD	•	•	•	•	•	0		
S60	2009	DEM	M58	•	•	•	•	•	0		
S60	2009	ECM	D5244T7	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2009	ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2009	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2009		B5254T2	•	•	•	•	•	•	74	
S60	2009		B5244T5	•	•	•	•	•	•	74	
S60	2009		B5244S2	•	•	•	•	•	•		
S60	2009		B5244S	•	•	•	•	•	•		
S60	2009	ECM	B5204T5	•	•	•	•	•	•	74	
S60	2009		AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S60	2009	DEM	AW50/51 AWD	•	•	•	•	•	0		
S60	2009	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2009	AUM		•	•	•	•	•	0	T dilotion	
S60	2009			•	•	•	•	•	•	86, 87	
S60	2009			•	•	•	•	•	0	95	
S60	2009			•	•	•	•	•	•	107	
S60	2009			•	•	•	•	•	•	107, 108	
S60	2009	PDM		•	•	•	•	•	•	108	
S60	2009	SUM		•	•	•	•	•	•		
S60	2009			•	•	•	•	•	•		
S60	2009			•	•	•	•	•	•		
S60	2009			•	0	0	0	•	0	111, 112	
S60	2009	RTI		•	•	•	•	0	0		
S60	2009			•	•	•	•	•	0		
S60	2009	HCM		•	•	•	•	•	0		
S60	2009	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
S60	2009	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47, 118	
S60	2009	UEM		•	•	•	•	•	•		
S60	2009	PHM		•	•	•	•	•	0		
S60	2009			•	•	•	•	•	•	91, 92, 94, 95, 96	
S40 (04-)	2009	TCM	MPS6	•	•	•	•	•	0		
S40 (04-)	2009	DEM	M66 AWD	•	•	•	•	•	0		
S40 (04-)	2009	ECM	D5244T9	•	•	•	•	•	•		
S40 (04-)	2009	ECM	D5244T8	•	•	•	•	•	•		
S40 (04-)	2009	ECM	D5244T13	•	•	•	•	•	•		
S40 (04-)	2009	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
S40 (04-)	2009		D4204T	•	•	•	•	•	0		
S40 (04-)	2009		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
S40 (04-)	2009		D4164T	•	•	•	•	•	0		
S40 (04-)	2009		D4164T	•	•	•	•	•	•	69, 141	
S40 (04-)	2009		B5254T7	•	•	•	•	•	•	74	
S40 (04-)	2009		B5244S7	•	•	•	•	•	•	9	
S40 (04-)	2009		B5244S5	•	•	•	•	•	•	9	
S40 (04-)	2009		B5244S4	•	•	•	•	•	•	9	
S40 (04-)	2009		B4204S3	•	•	•	•	•	•	9	
S40 (04-)	2009	ECM	B4184S8	•	•	•	•	•	•	9	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2009	ECM	B4184S11	•	•	•	•	•	•	9	
S40 (04-)	2009	ECM	B4164S3	•	•	•	•	•	•	9	
S40 (04-)	2009	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
S40 (04-)	2009	DEM	AW50/51 AWD	•	•	•	•	•	0		
S40 (04-)	2009	TCM	AW50/51 AWD	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
S40 (04-)	2009	PSM		•	•	•	•	•	•	145	
S40 (04-)	2009			•	•	•	•	•	•	146	
S40 (04-)	2009			•	•	•	•	•	•	147	
S40 (04-)		RDAR		•	•	•	•	•	0		
S40 (04-)	2009			•	•	•	•	•	0		
S40 (04-)	2009	CPM		•	•	•	•	•	•		
S40 (04-)	2009			•	•	•	•	0	0		
S40 (04-)	2009	BPM		•	•	•	•	•	0		
S40 (04-)	2009			•	•	•	•	•	0		
S40 (04-)	2009			•	•	•	•	•	0	95	
S40 (04-)	2009			•	•	•	•	•	•	149, 150	
S40 (04-)	2009			•	•	•	•	•	•	149, 150	
S40 (04-)	2009	AUU		•	•	•	•	•	0		
S40 (04-)	2009			•	•	•	•	•	0	23	
S40 (04-)	2009	BCM		•	•	•	•	•	0	146, 111	
S40 (04-)	2009	CCM		•	•	•	•	0	0	30, 113, 152, 32, 153	
S40 (04-)	2009	SWM		•	•	•	•	•	0		
S40 (04-)	2009	TRM		•	•	•	•	•	0		
S40 (04-)	2009	EPS		•	•	•	•	•	0		
S40 (04-)	2009	IAM		•	•	•	•	•	•		
S40 (04-)	2009	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 35, 162, 95	
S40 (04-)	2009	DIM		•	•	•	•	•	•	48, 161, 118, 46, 165 , 51	
S40 (04-)	2009	ICM		•	•	•	•	•	•	166, 167, 168	
S40 (04-)	2009	MMM		•	•	•	•	0	0		
C70 (06-)	2009		MPS6	•	•	•	•	•	0		
C70 (06-)	2009		D5244T9	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2009		D5244T8	•	•	•	•	•	•		
C70 (06-)	2009	ECM	D5244T13	•	•	•	•	•	•		
C70 (06-)	2009		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
C70 (06-)	2009		D4204T	•	•	•	•	•	0		
C70 (06-)	2009		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
C70 (06-)	2009		B5254T7	•	•	•	•	•	•	74	
C70 (06-)	2009	ECM	B5244S5	•	•	•	•	•	•	9	
C70 (06-)	2009	ECM	B5244S4	•	•	•	•	•	•	9	
C70 (06-)	2009	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
C70 (06-)	2009	AEM		•	•	•	•	•	•	146	
C70 (06-)	2009	KVM		•	•	•	•	•	•	147	
C70 (06-)	2009	RDAR		•	•	•	•	•	0		
C70 (06-)	2009	PHM		•	•	•	•	•	0		
C70 (06-)	2009	CPM		•	•	•	•	•	•		
C70 (06-)	2009	AUD		•	•	•	•	0	0		
C70 (06-)	2009	BPM		•	•	•	•	•	0		
C70 (06-)	2009	PAM		•	•	•	•	•	0		
C70 (06-)	2009	SRS		•	•	•	•	•	0	95	
C70 (06-)	2009	DDM		•	•	•	•	•	•	149, 150	
C70 (06-)	2009	PDM		•	•	•	•	•	•	149, 150	
C70 (06-)	2009	AUU		•	•	•	•	•	0		
C70 (06-)	2009	BCM		•	•	•	•	•	0	146, 111	
C70 (06-)	2009	CCM		•	•	•	•	0	0	30, 113, 152, 32, 153	
C70 (06-)	2009	CRM		•	•	•	•	•	0	174, 176	
C70 (06-)	2009	SWM		•	•	•	•	•	0	·	
C70 (06-)	2009			•	•	•	•	•	0		
C70 (06-)	2009	EPS		•	•	•	•	•	0		
C70 (06-)	2009			•	•	•	•	0	0		
C70 (06-)	2009	IAM		•	•	•	•	•	•		
C70 (06-)	2009	PSL		•	•	•	•	•	•	145	
C70 (06-)	2009	PSR		•	•	•	•	•	•	145	
C70 (06-)	2009	СЕМ		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 35, 162, 95	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
										48, 161, 118, 46, 165	
C70 (06-)	2009	DIM		•	•	•	•	•	•	, 51	
C70 (06-)	2009	ICM		•	•	•	•	•	•	166, 167, 168	
C70 (06-)	2009	MMM		•	•	•	•	0	0	159	
C30	2009	TCM	MPS6	•	•	•	•	•	0		
C30	2009	ECM	D5244T9	•	•	•	•	•	•		
C30	2009		D5244T8	•	•	•	•	•	•		
C30	2009		D5244T13	•	•	•	•	•	•		
C30	2009	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
C30	2009		D4204T	•	•	•	•	•	0		
C30	2009		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
C30	2009		D4164T	•	•	•	•	•	0		
C30	2009		D4164T	•	•	•	•	•	•	69, 141	
C30	2009	ECM	B5254T7	•	•	•	•	•	•	74	
C30	2009	ECM	B5244S4	•	•	•	•	•	•	9	
C30	2009		B4204S3	•	•	•	•	•	•	9	
C30	2009	ECM	B4184S8	•	•	•	•	•	•	9	
C30	2009	ECM	B4184S11	•	•	•	•	•	•	9	
C30	2009	ECM	B4164S3	•	•	•	•	•	•	9	
C30	2009	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
C30	2009	AEM		•	•	•	•	•	•	146	
C30	2009	KVM		•	•	•	•	•	•	147	
C30	2009	RDAR		•	•	•	•	•	0		
C30	2009	PHM		•	•	•	•	•	0		
C30	2009	CPM		•	•	•	•	•	•		
C30	2009	AUD		•	•	•	•	0	0		
C30	2009			•	•	•	•	•	0		
C30	2009			•	•	•	•	•	0		
C30	2009			•	•	•	•	•	0	95	
C30	2009			•	•	•	•	•	•	149, 150	
C30	2009			•	•	•	•	•	•	149, 150	
C30	2009	AUU		•	•	•	•	•	0		
C30	2009	BCM		•	•	•	•	•	0	146, 111	
C30	2009	CCM		•	•	•	•	0	0	30, 113, 152, 32, 153	
C30	2009	SWM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2009	TRM		•	•	D 1€	T-T alle	Data	O	Fulle CTOII	
C30	2009			•	•	•	•	•	0		
C30	2009			•	•	•	•	•	•		
C30	2009	PSL		•		•	•	•	•	145	
C30	2009	PSR		•	•	•	•	•	•	145	
C30	2009	CEM		•	•	•	•	•	•	154, 156, 94, 158, 35 , 95, 159, 160, 162	
C30	2009			•	•	•	•	•	•	48, 161, 46, 165, 118 , 51	
C30	2009			•	•	•	•	•	•	166, 167, 168	
C30	2009	MMM		•	•	•	•	0	0		
XC90	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
XC90	2008	DEM	TF-80SC AWD	•	•	•	•	•	0		
XC90	2008		M66 AWD	•		•	•	•	0		
XC90	2008	BCM	D5244T5	•	•	•	•	•	•	86, 87	
XC90	2008	CEM	D5244T5	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2008	HCM	D5244T5	•	•	•	•	•	0		
XC90	2008	SAS	D5244T5	•		•	•	•	0		
XC90	2008	ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
XC90	2008		TF-80SC AWD	•	•	•	•	•	•	1, 3, 81, 84, 85	
XC90	2008		TF-80SC AWD	•	•	•	•	•	0		
XC90	2008		M66 AWD	•	•	•	•	•	0		
XC90	2008	BCM	D5244T4	•	•	•	•	•	•	86, 87	
XC90	2008	CEM	D5244T4	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2008	HCM	D5244T4	•	•	•	•	•	0		
XC90	2008	SAS	D5244T4	•	•	•	•	•	0		
XC90	2008	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
XC90	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
XC90	2008		TF-80SC AWD	•	•	•	•	•	•		
XC90	2008		B8444S	•	•	•	•	•	•	86, 87	
XC90	2008	ECM	B8444S	•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2008	SAS	B8444S	•	•	•	•	•	0		
XC90	2008	CEM	B8444S	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2008	HCM	B8444S	•	•	•	•	•	0		
XC90	2008		TF-80SC AWD	•	•	•	•	•	•		
XC90	2008		TF-80SC AWD	•	•	•	•	•	•	1, 3, 81, 84, 85	
XC90	2008		B6324S	•	•	•	•	•	•	86, 87	
XC90	2008	SAS	B6324S	•	•	•	•	•	0		
XC90	2008	CEM	B6324S	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2008	HCM	B6324S	•	•	•	•	•	0		
XC90	2008	ECM	B6324S	•	•	•	•	•	•	9	
XC90	2008	DEM	TF-80SC AWD	•	•	•	•	•	0		
XC90	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
XC90	2008	BCM	B5254T2	•	•	•	•	•	•	86, 87	
XC90	2008	CEM	B5254T2	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2008	HCM	B5254T2	•	•	•	•	•	0		
XC90	2008		B5254T2	•	•	•	•	•	0		
XC90	2008		B5254T2	•	•	•	•	•	•	74	
XC90	2008			•	•	•	•	•	0		
XC90	2008			•	•	•	•	•	0	95	
XC90	2008			•	•	•	•	•	•	107	
XC90	2008			•	•	•	•	•	•	107, 108	
XC90	2008			•	•	•	•	•	•	108	
XC90	2008			•	•	•	•	•	•		
XC90	2008			•	•	•	•	•	•		
XC90	2008			•	0	0	0	•	0	111, 112	
XC90		RDAR		•	•	•	•	•	0		
XC90 XC90	2008 2008			•	•	•	•	•	0		
XC90 XC90	2008			•	0	0	0	0	0		
XC90 XC90	2008			•	•	•	•	•	0		
XC90	2008					•	•		0		
XC90	2008			•	•	•	•	•	0	30, 113, 114, 29, 32, 115	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze	Live	Active Test	Special Function	Other
				Inio.		DIC	Frame	Data		116, 117, 28, 46, 47,	
XC90	2008	DIM		•	•	•	•	•	•	118	
XC90	2008	TIEM		•	•	•	•	•	•	119, 120, 128, 122, 1	
				•		•			•	23, 124	
XC90	2008			•	•	•	•	•	•		
XC90	2008			•	•	•	•	0	0		
XC90	2008		TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 85	
XC70 (08-)	2008		TF-80SC AWD	•	•	•	•	•	•		
XC70 (08-)	2008		M66 AWD	•	•	•	•	•	•		
XC70 (08-)	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC70 (08-)	2008	ECM	D5244T5	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
XC70 (08-)	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC70 (08-)	2008	ECM	D5244T4	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
XC70 (08-)	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
XC70 (08-)	2008		B6324S	•	•	•	•	•	•	9	
XC70 (08-)	2008	POT		•	•	•	•	0	0		
XC70 (08-)	2008	SUM		•	•	•	•	•	•	10	
XC70 (08-)	2008	IAM		•	•	•	•	0	0		
XC70 (08-)	2008	PSM		•	•	•	•	•	•		
XC70 (08-)	2008	RDAR		•	•	•	•	0	0		
XC70 (08-)		HLDF		•	•	•	•	•	0		
XC70 (08-)	2008			•	•	•	•	•	0		
XC70 (08-)	2008			•	•	•	•	•	•	12, 13	
XC70 (08-)	2008			•	•	•	•	•	•	12, 13	
XC70 (08-)	2008			•	•	•	•	•	0	14	
XC70 (08-)	2008			•	•	•	•	•	0	16, 17	
XC70 (08-)	2008			•	•	•	•	0	0		
XC70 (08-)	2008			•	•	•	•	•	0		
XC70 (08-)	2008			•	•	•	•	•	•		
XC70 (08-)	2008			•	•	•	•	0	0		
XC70 (08-)	2008			•	•	•	•	•	0	23	
XC70 (08-)	2008			•	•	•	•	•	0	25, 26, 27	
XC70 (08-)	2008			•	•	•	•	•	•	80	
XC70 (08-)	2008			•	•	•	•	•	0		
XC70 (08-)	2008	CEM		•	•	•	•	•	•	35, 39	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2008	DIM		•	•	•	•	•	0	47, 48, 49, 50, 51, 52	
XC70 (08-)	2008	CCM		•	•	•	•	•	•	28, 29, 30, 31, 32	
XC70 (08-)		TRM		•	•	•	•	•	0		
XC70 (08-)		PBM		•	•	•	•	•	0	43	
XC70 (08-)		BPM		•	•	•	•	•	0		
XC70 (08-)		MMM		•	•	•	•	0	0		
XC70 (08-)		FSM		•	•	•	•	•	0		
XC70 (08-)		ICM		•	•	•	•	•	•		
XC70 (08-)	2008			•	•	•	•	•	0		
V70 (08-)		DEM	TF-80SC AWD	•	•	•	•	•	•		
V70 (08-)		DEM	M66 AWD	•	•	•	•	•	•		
V70 (08-)	2008	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2008	ECM	D5244T5	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
V70 (08-)	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2008	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2008	ECM	D5244T4	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
V70 (08-)	2008	ECM	D4204T	•	•	•	•	•	•	69, 70, 71	
V70 (08-)	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)		TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2008	ECM	B6324S	•	•	•	•	•	•	9	
V70 (08-)		TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)	2008		B6304T2	•	•	•	•	•	•	9	
V70 (08-)		TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
V70 (08-)		ECM	B5254T6	•	•	•	•	•	•	74, 79	
V70 (08-)	2008		B4204S4	•	•	•	•	•	•	79	
V70 (08-)		ECM	B4204S3	•	•	•	•	•	•	79	
V70 (08-)	2008			•	•	•	•	0	0		
V70 (08-)	2008			•	•	•	•	•	•	10	
V70 (08-)		IAM		•	•	•	•	0	0		
V70 (08-)		PSM		•	•	•	•	•	•		
V70 (08-)	2008	RDAR		•	•	•	•	0	0		
V70 (08-)	2008	HLDF		•	•	•	•	•	0		
V70 (08-)	2008	AUU		•	•	•	•	•	0		



NOTES:

This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (08-)	2008	DDM		•	•	•	•	•	0	12, 13	
V70 (08-)	2008			•	•	•	•	•	•	12, 13	
V70 (08-)	2008	PAM		•	•	•	•	•	0	14	
V70 (08-)	2008	KVM		•	•	•	•	•	0	16, 17	
V70 (08-)	2008	AUD		•	•	•	•	0	0		
V70 (08-)	2008	PHM		•	•	•	•	•	0		
V70 (08-)	2008	CPM		•	•	•	•	•	•		
V70 (08-)	2008	SUB		•	•	•	•	0	0		
V70 (08-)	2008	HCM		•	•	•	•	•	0	23	
V70 (08-)	2008			•	•	•	•	•	0	25, 26, 27	
V70 (08-)	2008	BCM		•	•	•	•	•	•	80	
V70 (08-)	2008			•	•	•	•	•	0		
V70 (08-)	2008	CEM		•	•	•	•	•	•	35, 39	
V70 (08-)	2008	DIM		•	•	•	•	•	0	47, 48, 49, 50, 51, 52	
V70 (08-)	2008	CCM		•	•	•	•	•	•	28, 29, 30, 31, 32	
V70 (08-)	2008	TRM		•	•	•	•	•	0		
V70 (08-)	2008	PBM		•	•	•	•	•	0	43	
V70 (08-)	2008	BPM		•	•	•	•	•	0		
V70 (08-)	2008	MMM		•	•	•	•	0	0		
V70 (08-)	2008	FSM		•	•	•	•	•	0		
V70 (08-)	2008	ICM		•	•	•	•	•	•		
V70 (08-)	2008	PAC		•	•	•	•	•	0		
V70 (00-08)	2008	DEM	TF-80SC AWD	•	•	•	•	•	0		
V70 (00-08)	2008	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
V70 (00-08)	2008	DEM	M66 AWD	•	•	•	•	•	0		
V70 (00-08)	2008	ECM	D5244T7	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
V70 (00-08)	2008	ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
V70 (00-08)	2008	ECM	B5254T2	•	•	•	•	•	•	74	
V70 (00-08)	2008		B5244SG	•	0	0	0	•	0		
V70 (00-08)	2008		B5244SG	•	•	•	•	•	•		
V70 (00-08)	2008		B5244S2	•	•	•	•	•	•		
V70 (00-08)	2008	ECM	B5244S	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-08)	2008	DEM	AW55-50/51SN	•	•	•	•	•	0		
V70 (00-08)	2008	TCM	AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
V70 (00-08)	2008	DEM	AW50/51 AWD	•	•	•	•	•	0		
V70 (00-08)	2008	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
V70 (00-08)	2008	PHM		•	•	•	•	•	0		
V70 (00-08)	2008	AUM		•	•	•	•	•	0		
V70 (00-08)		BCM		•	•	•	•	•	•	86, 87	
V70 (00-08)	2008	SRS		•	•	•	•	•	0	95	
V70 (00-08)	2008	PSM		•	•	•	•	•	•	107	
V70 (00-08)		DDM		•	•	•	•	•	•	107, 108	
V70 (00-08)		PDM		•	•	•	•	•	•	108	
V70 (00-08)	2008	SUM		•	•	•	•	•	•		
V70 (00-08)	2008	AEM		•	•	•	•	•	•		
V70 (00-08)	2008	REM		•	•	•	•	•	•		
V70 (00-08)	2008	CPM		•	0	0	0	•	0	111, 112	
V70 (00-08)	2008	CEM		•	•	•	•	•	•	91, 92, 94, 95, 96	
V70 (00-08)	2008	HCM		•	•	•	•	•	0		
V70 (00-08)	2008	RTI		•	•	•	•	0	0		
V70 (00-08)	2008	SAS		•	•	•	•	•	0		
V70 (00-08)	2008	AUU		•	•	•	•	•	0		
V70 (00-08)	2008	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
V70 (00-08)	2008	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47, 118	
V70 (00-08)	2008	UEM		•	•	•	•	•	•		
V50		TCM	MPS6	•	•	•	•	•	0		
V50		DEM	M66 AWD	•	•	•	•	•	0		
V50		ECM	D5244T9	•	•	•	•	•	•		
V50		ECM	D5244T8	•	•	•	•	•	•		
V50	2008	ECM	D5244T13	•	•	•	•	•	•		
V50	2008	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
V50	2008	ADM	D4204T	•	•	•	•	•	0		
V50	2008	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
V50	2008	ADM	D4164T	•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2008	ECM	D4164T	•	•	•	•	•	•	69, 141	
V50	2008	ECM	B5254T7	•	•	•	•	•	•	74	
V50	2008	ECM	B5244S7	•	•	•	•	•	•	9	
V50	2008	ECM	B5244S5	•	•	•	•	•	•	9	
V50	2008		B5244S4	•	•	•	•	•	•	9	
V50	2008	ECM	B4204S3	•	•	•	•	•	•	9	
V50	2008		B4184S8	•	•	•	•	•	•	9	
V50	2008		B4184S11	•	•	•	•	•	•	9	
V50	2008	ECM	B4164S3	•	•	•	•	•	•	9	
V50	2008	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
V50	2008	DEM	AW50/51 AWD	•	•	•	•	•	0		
V50	2008	TCM	AW50/51 AWD	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
V50	2008	BCM		•	•	•	•	•	0	146, 111	
V50	2008	PSM		•	•	•	•	•	•	145	
V50	2008	AEM		•	•	•	•	•	•	146	
V50	2008	KVM		•	•	•	•	•	•	147	
V50	2008	RDAR		•	•	•	•	•	0		
V50	2008	CPM		•	•	•	•	•	•		
V50	2008			•	•	•	•	0	0		
V50	2008			•	•	•	•	•	0		
V50	2008			•	•	•	•	•	0	95	
V50	2008			•	•	•	•	•	•	149, 150	
V50	2008	PDM		•	•	•	•	•	•	149, 150	
V50	2008			•	•	•	•	•	0		
V50	2008	HCM		•	•	•	•	•	0	23	
V50	2008	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
V50	2008	PHM		•	•	•	•	•	0		
V50	2008	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95, 35	
V50	2008			•	•	•	•	•	•	48, 161, 118, 46, 165 , 51	
V50	2008			•	•	•	•	•	0		
V50	2008	TRM		•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2008	EPS		•	•	•	•	•	0		
V50	2008	IAM		•	•	•	•	•	•		
V50	2008	ICM		•	•	•	•	•	•	166, 167, 168	
V50	2008	MMM		•	•	•	•	0	0		
S80 (07-)	2008	DEM	TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2008	DEM	M66 AWD	•	•	•	•	•	•		
S80 (07-)	2008	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	D5244T5	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
S80 (07-)	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2008	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	D5244T4	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
S80 (07-)	2008	ECM	D4204T	•	•	•	•	•	•	69, 70, 71	
S80 (07-)	2008	TCM	B8444S	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2008		B8444S	•	•	•	•	•	•	9	
S80 (07-)	2008	TCM	B6324S	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2008		B6324S	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	B6324S	•	•	•	•	•	•	9	
S80 (07-)	2008	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	B6304T2	•	•	•	•	•	•	9	
S80 (07-)	2008	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	B5254T6	•	•	•	•	•	•	74, 79	
S80 (07-)	2008	ECM	B4204S4	•	•	•	•	•	•	79	
S80 (07-)	2008	ECM	B4204S3	•	•	•	•	•	•	79	
S80 (07-)	2008	SUM		•	•	•	•	•	•	10	
S80 (07-)	2008			•	•	•	•	0	0		
S80 (07-)	2008			•	•	•	•	•	•		
S80 (07-)		RDAR		•	•	•	•	0	0		
S80 (07-)		HLDF		•	•	•	•	•	0		
S80 (07-)	2008			•	•	•	•	•	0		
S80 (07-)	2008			•	•	•	•	•	•	12, 13	
S80 (07-)	2008			•	•	•	•	•	•	12, 13	
S80 (07-)	2008			•	•	•	•	•	0	14	
S80 (07-)	2008			•	•	•	•	•	0	16, 17	
S80 (07-)	2008			•	•	•	•	0	0		
S80 (07-)	2008	PHM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2008			•	•	•	•	•	•		
S80 (07-)	2008			•	•	•	•	•	0	23	
S80 (07-)	2008			•	•	•	•	•	•	80	
S80 (07-)	2008			•	•	•	•	•	0		
S80 (07-)	2008			•	•	•	•	•	0	25, 26, 27	
S80 (07-)	2008	CEM		•	•	•	•	•	•	35, 39	
S80 (07-)	2008	DIM		•	•	•	•	•	0	47, 48, 49, 50, 51, 52	
S80 (07-)	2008	CCM		•	•	•	•	•	•	28, 29, 30, 31, 32	
S80 (07-)	2008	TRM		•	•	•	•	•	0		
S80 (07-)	2008			•	•	•	•	•	0	43	
S80 (07-)	2008	BPM		•	•	•	•	•	0		
S80 (07-)	2008	MMM		•	•	•	•	0	0		
S80 (07-)	2008	FSM		•	•	•	•	•	0		
S80 (07-)	2008	ICM		•	•	•	•	•	•		
S80 (07-)	2008	PAC		•	•	•	•	•	0		
S60	2008	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
S60	2008	DEM	M66 AWD	•	•	•	•	•	0		
S60	2008	DEM	M58	•	•	•	•	•	0		
S60	2008	ECM	D5244T7	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2008	ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2008	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2008		B5254T2	•	•	•	•	•	•	74	
S60	2008		B5244T5	•	•	•	•	•	•	74	
S60	2008		B5244SG	•	0	0	0	•	0		
S60	2008		B5244SG	•	•	•	•	•	•		
S60	2008		B5244S2	•	•	•	•	•	•		
S60	2008		B5244S	•	•	•	•	•	•		
S60	2008	ECM	B5204T5	•	•	•	•	•	•	74	
S60	2008	TCM	AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S60	2008	DEM	AW50/51 AWD	•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2008	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S60	2008	AUM		•	•	•	•	•	0		
S60	2008	BCM		•	•	•	•	•	•	86, 87	
S60	2008	SRS		•	•	•	•	•	0	95	
S60	2008			•	•	•	•	•	•	107	
S60	2008			•	•	•	•	•	•	107, 108	
S60	2008	PDM		•	•	•	•	•	•	108	
S60	2008			•	•	•	•	•	•		
S60	2008			•	•	•	•	•	•		
S60	2008	PHM		•	•	•	•	•	0		
S60	2008			•	•	•	•	•	•		
S60	2008	CPM		•	0	0	0	•	0	111, 112	
S60	2008	CEM		•	•	•	•	•	•	91, 92, 94, 95, 96	
S60	2008	HCM		•	•	•	•	•	0		
S60	2008	RTI		•	•	•	•	0	0		
S60	2008	SAS		•	•	•	•	•	0		
S60	2008	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
S60	2008	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47, 118	
S60	2008	UEM		•	•	•	•	•	•		
S40 (04-)		TCM	MPS6	•	•	•	•	•	0		
S40 (04-)	2008	DEM	M66 AWD	•	•	•	•	•	0		
S40 (04-)	2008	ECM	D5244T9	•	•	•	•	•	•		
S40 (04-)	2008	ECM	D5244T8	•	•	•	•	•	•		
S40 (04-)	2008	ECM	D5244T13	•	•	•	•	•	•		
S40 (04-)	2008	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
S40 (04-)	2008		D4204T	•	•	•	•	•	0		
S40 (04-)	2008		D4204T	•		•	•	•	•	71, 9, 141, 69	
S40 (04-)	2008		D4164T	•	•	•	•	•	0		
S40 (04-)	2008		D4164T	•	•	•	•	•	•	69, 141	
S40 (04-)	2008		B5254T7	•	•	•	•	•	•	74	
S40 (04-)	2008		B5254T3	•	•	•	•	•	•	74	
S40 (04-)	2008		B5244S7	•	•	•	•	•	•	9	
S40 (04-)	2008	ECM	B5244S5	•	•	•	•	•	•	9	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2008		B5244S4	•	•	•	•	•	•	9	
S40 (04-)	2008		B4204S3	•	•	•	•	•	•	9	
S40 (04-)	2008		B4184S8	•	•	•	•	•	•	9	
S40 (04-)	2008		B4184S11	•	•	•	•	•	•	9	
S40 (04-)	2008	ECM	B4164S3	•	•	•	•	•	•	9	
S40 (04-)	2008	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
S40 (04-)	2008	DEM	AW50/51 AWD	•	•	•	•	•	0		
S40 (04-)	2008	TCM	AW50/51 AWD	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
S40 (04-)	2008	BCM		•	•	•	•	•	0	146, 111	
S40 (04-)	2008			•	•	•	•	•	•	145	
S40 (04-)	2008			•	•	•	•	•	•	146	
S40 (04-)	2008			•	•	•	•	•	•	147	
S40 (04-)	2008	RDAR		•	•	•	•	•	0		
S40 (04-)	2008	CPM		•	•	•	•	•	•		
S40 (04-)	2008	AUD		•	•	•	•	0	0		
S40 (04-)	2008	PAM		•	•	•	•	•	0		
S40 (04-)	2008			•	•	•	•	•	0	95	
S40 (04-)	2008			•	•	•	•	•	•	149, 150	
S40 (04-)	2008			•	•	•	•	•	•	149, 150	
S40 (04-)	2008			•	•	•	•	•	0		
S40 (04-)	2008	HCM		•	•	•	•	•	0	23	
S40 (04-)	2008	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
S40 (04-)	2008	PHM		•	•	•	•	•	0		
S40 (04-)	2008	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 35, 162, 95	
S40 (04-)	2008	DIM		•	•	•	•	•	•	48, 161, 118, 46, 165 , 51	
S40 (04-)	2008	SWM		•	•	•	•	•	0		
S40 (04-)	2008			•	•	•	•	•	0		
S40 (04-)	2008			•	•	•	•	•	0		
S40 (04-)	2008	IAM		•	•	•	•	•	•		
S40 (04-)	2008			•	•	•	•	•	•	166, 167, 168	
S40 (04-)	2008	MMM		•	•	•	•	0	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	0ther
C70 (06-)	2008	ECM	D5244T9	•	•	•	•	•	•		
C70 (06-)	2008	ECM	D5244T8	•	•	•	•	•	•		
C70 (06-)	2008	ECM	D5244T13	•	•	•	•	•	•	94	
C70 (06-)	2008	ADM	D4204T	•	•	•	•	•	0		
C70 (06-)	2008		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
C70 (06-)	2008	ECM	B5254T7	•	•	•	•	•	•	74	
C70 (06-)	2008		B5244S5	•	•	•	•	•	•	9	
C70 (06-)	2008	ECM	B5244S4	•	•	•	•	•	•	9	
C70 (06-)	2008	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
C70 (06-)	2008	BCM		•	•	•	•	•	0	146, 111	
C70 (06-)	2008			•	•	•	•	•	•	146	
C70 (06-)	2008			•	•	•	•	•	•	147	
C70 (06-)	2008			•	•	•	•	•	0		
C70 (06-)	2008			•	•	•	•	•	•		
C70 (06-)	2008	AUD		•	•	•	•	0	0		
C70 (06-)	2008	PAM		•	•	•	•	•	0		
C70 (06-)	2008			•	•	•	•	•	0	95	
C70 (06-)	2008			•	•	•	•	•	•	149, 150	
C70 (06-)	2008	PDM		•	•	•	•	•	•	149, 150	
C70 (06-)	2008	PSL		•	•	•	•	•	•	145	
C70 (06-)	2008	PSR		•	•	•	•	•	•	145	
C70 (06-)	2008			•	•	•	•	•	0		
C70 (06-)	2008	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
C70 (06-)	2008	PHM		•	•	•	•	•	0		
C70 (06-)	2008			•	•	•	•	•	0	174, 176	
C70 (06-)	2008	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 35, 162, 95	
C70 (06-)	2008	DIM		•	•	•	•	•	•	48, 161, 118, 46, 165 , 51	
C70 (06-)	2008	SWM		•	•	•	•	•	0		
C70 (06-)	2008			•	•	•	•	•	0		
C70 (06-)	2008	EPS		•	•	•	•	•	0		
C70 (06-)	2008	SUB		•	•	•	•	0	0		
C70 (06-)	2008			•	•	•	•	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2008	ICM		•	•	•	•	•	•	166, 167, 168	
C70 (06-)	2008			•	•	•	•	0	0		
C30	2008	TCM	MPS6	•	•	•	•	•	0		
C30	2008	ECM	D5244T9	•	•	•	•	•	•		
C30	2008		D5244T8	•	•	•	•	•	•		
C30	2008	ECM	D5244T13	•	•	•	•	•	•		
C30	2008	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
C30	2008	ADM	D4204T	•	•	•	•	•	0		
C30	2008	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
C30	2008	ADM	D4164T	•	•	•	•	•	0		
C30	2008	ECM	D4164T	•	•	•	•	•	•	69, 141	
C30	2008	ECM	B5254T7	•	•	•	•	•	•	74	
C30	2008	ECM	B5244S4	•	•	•	•	•	•	9	
C30	2008	ECM	B4204S3	•	•	•	•	•	•	9	
C30	2008	ECM	B4184S8	•	•	•	•	•	•	9	
C30	2008	ECM	B4184S11	•	•	•	•	•	•	9	
C30	2008	ECM	B4164S3	•	•	•	•	•	•	9	
C30	2008	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
C30	2008	BCM		•	•	•	•	•	0	146, 111	
C30	2008	KVM		•	•	•	•	•	•	147	
C30	2008	RDAR		•	•	•	•	•	0		
C30	2008	CPM		•	•	•	•	•	•		
C30	2008	AUD		•	•	•	•	0	0		
C30	2008	PAM		•	•	•	•	•	0		
C30	2008	SRS		•	•	•	•	•	0	95	
C30	2008	DDM		•	•	•	•	•	•	149, 150	
C30	2008	PDM		•	•	•	•	•	•	149, 150	
C30	2008	PSL		•	•	•	•	•	•	145	
C30	2008	PSR		•	•	•	•	•	•	145	
C30	2008	AUU		•	•	•	•	•	0		
C30	2008	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
C30	2008	PHM		•	•	•	•	•	0		
C30	2008	СЕМ		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 35, 162, 95	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2008	DIM		•	•	•	•	•	•	48, 161, 46, 165, 118 , 51	
C30	2008	SWM		•	•	•	•	•	0		
C30	2008			•	•	•	•	•	0		
C30	2008			•	•	•	•	•	0		
C30	2008			•	•	•	•	•	•		
C30	2008			•	•	•	•	•	•	166, 167, 168	
C30	2008			•	•	•	•	0	0		
XC90	2007		TF-80SC AWD	•	•	•	•	•	•	1, 3, 81, 84, 85	
XC90	2007		TF-80SC AWD	•	•	•	•	•	0		
XC90	2007		M66 AWD	•	•	•	•	•	0		
XC90	2007	BCM	D5244T4	•	•	•	•	•	•	86, 87	
XC90	2007	CEM	D5244T4	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2007	HCM	D5244T4	•	•	•	•	•	0		
XC90	2007	SAS	D5244T4	•	•	•	•	•	0		
XC90	2007	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
XC90	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
XC90	2007	DEM	TF-80SC AWD	•	•	•	•	•	•		
XC90	2007		B8444S	•	•	•	•	•	•	86, 87	
XC90	2007	SAS	B8444S	•	•	•	•	•	0		
XC90	2007	CEM	B8444S	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2007	HCM	B8444S	•	•	•	•	•	0		
XC90	2007	ECM	B8444S	•	•	•	•	•	•		
XC90	2007	DEM	TF-80SC AWD	•	•	•	•	•	•		
XC90	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 3, 81, 84, 85	
XC90	2007	BCM	B6324S	•	•	•	•	•	•	86, 87	
XC90	2007	SAS	B6324S	•	•	•	•	•	0		
XC90	2007	CEM	B6324S	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2007	HCM	B6324S	•	•	•	•	•	0		
XC90	2007	ECM	B6324S	•	•	•	•	•	•	9	
XC90	2007	DEM	M66 AWD	•	•	•	•	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2007	TCM	AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
XC90	2007	DEM	AW50/51 AWD	•	•	•	•	•	0		
XC90	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
XC90	2007	BCM	B5254T2	•	•	•	•	•	•	86, 87	
XC90	2007	CEM	B5254T2	•	•	•	•	•	•	91, 92, 94, 95, 96	
XC90	2007	HCM	B5254T2	•	•	•	•	•	0		
XC90	2007	SAS	B5254T2	•	•	•	•	•	0		
XC90	2007		B5254T2	•	•	•	•	•	•	74	
XC90	2007			•	•	•	•	•	0		
XC90	2007			•	•	•	•	•	0	95	
XC90	2007			•	•	•	•	•	•	107	
XC90	2007			•	•	•	•	•	•	107, 108	
XC90	2007	PDM		•	•	•	•	•	•	108	
XC90	2007	AEM		•	•	•	•	•	•		
XC90	2007	PHM		•	•	•	•	•	0		
XC90	2007			•	•	•	•	•	•		
XC90	2007	CPM		•	0	0	0	•	0	111, 112	
XC90	2007	RDAR		•	•	•	•	•	0		
XC90	2007	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
XC90	2007	IAM		•	•	•	•	•	•		
XC90	2007	AUD		•	•	•	•	0	0		
XC90	2007	PAC		•	0	0	0	0	0		
XC90	2007	MMM		•	•	•	•	0	0		
XC90	2007	AUU		•	•	•	•	•	0		
XC90	2007	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47, 118	
XC90	2007	UEM		•	•	•	•	•	•	119, 120, 128, 122, 1 23, 124	
XC90	2007	ICM		•	•	•	•	•	•		
XC90	2007		TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 85	
V70 (00-08)	2007		TF-80SC AWD	•	•	•	•	•	0		
V70 (00-08)	2007		M66 AWD	•	•	•	•	•	0		
V70 (00-08)	2007	DEM	M58	•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
770 (00-08)	2007	ECM	D5244T7	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
770 (00-08)	2007	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
770 (00-08)	2007	ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
70 (00-08)	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
70 (00-08)	2007	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
70 (00-08)	2007	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
770 (00-08)	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
770 (00-08)	2007	ECM	B5254T4	•	•	•	•	•	•	74	
70 (00-08)	2007		B5254T2	•	•	•	•	•	•	74	
70 (00-08)	2007	ECM	B5244T5	•	•	•	•	•	•	74	
70 (00-08)	2007	ETM	B5244SG	•	0	0	0	•	0		
70 (00-08)	2007	ECM	B5244SG	•	•	•	•	•	•		
70 (00-08)	2007	ECM	B5244S2	•	•	•	•	•	•		
70 (00-08)	2007	ECM	B5244S	•	•	•	•	•	•		
70 (00-08)	2007	ECM	B5204T5	•	•	•	•	•	•	74	
770 (00-08)	2007	TCM	AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
770 (00-08)	2007	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
70 (00-08)	2007		AW50/51 AWD	•	•	•	•	•	0		
70 (00-08)	2007			•		•	•	•	0		
70 (00-08)	2007			•	•	•	•	•	0		
70 (00-08)	2007			•	•	•	•	•	•	86, 87	
70 (00-08)	2007			•	•	•	•	•	0	95	
70 (00-08)	2007			•	•	•	•	•	•	107	
70 (00-08)	2007			•	•	•	•	•	•	107, 108	
70 (00-08)	2007			•	•	•	•	•	•	108	
70 (00-08)	2007			•	•	•	•	•	•		
770 (00-08)	2007			•	•	•	•	•	•		
V70 (00-08)	2007			•	•	•	•	•	•		
V70 (00-08)	2007	CPM		•	0	0	0	•	0	111, 112	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-08)	2007	СЕМ		•	•	•	•	•	•	91, 92, 94, 95, 96	
V70 (00-08)	2007	HCM		•	•	•	•	•	0		
V70 (00-08)	2007	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
V70 (00-08)	2007			•	•	•	•	0	0		
V70 (00-08)	2007			•	•	•	•	•	0	116, 117, 28, 46, 47,	
V70 (00-08)	2007	DIM		•	•	•	•	•	•	118	
V70 (00-08)	2007	UEM		•	•	•	•	•	•		
V70 XC(01-)/XC70(-07)	2007	DEM	TF-80SC AWD	•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2007	DEM	M66 AWD	•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2007	DEM	M58	•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
V70 XC (01-) /XC70 (-07)	2007	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
V70 XC(01-)/XC70(-07)	2007	ECM	B5254T2	•	•	•	•	•	•	74	
V70 XC (01-) /XC70 (-07)	2007	DEM	AW50/51 AWD	•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2007	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
V70 XC(01-)/XC70(-07)	2007	РНМ		•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2007	AUM		•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2007	BCM		•	•	•	•	•	•	86, 87	
V70 XC(01-)/XC70(-07)	2007	SRS		•	•	•	•	•	0	95	
V70 XC(01-)/XC70(-07)	2007	PSM		•	•	•	•	•	•	107	
V70 XC(01-)/XC70(-07)	2007	DDM		•	•	•	•	•	•	107, 108	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70(-07)	2007	PDM		•	•	•	•	•	•	108	
V70 XC(01-)/XC70(-07)	2007	SUM		•	•	•	•	•	•		
V70 XC(01-)/XC70(-07)	2007	AEM		•	•	•	•	•	•		
V70 XC(01-)/XC70(-07)	2007	REM		•	•	•	•	•	•		
V70 XC(01-)/XC70(-07)	2007	СРМ		•	0	0	0	•	0	111, 112	
V70 XC(01-)/XC70(-07)	2007	CEM		•	•	•	•	•	•	91, 92, 94, 95, 96	
V70 XC(01-)/XC70(-07)	2007	НСМ		•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2007	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
V70 XC(01-)/XC70(-07)	2007	RTI		•	•	•	•	0	0		
V70 XC(01-)/XC70(-07)	2007	SAS		•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2007	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47, 118	
V70 XC(01-)/XC70(-07)	2007	UEM		•	•	•	•	•	•		
V50	2007		M66 AWD	•	•	•	•	•	0		
V50	2007		D5244T9	•	•	•	•	•	•		
V50	2007	ECM	D5244T8	•	•	•	•	•	•		
V50	2007	ADM	D4204T	•	•	•	•	•	0		
V50	2007	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
V50	2007	ADM	D4164T	•	•	•	•	•	0		
V50	2007	ECM	D4164T	•	•	•	•	•	•	69, 141, 169	
V50	2007	ECM	B5254T3	•	•	•	•	•	•	74	
V50	2007		B5244S7	•	•	•	•	•	•	9	
V50	2007	ECM	B5244S5	•	•	•	•	•	•	9	
V50	2007	ECM	B5244S4	•	•	•	•	•	•	9	
V50	2007	ECM	B4204S3	•	•	•	•	•	•	9	
V50	2007	ECM	B4184S8	•	•	•	•	•	•	9	
V50	2007	ECM	B4184S11	•	•	•	•	•	•	9	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2007	ECM	B4164S3	•	•	•	•	•	•	9	
V50	2007	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
V50	2007	DEM	AW50/51 AWD	•	•	•	•	•	0		
V50	2007	TCM	AW50/51 AWD	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
V50	2007			•	•	•	•	•	0		
V50	2007			•	•	•	•	•	0	146, 111	
V50	2007			•	•	•	•	•	•	145	
V50	2007			•	•	•	•	•	0		
V50	2007			•	•	•	•	•	0		
V50	2007			•	•	•	•	•	•	147	
V50	2007			•	•	•	•	•	•	146	
V50	2007			•	•	•	•	•	0		
V50	2007	TRM		•	•	•	•	•	0		
V50	2007	СЕМ		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95	
V50	2007	MMM		•	•	•	•	0	0		
V50	2007	RDAR		•	•	•	•	•	0		
V50	2007	CPM		•	•	•	•	•	•		
V50	2007	IAM		•	•	•	•	•	•		
V50	2007	AUD		•	•	•	•	0	0		
V50	2007	PAM		•	•	•	•	•	0		
V50	2007	DDM		•	•	•	•	•	•	149, 150	
V50	2007			•	•	•	•	•	•	149, 150	
V50	2007	SRS		•	•	•	•	•	0	95	
V50	2007	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
V50	2007	DIM		•	•	•	•	•	•	48, 161, 118, 46, 165	
V50	2007	ICM		•	•	•	•	•	•	166, 167	
V50	2007			•	•	•	•	•	0		
S80 (07-)	2007	DEM	TF-80SC AWD	•	•	•	•	•	•		
S80 (07-)	2007	ECM	B5254T6	•	•	•	•	•	•	74, 79	
S80 (07-)	2007			•	•	•	•	•	•	10	
S80 (07-)	2007	PSM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2007	HLDF		•	•	•	•	•	0		
S80 (07-)	2007	AUU		•	•	•	•	•	0		
S80 (07-)	2007			•	•	•	•	•	•	12, 13	
S80 (07-)	2007			•	•	•	•	•	•	12, 13	
S80 (07-)	2007			•	•	•	•	•	0	14	
S80 (07-)	2007			•	•	•	•	•	0	16, 17	
S80 (07-)	2007			•	•	•	•	0	0		
S80 (07-)	2007			•	•	•	•	•	0		
S80 (07-)	2007			•	•	•	•	•	•		
S80 (07-)	2007			•	•	•	•	•	0	23	
S80 (07-)	2007	SAS		•	•	•	•	•	0		
S80 (07-)	2007	CCM		•	•	•	•	•	•	28, 29, 30, 31, 32	
S80 (07-)	2007	TRM		•	•	•	•	•	0		
S80 (07-)	2007	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2007	ECM	D5244T5	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
S80 (07-)	2007	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2007	ECM	D5244T4	•	•	•	•	•	•	58, 59, 60, 61, 62, 63 , 90, 64	
S80 (07-)	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2007	ECM	B8444S	•	•	•	•	•	•	9	
S80 (07-)	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2007	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2007	ECM	B6324S	•	•	•	•	•	•	9	
S80 (07-)	2007	TCM	TF-80SC	•	•	•	•	•	•	1, 2, 3, 4, 5	
S80 (07-)	2007	BCM		•	•	•	•	•	•	10	
S80 (07-)	2007	FSM		•	•	•	•	•	0		
S80 (07-)	2007			•	•	•	•	0	0		
S80 (07-)	2007			•	•	•	•	•	0		
S80 (07-)		RDAR		•	•	•	•	0	0		
S80 (07-)	2007			•	•	•	•	•	•		
S80 (07-)	2007			•	•	•	•	•	0	25, 26, 27	
S80 (07-)	2007			•	•	•	•	•	0	43	
S80 (07-)	2007			•	•	•	•	•	•	35, 39	
S80 (07-)	2007	BPM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2007	DIM		•	•	•	•	•	0	47, 48, 49, 50, 51, 52	
S80 (07-)	2007	MMM		•	•	•	•	0	0		
S60	2007		TF-80SC AWD	•	•	•	•	•	0		
S60	2007	DEM	M66 AWD	•	•	•	•	•	0		
S60	2007	DEM	M58	•	•	•	•	•	0		
S60	2007	ECM	D5244T7	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2007	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
S60	2007	ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2007	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
S60	2007	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2007	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
S60	2007	ECM	B5254T4	•	•	•	•	•	•	74	
S60	2007		B5254T2	•	•	•	•	•	•	74	
S60	2007		B5244T5	•	•	•	•	•	•	74	
S60	2007		B5244SG	•	0	0	0	•	0		
S60	2007		B5244SG	•	•	•	•	•	•		
S60	2007		B5244S2	•	•	•	•	•	•		
S60	2007		B5244S	•	•	•	•	•	•		
S60	2007	ECM	B5204T5	•	•	•	•	•	•	74	
S60	2007		AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S60	2007	DEM	AW50/51 AWD	•	•	•	•	•	0		
S60	2007		AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S60	2007			•	•	•	•	•	0		
S60	2007			•	•	•	•	•	•	86, 87	
S60	2007			•	•	•	•	•	0	95	
S60	2007			•	•	•	•	•	•	107	
S60	2007			•	•	•	•	•	•	107, 108	
S60	2007			•	•	•	•	•	•	108	
S60	2007	SUM		•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.
- As for special function please refer to the special function table.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2007			•	•	•	•	•	•		
S60	2007			•	•	•	•	•	0		
S60	2007			•	•	•	•	•	•		
S60	2007	CPM		•	0	0	0	•	0	111, 112	
S60	2007	CEM		•	•	•	•	•	•	91, 92, 94, 95, 96	
S60	2007	HCM		•	•	•	•	•	0		
S60	2007	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
S60	2007	RTI		•	•	•	•	0	0		
S60	2007	SAS		•	•	•	•	•	0		
S60	2007	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47	
S60	2007	UEM		•	•	•	•	•	•		
S40 (04-)	2007	DEM	M66 AWD	•	•	•	•	•	0		
S40 (04-)	2007	ECM	D5244T9	•	•	•	•	•	•		
S40 (04-)	2007	ECM	D5244T8	•	•	•	•	•	•		
S40 (04-)	2007	ADM	D4204T	•	•	•	•	•	0		
S40 (04-)	2007	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
S40 (04-)	2007		D4164T	•	•	•	•	•	0		
S40 (04-)	2007		D4164T	•	•	•	•	•	•	69, 141, 169	
S40 (04-)	2007		B5254T3	•	•	•	•	•	•	74	
S40 (04-)	2007	ECM	B5244S7	•	•	•	•	•	•	9	
S40 (04-)	2007		B5244S5	•	•	•	•	•	•	9	
S40 (04-)	2007		B5244S4	•	•	•	•	•	•	9	
S40 (04-)	2007		B4204S3	•	•	•	•	•	•	9	
S40 (04-)	2007		B4184S8	•	•	•	•	•	•	9	
S40 (04-)	2007		B4184S11	•	•	•	•	•	•	9	
S40 (04-)	2007	ECM	B4164S3	•	•	•	•	•	•	9	
S40 (04-)	2007	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
S40 (04-)	2007	DEM	AW50/51 AWD	•	•	•	•	•	0		
S40 (04-)	2007		AW50/51 AWD	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
S40 (04-)	2007			•	•	•	•	•	0		
S40 (04-)	2007			•	•	•	•	•	0	146, 111	
S40 (04-)	2007	PSM		•	•	•	•	•	•	145	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2007	TMC		•	•	•	•	•	0		
S40 (04-)	2007	SWM		•	•	•	•	•	0		
S40 (04-)	2007	KVM		•	•	•	•	•	•	147	
S40 (04-)	2007	AEM		•	•	•	•	•	•	146	
S40 (04-)	2007	PHM		•	•	•	•	•	0		
S40 (04-)	2007	TRM		•	•	•	•	•	0		
S40 (04-)	2007	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95	
S40 (04-)	2007	MMM		•	•	•	•	0	0		
S40 (04-)	2007	RDAR		•	•	•	•	•	0		
S40 (04-)	2007	CPM		•	•	•	•	•	•		
S40 (04-)	2007	IAM		•	•	•	•	•	•		
S40 (04-)	2007			•	•	•	•	0	0		
S40 (04-)	2007			•	•	•	•	•	0		
S40 (04-)	2007			•	•	•	•	•	•	149, 150	
S40 (04-)	2007			•	•	•	•	•	•	149, 150	
S40 (04-)	2007	SRS		•	•	•	•	•	0	95	
S40 (04-)	2007	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
S40 (04-)	2007	DIM		•	•	•	•	•	•	48, 161, 118, 46, 165	
S40 (04-)	2007	ICM		•	•	•	•	•	•	166, 167	
S40 (04-)	2007	EPS		•	•	•	•	•	0		
C70 (06-)	2007	ECM	D5244T9	•	•	•	•	•	•		
C70 (06-)	2007		D5244T8	•	•	•	•	•	•		
C70 (06-)	2007	ECM	B5254T3	•	•	•	•	•	•	74	
C70 (06-)	2007		B5244S5	•	•	•	•	•	•	9	
C70 (06-)	2007	ECM	B5244S4	•	•	•	•	•	•	9	
C70 (06-)	2007	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
C70 (06-)	2007	DIM		•	•	•	•	•	•	48, 161, 46, 165	
C70 (06-)	2007	GPS		•	•	•	•	•	0		
C70 (06-)	2007	BCM		•	•	•	•	•	0	146, 111	
C70 (06-)	2007			•	•	•	•	•	0		
C70 (06-)	2007	SWM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2007			•	•	•	•	•	•	147	
C70 (06-)	2007			•	•	•	•	•	•	146	
C70 (06-)	2007			•	•	•	•	•	0		
C70 (06-)	2007	TRM		•	•	•	•	•	0		
C70 (06-)	2007	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95	
C70 (06-)	2007	MMM		•	•	•	•	0	0		
C70 (06-)		RDAR		•	•	•	•	•	0		
C70 (06-)	2007	CPM		•	•	•	•	•	•		
C70 (06-)	2007	SUB		•	•	•	•	0	0		
C70 (06-)	2007	IAM		•	•	•	•	•	•		
C70 (06-)	2007			•	•	•	•	0	0		
C70 (06-)	2007			•	•	•	•	•	0		
C70 (06-)	2007			•	•	•	•	•	0	95	
C70 (06-)	2007			•	•	•	•	•	•	149, 150	
C70 (06-)	2007			•	•	•	•	•	•	149, 150	
C70 (06-)	2007			•	•	•	•	•	•	145	
C70 (06-)	2007	PSR		•	•	•	•	•	•	145	
C70 (06-)	2007	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
C70 (06-)	2007			•	•	•	•	•	0	174, 176	
C70 (06-)	2007			•	•	•	•	•	•	166, 167	
C70 (06-)	2007			•	•	•	•	•	0		
C30	2007		D5244T9	•	•	•	•	•	•		
C30	2007		D5244T8	•	•	•	•	•	•		
C30	2007		D4204T	•	•	•	•	•	0		
C30	2007		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
C30	2007		D4164T	•	•	•	•	•	0		
C30	2007		D4164T	•	•	•	•	•	•	69, 141, 169	
C30	2007		B5254T3	•	•	•	•	•	•	74	
C30	2007		B5244S4	•	•	•	•	•	•	9	
C30	2007		B4204S3	•	•	•	•	•	•	9	
C30	2007		B4184S8	•	•	•	•	•	•	9	
C30	2007		B4184S11	•	•	•	•	•	•	9	
C30	2007	ECM	B4164S3	•	•	•	•	•	•	9	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2007	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
C30	2007	DIM		•	•	•	•	•	•	48, 161, 46, 165, 118	
C30	2007	GPS		•	•	•	•	•	0		
C30	2007			•	•	•	•	•	0	146, 111	
C30	2007	TMC		•	•	•	•	•	0		
C30	2007	SWM		•	•	•	•	•	0		
C30	2007	KVM		•	•	•	•	•	•	147	
C30	2007	PHM		•	•	•	•	•	0		
C30	2007	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95	
C30	2007	MMM		•	•	•	•	0	0		
C30		RDAR		•	•	•	•	•	0		
C30	2007	CPM		•	•	•	•	•	•		
C30	2007	IAM		•	•	•	•	•	•		
C30	2007			•	•	•	•	0	0		
C30	2007			•	•	•	•	•	0		
C30	2007	SRS		•	•	•	•	•	0	95	
C30	2007	DDM		•	•	•	•	•	•	149, 150	
C30	2007	PDM		•	•	•	•	•	•	149, 150	
C30	2007	PSL		•	•	•	•	•	•	145	
C30	2007	PSR		•	•	•	•	•	•	145	
C30	2007	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
C30	2007	TRM		•	•	•	•	•	0		
C30	2007	ICM		•	•	•	•	•	•	166, 167	
C30	2007			•	•	•	•	•	0		
XC90	2006		TF-80SC AWD	•	•	•	•	•	•	1, 3, 81, 84, 85	
XC90	2006		TF-80SC AWD	•	•	•	•	•	0		
XC90	2006	DEM	M66 AWD	•	•	•	•	•	0		
XC90	2006	BCM	D5244T4	•	•	•	•	•	•	86, 87	
XC90	2006		D5244T4	•	•	•	•	•	•	91, 92, 94, 95	
XC90	2006	SAS	D5244T4	•	•	•	•	•	0		
XC90	2006	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62, 63, 64	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2006	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
XC90	2006	DEW	AW50/51 AWD	•	•	•	•	•	0	20	
XC90	2006		D5244T			•	•	•	•		
XC90	2006		D5244T	•	•	•	•	•	•	86, 87	
XC90	2006		D5244T	•		•	•	•	•	91, 92, 94, 95	
XC90	2006		D5244T	•	•	•	•	•	0	01, 02, 01, 00	
XC90	2006		TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
XC90	2006	DEM	TF-80SC AWD	•	•	•	•	•	•		
XC90	2006	BCM	B8444S	•	•	•	•	•	•	86, 87	
XC90	2006		B8444S	•	•	•	•	•	0		
XC90	2006		B8444S	•	•	•	•	•	•	91, 92, 94, 95	
XC90	2006		B8444S	•	•	•	•	•	•		
XC90	2006	TCM	4T65 AWD	•	•	•	•	•	•	125, 102, 100, 103	
XC90	2006	DEM	4T65 AWD	•	•	•	•	•	0		
XC90	2006	BCM	B6294T	•	•	•	•	•	•	86, 87	
XC90	2006	ECM	B6294T	•	•	•	•	•	•	74	
XC90	2006	CEM	B6294T	•	•	•	•	•	•	91, 92, 94, 95	
XC90	2006	SAS	B6294T	•	•	•	•	•	0		
XC90	2006	DEM	M66 AWD	•	•	•	•	•	0		
XC90	2006	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
XC90	2006	DEM	AW50/51 AWD	•	•	•	•	•	0		
XC90	2006	BCM	B5254T2	•	•	•	•	•	•	86, 87	
XC90	2006	CEM	B5254T2	•	•	•	•	•	•	91, 92, 94, 95	
XC90	2006	ECM	B5254T2	•	•	•	•	•	•	74	
XC90	2006		B5254T2	•	•	•	•	•	0		
XC90	2006			•	•	•	•	•	•		
XC90	2006			•	•	•	•	•	•		
XC90	2006			•	•	•	•	•	•		
XC90	2006			•	•	•	•	•	•		
XC90	2006			•	•	•	•	•	0	95	
XC90	2006			•	•	•	•	•	•	107	
XC90	2006			•	•	•	•	•	•	107, 108	
XC90	2006	PDM		•	•	•	•	•	•	108	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2006			•	•	•	•	•	•		
XC90	2006			•	•	•	•	0	0		
XC90	2006			•	•	•	•	•	•		
XC90	2006	PHM		•	•	•	•	•	0		
XC90	2006	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47	
XC90	2006	CPM		•	0	0	0	•	0	111, 112	
XC90	2006	UEM		•	•	•	•	•	•	119, 120, 128, 122, 1 23, 124	
XC90	2006	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
XC90	2006	MMM		•	•	•	•	0	0		
V70 (00-08)	2006	DEM	TF-80SC AWD	•	•	•	•	•	0		
V70 (00-08)	2006	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
V70 (00-08)	2006	DEM	M66 AWD	•	•	•	•	•	0		
V70 (00-08)	2006	DEM	M58	•	•	•	•	•	0		
V70 (00-08)	2006	ECM	D5244T7	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
V70 (00-08)	2006	ECM	D5244T6	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
V70 (00-08)	2006	ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
V70 (00-08)	2006	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
V70 (00-08)	2006	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
V70 (00-08)	2006	ECM	D5244T2	•	•	•	•	•	•		
V70 (00-08)	2006	ECM	D5244T	•	•	•	•	•	•		
V70 (00-08)	2006	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
V70 (00-08)	2006	ECM	B5254T4	•	•	•	•	•	•	74	
V70 (00-08)	2006		B5254T2	•	•	•	•	•	•	74	
V70 (00-08)	2006		B5244T5	•	•	•	•	•	•	74	
V70 (00-08)	2006		B5244SG	•	0	0	0	•	0		
V70 (00-08)	2006		B5244SG	•	•	•	•	•	•		
V70 (00-08)	2006		B5244S6	•	•	•	•	•	•		
V70 (00-08)	2006	ECM	B5244S2	•	•	•	•	•	•		



NOTES:

• This function is supported.

imes This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (00-08)	2006	ECM	B5244S	•	•	•	•	•	•	74	
V70 (00-08)	2006	ECM	B5204T5	•	•	•	•	•	•	74	
V70 (00-08)	2006	TCM	AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
V70 (00-08)	2006	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
V70 (00-08)	2006		AW50/51 AWD	•	•	•	•	•	0		
V70 (00-08)	2006			•	•	•	•	•	•		
V70 (00-08)	2006			•	•	•	•	•	0		
V70 (00-08)	2006			•	•	•	•	•	•	86, 87	
V70 (00-08)	2006			•	•	•	•	•	0	95	
V70 (00-08)	2006			•	•	•	•	•	•	107	
V70 (00-08)	2006			•	•	•	•	•	•	107, 108	
V70 (00-08)	2006			•	•	•	•	•	•	108	
V70 (00-08)	2006			•	•	•	•	•	•		
V70 (00-08)	2006			•	•	•	•	•	•		
V70 (00-08)	2006	PHM		•	•	•	•	•	0		
V70 (00-08)	2006	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47	
V70 (00-08)	2006	CPM		•	0	0	0	•	0	111, 112	
V70 (00-08)	2006	UEM		•	•	•	•	•	•	119, 120, 128, 122, 1 23, 124	
V70 (00-08)	2006	CEM		•	•	•	•	•	•	91, 92, 94, 95	
V70 (00-08)	2006	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
V70 (00-08)	2006	RTI		•	•	•	•	0	0		
V70 (00-08)	2006	SAS		•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2006	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
V70 XC(01-)/XC70(-07)	2006	DEM	TF-80SC AWD	•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2006	DEM	M66 AWD	•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2006	DEM	M58	•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2006	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70(-07)	2006	ECM	D5244T	•	•	•	•	•	•		
V70 XC(01-)/XC70(-07)	2006	ECM	B5254T2	•	•	•	•	•	•	74	
V70 XC(01-)/XC70(-07)	2006	ECM	B5244T4	•	•	•	•	•	•	74	
V70 XC(01-)/XC70(-07)	2006	TCM	AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
V70 XC(01-)/XC70(-07)	2006	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
V70 XC(01-)/XC70(-07)	2006	DEM	AW50/51 AWD	•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2006	REM		•	•	•	•	•	•		
V70 XC(01-)/XC70(-07)	2006	AUM		•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2006	BCM		•	•	•	•	•	•	86, 87	
V70 XC(01-)/XC70(-07)	2006	SRS		•	•	•	•	•	0	95	
V70 XC(01-)/XC70(-07)	2006	PSM		•	•	•	•	•	•	107	
V70 XC(01-)/XC70(-07)	2006	DDM		•	•	•	•	•	•	107, 108	
V70 XC(01-)/XC70(-07)	2006	PDM		•	•	•	•	•	•	108	
V70 XC(01-)/XC70(-07)	2006	SUM		•	•	•	•	•	•		
V70 XC(01-)/XC70(-07)	2006	AEM		•	•	•	•	•	•		
V70 XC(01-)/XC70(-07)	2006	РНМ		•	•	•	•	•	0		
V70 XC(01-)/XC70(-07)	2006	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47	
V70 XC(01-)/XC70(-07)	2006	СРМ		•	0	0	0	•	0	111, 112	
V70 XC (01-) /XC70 (-07)	2006	UEM		•	•	•	•	•	•	119, 120, 128, 122, 1 23, 124	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported. ▲ This fund
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70(-07)	2006	CEM		•	•	•	•	•	•	91, 92, 94, 95	
V70 XC(01-)/XC70(-07)	2006	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
V70 XC(01-)/XC70(-07)	2006	RTI		•	•	•	•	0	0		
V70 XC(01-)/XC70(-07)	2006	SAS		•	•	•	•	•	0		
V50	2006	DEM	M66 AWD	•	•	•	•	•	0		
V50	2006		D5244T8	•	•	•	•	•	•		
V50	2006		D4204T2	•	•	•	•	•	0		
V50	2006		D4204T2	•	•	•	•	•	•	71, 9, 141, 69	
V50	2006		D4204T	•	•	•	•	•	0		
V50	2006		D4204T	•	•	•	•	•	•	71, 9, 141, 69	
V50	2006		D4164T	•	•	•	•	•	0		
V50	2006		D4164T	•	•	•	•	•	•	69, 141, 169	
V50	2006		B5254T3	•	•	•	•	•	•	74	
V50	2006		B5244S7	•	•	•	•	•	•	9	
V50	2006		B5244S5	•	•	•	•	•	•	9	
V50	2006		B5244S4	•	•	•	•	•	•	9	
V50	2006		B4184S8	•	•	•	•	•	•	9	
V50	2006		B4184S11	•	•	•	•	•	•	9	
V50	2006	ECM	B4164S3	•	•	•	•	•	•	9	
V50	2006	TCM	AW55-50/51SN	•	•	•	•	•	•	170, 111, 82, 140, 4, 100, 101	
V50	2006	DEM	AW50/51 AWD	•	•	•	•	•	0		
V50	2006	TCM	AW50/51 AWD	•	•	•	•	•	•	170, 111, 82, 140, 4, 100, 101	
V50	2006	DIM		•	•	•	•	•	•	48, 161, 46, 165	
V50	2006			•	•	•	•	•	0		
V50	2006	DDM		•	•	•	•	•	•	149, 150	
V50	2006			•	•	•	•	•	•	149, 150	
V50	2006			•	•	•	•	•	0	146, 111	
V50	2006			•	•	•	•	•	•	145	
V50	2006			•	•	•	•	•	0		
V50	2006	SWM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2006	KVM		•	•	•	•	•	•	147	
V50	2006	AEM		•	•	•	•	•	•	146	
V50	2006	ICM		•	•	•	•	•	•	166	
V50	2006	IAM		•	•	•	•	•	•		
V50	2006			•	•	•	•	•	0		
V50	2006			•	•	•	•	•	0		
V50	2006	PAM		•	•	•	•	•	0		
V50	2006	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95	
V50	2006	MMM		•	•	•	•	0	0		
V50	2006	CPM		•	•	•	•	•	•		
V50	2006	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
V50	2006			•	•	•	•	0	0		
V50	2006			•	•	•	•	•	0	95	
V50	2006			•	•	•	•	•	0		
S80 (-06)	2006		D5244T2	•	•	•	•	•	•		
S80 (-06)	2006		D5244T	•	•	•	•	•	•		
S80 (-06)	2006		B6294T	•	•	•	•	•	•	74	
S80 (-06)	2006		B6294S2	•	•	•	•	•	•	74	
S80 (-06)	2006		B5254T2	•	•	•	•	•	•	74	
S80 (-06)	2006		B5244T4	•	•	•	•	•	•	74	
S80 (-06)	2006		B5244SG	•	0	0	0	•	0		
S80 (-06)	2006		B5244SG	•	•	•	•	•	•		
S80 (-06)	2006		B5244S2	•	•	•	•	•	•		
S80 (-06)	2006		B5244S	•	•	•	•	•	•		
S80 (-06)	2006	ECM	B5204T5	•	•	•	•	•	•	74	
S80 (-06)	2006	TCM	AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S80 (-06)	2006	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S80 (-06)	2006	DEM	AW50/51 AWD	•	•	•	•	•	0		
S80 (-06)	2006	TCM	4T65EV-GT	•	•	•	•	•	•	125, 102, 100, 103	
S80 (-06)	2006	TCM	4T65EV	•	•	•	•	•	•	125, 102, 100, 103	



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (-06)	2006	REM		•	•	•	•	•	•		
S80 (-06)	2006			•	•	•	•	•	0		
S80 (-06)	2006			•	•	•	•	•	•	86, 87	
S80 (-06)	2006			•	•	•	•	•	0	95	
S80 (-06)	2006			•	•	•	•	•	•	107	
S80 (-06)	2006			•	•	•	•	•	•	107, 108	
S80 (-06)	2006			•	•	•	•	•	•	108	
S80 (-06)	2006			•	•	•	•	•	•		
S80 (-06)	2006			•	•	•	•	•	•		
S80 (-06)	2006	PHM		•	•	•	•	•	0		
S80 (-06)	2006	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47	
S80 (-06)	2006	CPM		•	0	0	0	•	0	111, 112	
S80 (-06)	2006	UEM		•	•	•	•	•	•	119, 120, 128, 122, 1 23, 124	
S80 (-06)	2006	CEM		•	•	•	•	•	•	91, 92, 94, 95	
S80 (-06)	2006	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
S80 (-06)	2006	RTI		•	•	•	•	0	0		
S80 (-06)	2006	SAS		•	•	•	•	•	0		
S60	2006		TF-80SC AWD	•	•	•	•	•	0		
S60	2006		M66 AWD	•	•	•	•	•	0		
S60	2006	DEM	M58	•	•	•	•	•	0		
S60	2006	ECM	D5244T7	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2006	ECM	D5244T6	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2006	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
S60	2006	ECM	D5244T5	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2006	TCM	TF-80SC	•	•	•	•	•	•	81, 82, 83, 84, 85	
S60	2006	ECM	D5244T4	•	•	•	•	•	•	58, 59, 89, 60, 61, 62 , 63, 64	
S60	2006	ECM	D5244T2	•	•	•	•	•	•		
S60	2006	ECM	D5244T	•	•	•	•	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2006	TCM	TF-80SC AWD	•	•	•	•	•	•	81, 82, 83, 84, 85	
S60	2006	ECM	B5254T4	•	•	•	•	•	•	74	
S60	2006	ECM	B5254T2	•	•	•	•	•	•	74	
S60	2006		B5244T5	•	•	•	•	•	•	74	
S60	2006		B5244T4	•	•	•	•	•	•	74	
S60	2006		B5244SG	•	0	0	0	•	0		
S60	2006		B5244SG	•	•	•	•	•	•		
S60	2006		B5244S6	•	•	•	•	•	•		
S60	2006		B5244S2	•	•	•	•	•	•		
S60	2006		B5244S	•	•	•	•	•	•		
S60	2006	ECM	B5204T5	•	•	•	•	•	•	74	
S60	2006	TCM	AW55-50/51SN	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S60	2006	DEM	AW50/51 AWD	•	•	•	•	•	0		
S60	2006	TCM	AW50/51 AWD	•	•	•	•	•	•	100, 101, 102, 103, 1 25	
S60	2006	REM		•	•	•	•	•	•		
S60	2006	AUM		•	•	•	•	•	0		
S60	2006	BCM		•	•	•	•	•	•	86, 87	
S60	2006	SRS		•	•	•	•	•	0	95	
S60	2006	PSM		•	•	•	•	•	•	107	
S60	2006			•	•	•	•	•	•	107, 108	
S60	2006	PDM		•	•	•	•	•	•	108	
S60	2006			•	•	•	•	•	•		
S60	2006			•	•	•	•	•	•		
S60	2006	PHM		•	•	•	•	•	0		
S60	2006	DIM		•	•	•	•	•	•	116, 117, 28, 46, 47	
S60	2006	CPM		•	0	0	0	•	0	111, 112	
S60	2006	UEM		•	•	•	•	•	•	119, 120, 128, 122, 1 23, 124	
S60	2006	CEM		•	•	•	•	•	•	91, 92, 94, 95	
S60	2006	CCM		•	•	•	•	•	0	30, 113, 114, 29, 32, 115	
S60	2006	RTI		•	•	•	•	0	0		
S60	2006	SAS		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2006		M66 AWD	•	•	•	•	•	0		
S40 (04-)	2006	ECM	D5244T8	•	•	•	•	•	•		
S40 (04-)	2006		D4204T2	•	•	•	•	•	0		
S40 (04-)	2006	ECM	D4204T2	•	•	•	•	•	•	71, 9, 141, 69	
S40 (04-)	2006		D4204T	•	•	•	•	•	0		
S40 (04-)	2006	ECM	D4204T	•	•	•	•	•	•	71, 9, 141, 69	
S40 (04-)	2006		D4164T	•	•	•	•	•	0		
S40 (04-)	2006	ECM	D4164T	•	•	•	•	•	•	69, 141, 169	
S40 (04-)	2006	ECM	B5254T3	•	•	•	•	•	•	74	
S40 (04-)	2006	ECM	B5244S7	•	•	•	•	•	•	9	
S40 (04-)	2006		B5244S5	•	•	•	•	•	•	9	
S40 (04-)	2006		B5244S4	•	•	•	•	•	•	9	
S40 (04-)	2006		B4184S8	•	•	•	•	•	•	9	
S40 (04-)	2006	ECM	B4184S11	•	•	•	•	•	•	9	
S40 (04-)	2006	ECM	B4164S3	•	•	•	•	•	•	9	
S40 (04-)	2006	TCM	AW55-50/51SN	•	•	•	•	•	•	170, 111, 82, 140, 4, 100, 101	
S40 (04-)	2006	DEM	AW50/51 AWD	•	•	•	•	•	0		
S40 (04-)	2006	TCM	AW50/51 AWD	•	•	•	•	•	•	170, 111, 82, 140, 4, 100, 101	
S40 (04-)	2006	DIM		•	•	•	•	•	•	48, 161, 46, 165	
S40 (04-)	2006	GPS		•	•	•	•	•	0		
S40 (04-)	2006	DDM		•	•	•	•	•	•	149, 150	
S40 (04-)	2006	PDM		•	•	•	•	•	•	149, 150	
S40 (04-)	2006	BCM		•	•	•	•	•	0	146, 111	
S40 (04-)	2006	PSM		•	•	•	•	•	•	145	
S40 (04-)	2006	TMC		•	•	•	•	•	0		
S40 (04-)	2006	SWM		•	•	•	•	•	0		
S40 (04-)	2006	KVM		•	•	•	•	•	•	147	
S40 (04-)	2006			•	•	•	•	•	•	146	
S40 (04-)	2006			•	•	•	•	•	•	166	
S40 (04-)	2006			•	•	•	•	•	•		
S40 (04-)	2006			•	•	•	•	•	0		
S40 (04-)	2006	TRM		•	•	•	•	•	0		
S40 (04-)	2006	PAM		•	•	•	•	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2006	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95	
S40 (04-)	2006	MMM		•	•	•	•	0	0		
S40 (04-)	2006	CPM		•	•	•	•	•	•		
S40 (04-)	2006	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
S40 (04-)	2006	AUD		•	•	•	•	0	0		
S40 (04-)	2006	SRS		•	•	•	•	•	0	95	
S40 (04-)	2006	EPS		•	•	•	•	•	0		
C70 (06-)	2006		B5254T3	•	•	•	•	•	•	74	
C70 (06-)		ECM	B5244S5	•	•	•	•	•	•	9	
C70 (06-)	2006	ECM	B5244S4	•	•	•	•	•	•	9	
C70 (06-)	2006	TCM	AW55-50/51SN	•	•	•	•	•	•	83, 111, 1, 140, 4, 10 0, 101	
C70 (06-)	2006	DIM		•	•	•	•	•	•	48, 161, 46, 165	
C70 (06-)	2006	GPS		•	•	•	•	•	0		
C70 (06-)	2006			•	•	•	•	•	0	146, 111	
C70 (06-)		TMC		•	•	•	•	•	0		
C70 (06-)	2006			•	•	•	•	•	0		
C70 (06-)		KVM		•	•	•	•	•	•	147	
C70 (06-)		AEM		•	•	•	•	•	•	146	
C70 (06-)		ICM		•	•	•	•	•	•	166	
C70 (06-)		IAM		•	•	•	•	•	•		
C70 (06-)		AUD		•	•	•	•	0	0		
C70 (06-)		PHM		•	•	•	•	•	0		
C70 (06-)		TRM		•	•	•	•	•	O		
C70 (06-)	2006	PSL		•	•	•	•	•	•	145	
C70 (06-)	2006	CEM		•	•	•	•	•	•	154, 156, 94, 158, 15 9, 160, 162, 95	
C70 (06-)	2006	MMM		•	•	•	•	0	0		
C70 (06-)		CPM		•	•	•	•	•	•		
C70 (06-)		SUB		•	•	•	•	0	0		
C70 (06-)		PSR		•	•	•	•	•	•	145	
C70 (06-)	2006			•	•	•	•	•	•	149	



NOTES:

- This function is supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2006	PDM		•	•	•	•	•	•	149	
C70 (06-)	2006	CCM		•	•	•	•	•	0	30, 113, 152, 32, 153	
C70 (06-)	2006	PAM		•	•	•	•	•	0		
C70 (06-)	2006			•	•	•	•	•	0	95	
C70 (06-)	2006			•	•	•	•	•	0	174, 176	
C70 (06-)	2006	EPS		•	•	•	•	•	0		
XC90	2005	Petrol	B5254T2	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
XC90	2005	Petrol	B6294T	•	•	•	•	•	•	1, 2, 3, 4, 5, 6	
XC90	2005	Petrol	B8444S	•	•	•	0	•	•		
XC90	2005	Diesel	D5244T	•	•	•	0	•	•	7	
XC90	2005		4T65AWD	•	•	•	•	•	•	10, 11	
XC90	2005	TCM	AW50/51AWD	•	•	•	•	•	•	10, 11	
XC90	2005	DEM	DEM	•	•	•	•	•	0		
XC90	2005	TCM	TF-80SC AWD	•	•	•	•	•	•		
XC90	2005	ABS/BCM	ABS/BCM	•	•	•	•	•	•		
XC90	2005	SUB	SUB	•	•	•	•	0	0		
XC90	2005	SRS	SRS	•	•	•	•	•	0		
XC90	2005	UEM	UEM	•	•	•	•	•	•	21, 22, 23, 24, 25	
V90	1998	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V90	1998	Immobilizer	IMM	•	•	•	0	•	0		
V90	1998	Petrol	ECM	•	•	•	0	•	0		
V90	1998	CI	CI	•	0	0	0	0	0	0_0001	
V90	1998	PSL	PSL	•	•	•	0	•	0		
V90	1998	PSR	PSR	•	•	•	0	•	•		
V90	1998		RTI	•	•	•	0	•	•		
V90	1998	SRS	SRS	•	•	•	0	•	0		
V90	1998		AW30-40	•	•	•	0	•	0		
V70 (-00)		ABS/BCM	ABS/BCM	•	•	•	0	•	0		
V70 (-00)	1998	ECM	D5252T MSA 15.7	•	•	•	0	•	0		
V70 (-00)	1998	Motronic 4.4	ECM	•	•	•	0	•	0		
V70 (-00)	1998	Immobilizer	IMM	•	•	•	0	•	0		
V70 (-00)	1998		CI	•	•	•	0	•	0	0_0001	
V70 (-00)		VGLA	VGLA	•	•	•	0	0	0		
V70 (-00)	1998		PSL	•	•	•	0	•	0		
V70 (-00)	1998	PSR	PSR	•	•	•	0	•	•		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (-00)	1998	CPM	CPM	•	•	•	0	•	•		
V70 (-00)	1998		RTI	•	•	•	0	•	•		
V70 (-00)		SRS	SRS	•	•	•	0	•	0		
V70 (-00)	1998	TCM	AW42AWD	•	•	•	0	•	0		
V70 XC (-00)	1998	ABS/BCM	ABS/BCM	•	•	•	0	•	0		
V70 XC (-00)	1998		CI	•	•	•	0	•	0	0_0001	
V70 XC (-00)		VGLA	VGLA	•	•	•	0	0	0		
V70 XC (-00)		PSL	PSL	•	•	•	0	•	0		
V70 XC (-00)		PSR	PSR	•	•	•	0	•	•		
V70 XC (-00)		Immobilizer	IMM	•	•	•	0	•	0		
V70 XC (-00)		ECM	D5252T MSA 15.7	•	•	•	0	•	0		
V70 XC (-00)	1998		RTI	•	•	•	0	•	•		
V70 XC (-00)		SRS	SRS	•	•	•	0	•	0		
V70 XC (-00)		TCM	AW42AWD	•	•	•	0	•	0		
V40		ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	1998	CI	CI	•	•	•	0	•	•	0_0001	
V40		Immobilizer	IMM	•	•	•	0	•	•		
V40		VGLA	VGLA	•	•	•	0	•	•		
V40		CPM	CPM	•	•	•	0	•	•		
V40	1998	DSA	DSA	•	•	•	0	•	•		
V40		SRS	SRS	•	•	•	0	•	0		
V40		TCM	AW50-42	•	•	•	0	•	0		
V40	1998		CCM	•	•	•	0	•	•		
V40	1998		RTI	•	•	•	0	•	•		
S90	1998	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S90		Immobilizer	IMM	•	•	•	0	•	0		
S90	1998		CI	•	0	0	0	0	0	0_0001	
S90		PSL	PSL	•	•	•	0	•	0		
S90	1998	PSR	PSR	•	•	•	0	•	•		
S90		Engine 1	ECM	•	•	•	0	•	0		
S90		SRS	SRS	•	•	•	0	•	0		
S90		RTI	RTI	•	•	•	0	•	•		
S90		TCM	AW30-43	•	•	•	0	•	0		
S70		ABS/BCM	ABS/BCM	•	•	•	0	•	0		
S70		Motronic 4.4	ECM	•	•	•	0	•	0		
S70	1998	ECM	D5252T MSA 15.7	•	•	•	0	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S70	1998	Engine 1	ECM	11110.	•	•	O	Data	0	r dife e l'on	
S70		Immobilizer	IMM	•		•	0	•	0		
S70	1998		CI	•	0	0	0	0	0	0_0001	
S70		VGLA	VGLA	•	•	•	0	0	0		
S70	1998		PSL	•	•	•	0	•	0		
S70	1998		PSR	•	•	•	0	•	0		
S70	1998	CPM	CPM	•	•	•	0	•	•		
S70	1998		RTI	•	•	•	0	•	•		
S70	1998	SRS	SRS	•	•	•	0	•	0		
S70	1998	TCM	AW50-42	•	•	•	0	•	0		
S40 (-04)	1998	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S40 (-04)	1998	CI	CI	•	•	•	0	•	•	0_0001	
S40 (-04)	1998	immobilizer	IMM	•	•	•	0	•	•		
S40 (-04)	1998	VGLA	VGLA	•	•	•	0	•	•		
S40 (-04)	1998	CPM	CPM	•	•	•	0	•	•		
S40 (-04)	1998	DSA	DSA	•	•	•	0	•	•		
S40 (-04)	1998		CCM	•	•	•	0	•	•		
S40 (-04)	1998	RTI	RTI	•	•	•	0	•	•		
S40 (-04)	1998		SRS	•	•	•	0	•	0		
S40 (-04)	1998	TCM	AW50-42	•	•	•	0	•	0		
V90		ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V90		Immobilizer	IMM	•	•	•	0	•	0		
V90		Petrol	ECM	•	•	•	0	•	0		
V90	1997		CI	•	0	0	0	0	0	0_0001	
V90	1997		PSL	•	•	•	0	•	0		
V90	1997		PSR	•	•	•	0	•	•		
V90	1997		RTI	•	•	•	0	•	•		
V90	1997		SRS	•	•	•	0	•	0		
V90	1997		AW30-40	•	•	•	0	•	0		
V70 (-00)		ABS/BCM	ABS/BCM	•	•	•	0	•	0		
V70 (-00)	1997		D5252T MSA 15.7	•	•	•	0	•	0		
V70 (-00)		Motronic 4.4	ECM	•	•	•	0	•	0		
V70 (-00)		Immobilizer	IMM	•	•	•	0	•	0		
V70 (-00)	1997		CI	•	•	•	0	•	0	0_0001	
V70 (-00)		VGLA	VGLA	•	•	•	0	0	0		
V70 (-00)	1997	PSL	PSL	•	•	•	0	•	0		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (-00)	1997		PSR	•		•	0	•	•		
V70 (-00)	1997		CPM	•	•	•	0	•	•		
V70 (-00)	1997		RTI	•	•	•	0	•	•		
V70 (-00)	1997	SRS	SRS	•	•	•	0	•	0		
V70 (-00)	1997		AW42AWD	•	•	•	0	•	0		
V40		ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	1997		CI	•	•	•	0	•	•	0_0001	
V40		Immobilizer	IMM	•	•	•	0	•	•		
V40	1997	VGLA	VGLA	•	•	•	0	•	•		
V40		CPM	CPM	•	•	•	0	•	•		
V40	1997		DSA	•	•	•	0	•	•		
V40	1997		SRS	•	•	•	0	•	0		
V40	1997		AW50-42	•	•	•	0	•	0		
V40	1997		CCM	•	•	•	0	•	•		
V40	1997		RTI	•	•	•	0	•	•		
S90	1997	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S90		Immobilizer	IMM	•	•	•	0	•	0		
S90	1997		CI	•	0	0	0	0	0	0_0001	
S90	1997		PSL	•	•	•	0	•	0		
S90	1997		PSR	•	•	•	0	•	0		
S90		Engine 1	ECM	•	•	•	0	•	0		
S90		SRS	SRS	•	•	•	0	•	0		
S90	1997		RTI	•	•	•	0	•	•		
S90		TCM	AW30-43	•	•	•	0	•	0		
S70		ABS/BCM	ABS/BCM	•	•	•	0	•	0		
S70		Petrol	ECM	•	•	•	0	•	0		
S70		Motronic 4.4	ECM	•	•	•	0	•	0		
S70	1997		D5252T MSA 15.7	•	•	•	0	•	0		
S70		Immobilizer	IMM	•	•	•	0	•	0		
S70	1997		CI	•	0	0	0	0	0	0_0001	
S70		VGLA	VGLA	•	•	•	0	0	0		
S70	1997		PSL	•	•	•	0	•	0		
S70	1997		PSR	•	•	•	0	•	0		
S70		CPM	CPM	•	•	•	0	•	•		
S70	1997		RTI	•	•	•	0	•	•		
S70	1997	SRS	SRS	•	•	•	0	•	0		



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S70	1997	TCM	AW50-42	•	•	•	0	•	0		
S40 (-04)	1997	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
S40 (-04)	1997		CI	•	•	•	0	•	•	0_0001	
S40 (-04)	1997	'immobilizer	IMM	•	•	•	0	•	•		
S40 (-04)		VGLA	VGLA	•	•	•	0	•	•		
S40 (-04)	1997	CPM	CPM	•	•	•	0	•	•		
S40 (-04)		DSA	DSA	•	•	•	0	•	•		
S40 (-04)		CCM	CCM	•	•	•	0	•	•		
S40 (-04)		RTI	RTI	•	•	•	0	•	•		
S40 (-04)		SRS	SRS	•	•	•	0	•	0		
S40 (-04)	1997	TCM	AW50-42	•	•	•	0	•	0		
9		Petrol	ECM	•	•	•	0	•	0		
9	60 1997	CI	CI	•	•	•	0	•	•	0_0001	
		'immobilizer	IMM	•	•	•	0	•	0		
9		PSL	PSL	•	•	•	0	•	0		
9		PSR	PSR	•	•	•	0	•	0		
9		TCM	AW30-43	•	•	•	0	•	0		
9		ABS/BCM	ABS/BCM	•	•	•	0	•	•		
		SRS	SRS	•	•	•	0	•	0		
8		Motronic 4.4	ECM	•	•	•	0	•	•		
	50 1997		CI	•	•	•	0	•	•	0_0001	
8		'immobilizer	IMM	•	•	•	0	•	0		
	50 1997	PSL	PSL	•	•	•	0	•	0		
		PSR	PSR	•	•	•	0	•	0		
8		TCM	AW50-42	•	•	•	0	•	•		
		ABS/BCM	ABS/BCM	•	•	•	0	•	•		
8		SRS	SRS	•	•	•	0	•	0		
V40		ABS/BCM	ABS/BCM	•	•	•	0	•	•		
V40	1996		CI	•	•	•	0	•	•	0_0001	
V40		Immobilizer	IMM	•	•	•	0	•	•		
V40		VGLA	VGLA	•	•	•	0	•	•		
V40		CPM	CPM	•	•	•	0	•	•		
V40		DSA	DSA	•	•	•	0	•	•		
V40		SRS	SRS	•	•	•	0	•	0		
V40		TCM	AW50-42	•	•	•	0	•	0		
V40	1996	CCM	CCM	•	•	•	0	•	•		



NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.

 A This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU	Read DTC	Clear	Freeze	Live		Special	Other
	1000			Info.		DTC	Frame	Data	Test	Function	
V40		RTI ABS/BCM	RTI	•	•	•	0	•	•		
S40 (-04)	1996	ABS/BCM	ABS/BCM	•	•	•	0	•	•	0.0001	
S40 (-04)		immobilizer	CI IMM			•	0	•		0_0001	
S40 (-04)				•		•	0	•			
S40 (-04)		VGLA CPM	VGLA CPM			-	0	-			
S40 (-04)		DSA			•	•	0	_			
S40 (-04)		6 CCM	DSA			•	0	•	•		
S40 (-04)			CCM	_	_	•	0		•		
S40 (-04)	1996		RTI	•	•		0	•			
S40 (-04)		SRS TCM	SRS	•	•	•	0	•	0		
S40 (-04)			AW50-42		, ,		0		0		
		Petrol	ECM CI	•	•	•	0	•	0	0.0001	
						•	0			0_0001	
		immobilizer	IMM PSL	•	•	•	0	•	0		
		PSL PSR	PSR			-	0	•	0		
		TCM				•					
		ABS/BCM	AW30-43 ABS/BCM			•	0	•	•		
		SRS	SRS			•	0	•	0		
			CI			-		-	•	0 0001	
		Immobilizer	IMM		_	•	0			0_0001	
		PSL	PSL		•	-	0	•	0		
		PSR	PSR		•	•	0	•	0		
		Motronic 4.4	ECM				0	-	•		
		TCM	AW50-42				0	-			
		ABS/BCM	ABS/BCM			-	0	•			
		SRS	SRS			•	0		0		
		Petrol	ECM			-	0	•	0		
	960 1995		CI			•	0		•	0_0001	
		immobilizer	IMM			•	0	•	0	0_0001	
		PSL	PSL				0		0		
		FSR PSR	PSR			-	0	-	0		
		TCM	AW30-43				0		0		
		ABS/BCM	ABS/BCM			-	0	•	•		
		SRS	SRS			•	0	•	0		
	850 1995		CI			-	0	•	•	0 0001	
	090 1990	01	OI		•		\cup	•		0_0001	



NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Year	System	Туре	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data		Special Function	Other
850	1995	Immobilizer	IMM	•	•	•	0	•	0		
850	1995	PSL	PSL	•	•	•	0	•	0		
850	1995	PSR	PSR	•	•	•	0	•	0		
850	1995	Petrol	ECM	•	•	•	0	•	•		
850	1995	TCM	AW50-42	•	•	•	0	•	•		
850	1995	ABS/BCM	ABS/BCM	•	•	•	0	•	•		
850	1995	SRS	SRS	•	•	•	0	•	0		

Al	Special Function			
ID	year range			
	<-2005	Readiness Code		
	2006->	Resetting adaptation		
2	<-2005	Adaptation of the throttle unit		
2	2006->	resetting the "Transmission fluid change" counter		
}	<-2005	Quick test of exhaust camshaft control		
3	2006->	Calibration of gear position sensor		
ŀ	<-2005	Quick test of intake camshaft control		
	2006->	Activating gear indication		
,	<-2005	Quick test of the fuel pump (FP)		
5	2006->	Control module adaptation		
3	<-2005	Quick test of the fuel tank system (USA/CDN)		
3	2006->	Readiness Code (USA/CDN)		
7	<-2005	Programming optimizing parameters		
7	2006->	Reading off IUMPR(USA/CDN)		
3	<-2005	Activating TEST MODE		
3	2006->	Quick test of fuel tank system(USA/CDM)		
)	<-2005	Control module adaption		
)	2006->	Resetting the adaptation values		
10	<-2005	Reset adaptation to zero		
.0	2006->	Calibration		
1	<-2005	Resetting the counter for-Gearbox oil change		
1	2006->	Activation		
12	<-2005	Resetting adaptation		
2	2006->	Initializing the window in the front door		
13	<-2005	Calibration of gear position sensor		
13	2006->	Initializing the window in the rear door		
14	<-2005	Resetting the oil counter		
4	2006->	Programming of Parking Assistance Module (PAM)		
15	<-2005	Calibration the system		
15	2006->	Checking all antennas		
6	<-2005	Calibrating the occupant weight sensor(OWS)		
16	2006->	Check the communication with the remote control receiver		
7	<-2005	Configuring the number of seats		
7	2006->	Remote control		
18	<-2005 2006->	Storing the ID number for the occupant weight sensor (OWS) Test of internal memory		
18	<-2005			
19	2006->	Activating and reading off sun roof parameters Activation of quick-lock motors		
20	<-2005	Add or Remove remote controls		
20	2006->	Quick test of function of the additional/parking heater		
21	<-2005	Programming the control unit		
21	2006->	Cooling of the cooling system		
22	<-2005	Configuration of the siren		
22	2006->	Activating components		
23	<-2005	Replacing the control module		
23	2006->	Calibration of position sensor		
4	<-2005	Reading the programmed values		
4	2006->	Activation		
5	<-2005	Quick test of the tire pressure sensor		
5	2006->	Powering the SRS system		
6	<-2005	Logging detailed diagnostic data		
6	2006->	Calibrating the occupant weight sensor (OWS)		
7	<-2005	Reading data for vehicle configuration		
7	2006->	Checking the PAD-light		
8	<-2005	Programming the control module, central electronic module (CEM)		
8	2006->	Reading off programmed values		

Al	Special Function			
ID	year range			
29	<-2005	Quick test of alternator fuction		
29	2006->	Programming the calimate control module (CCM)		
30	<-2005	Resetting factory settings		
30	2006->	Calibrating the Climate Control Module (CCM)		
31	<-2005	Resetting low voltage counters		
31	2006->	Identifying components on the LIN network that belong to climate control system (CCM)		
32	<-2005	Resetting car		
32	2006->	Reading out electronic damper motor, actual/preset range and tolerance limit		
33	<-2005	Testing all displays and lamps in instrument		
33	2006->	Programming the evaporator, climate control module (CCM)		
34	<-2005	Programming the audible acknowledgement signal, seat belt reminder		
34	2006->	Pre-delivery service for new car		
35	<-2005	Programming the driver information module(DIM)		
35	2006->	Workshop test (TPMS)		
36	<-2005	Reading off programmed values		
36	2006->	Quick test of alternator funtion		
37	<-2005	Resetting the service reminder indicator(SRI)		
37	2006->	Read-out and resetting alco-lock		
38	<-2005	Resetting the carphone code		
38	2006->	Checking the control module before replacement		
39	<-2005	Caibrating the position sensor for Bi-Xenon lamps		
39	2006->	Reading off alarm cause		
10	<-2005	Reading off the alarm cause		
10	2006->	Reading off power supply positon		
11	<-2005	Programming the climate control module (CCM)		
11	2006->	Check the brake light switch and brake pedal control switch adjustment		
12	<-2005	Checking LIN bus		
12	2006->	Calibration angle sensor		
13	<-2005	Reading off programmed parameters		
13 14	2006->	Activation and service		
14 14	<-2005 2006->	Identifying the Damper Motor Module (DMM)		
14 15	<-2005	Activating the internal test procedures		
15	2006->	Programming the additional and parking heater Calibration of radar and camera		
16	<-2005	Initializing the window position		
16	2006->	Programming the driver information module (DIM)		
17	<-2005	Programming soft stop		
17	2006->	Resetting the service reminder indicator(SRI)		
18	<-2005	Programming the remote control setting		
18	2006->	Testing all indicator and lamp in the driver information module (DIM)		
19	<-2005	Checking current values		
19	2006->	Read-out of fuel volume		
50	<-2005	Quick test of the fuel tank system		
50	2006->	Programming loudest audible signal, seat belt reminder		
51	<-2005	Programming the control module		
51	2006->	Programming seatbelt reminder in backseat		
52	<-2005	Installing/removing key		
52	2006->	Programming text message, seatbelt reminder		
53	<-2005	Read-out of programmed values in driver information module (DIM)		
i3	2006->	Activation of installation image		
54	<-2005	Reading off static data		
54	2006->	Programming control module		
55	<-2005	Calibrating the Bi-Xenon lamp position sensor		
55	2006->	Communication on MOST		
56	<-2005	Self-adjustment of damper motor end stops		
66	2006->	Open-circuit in the MOST cable		

Al	Special Function		
ID	year range		
57	<-2005	Adjusting parameter, ECC	
57	2006->	Reinstalling the reserve battery	
58	<-2005	Read-out of programmed values in driver information module	
58	2006->	Resetting counter particle filter	
59	<-2005	Window position set-up	
59	2006->	Adaptation of differential pressure sensor particle filter	
60	<-2005	programming the seat temperature	
60	2006->	Adaptation of throttle module	
61	<-2005	Calibration(DSTC)	
61	2006->	Adaptation of swivel channel throttle	
52	<-2005	Checking brake light switch adjustment	
52	2006->	Adaptation of mass airflow sensor	
3	<-2005	Calibration	
3	2006->	Adaptation of turbo control motor	
64	<-2005	Reading the user information	
64	2006->	Adaptation of mass airflow sensor	
35	<-2005	Activating/deactivating Volvo on Call	
35	2006->	Combustion of soot particles	
66	<-2005	Volvo On Call service check	
66	2006->	Checking injectors	
57	<-2005	Reinstalling the spare battery	
67	2006->	Quick-test injectors	
88	<-2005	Calibrating the system	
8	2006->	Combustion of soot particles, particle trap	
S9	<-2005	Add or Remove key	
39	2006->	Adaptation of the exhaust gas recirculation (EGR) valve	
70	<-2005	Resetting the SRL (Service Reminder Lamp) to zero	
70	2006->	Resetting the adaptation values	
71	<-2005	Program functionality	
71	2006->	Programming the optimizing parameters	
72	<-2005	Programming combined instrument panel	
72	2006->	Quick test of fuel tank system	
73	<-2005	Reading off programmed values in the combined instrument panel	
73	2006->	Readiness Code	
74	<-2005	Add/Erase keys	
4	2006->	Adaptation of the throttle unit	
'5 '5	<-2005 2006->	Erase the VIN code	
76		Quick test of exhaust camshaft control	
'6	<-2005	Initiate immobilizer control module	
7	2006-> <-2005	Quick test of intake camshaft control	
<i>i</i> 7	2006->	Programming lock type Quick test of the fuel pump (FP)	
'8	<-2005	Programming new control module	
'8	2006->	Checking/adjusting ethanol content	
'9	<-2005	Pragramming remote control	
9	2006->	Resetting the adaptation values	
0	<-2005	Checking the number of remote controls	
0	2006->	Calibration	
1	<-2005	Reading off the programmed values	
1	2006->	Resetting the counter for Transmission oil, change	
2	<-2005	Reading the static data	
2	2006->	Resetting adaptation	
33	<-2005	System test	
3	2006->	Calibration of position sensor	
4	<-2005	Programming the ECC control module	
4	2006->	Activation gear indication	

AL	Special Function		
ID	year range	Description	
35	<-2005	Self-adjusting of shutter motor end position	
35	2006->	Activation of adaption	
36	<-2005	Updating the electronic climate control module (ECC)	
36	2006->	Calibration (only vehicles with DSTC)	
37	<-2005	Resetting "Transmission oil replacement" counter	
37	2006->	Checking brake light switch adjustment	
38	<-2005	Readiness Code (USA/CDN)	
38	2006->	Quick-test of HCM	
39	<-2005	Reading off the diagnostic operating cycle	
39	2006->	Resetting counter oil	
90	<-2005	Programming fuel pump (FP) start diesel	
90	2006->	Adaptation of fuel pressure control valve	
91	<-2005	Programming the idle speed	
91	2006->	Programming control module	
92	<-2005	Check and adjust dynamic pump setting	
92	2006->	Quick test of alternator funtion	
93	<-2005	Quick fuel tank system test	
93	2006->	Resetting factory settings	
94	<-2005	IUMPR read out (USA/CDN)	
94	2006->	Resetting low voltage counters	
95	<-2005	Testing the fuel pump (FP)	
95	2006->	Resetting crash mode	
96	<-2005	Programming the optimizing parameters	
96	2006->	Programming of short flash sequence	
97	<-2005	Adaptation of the exhaust gas recirculation (EGR) valve	
97	2006->	Pre-delivery service for new car	
98	<-2005	Combustion of soot particles	
98	2006-> <-2005	Reading off the alarm cause	
99 99	2006->	Resetting the odometer particle trap	
100	<-2005	Testing the fuel pump (FP) Resetting the adaptation values	
100	2006->	Activating TEST MODE	
101	<-2005	Reading off the configuration	
101	2006->	Control module adaptation	
102	<-2005	Programming of global opening/closing of windows	
102	2006->	Resetting the adaptation	
103	<-2005	Testing all displays and lamps in the driver information module (DIM)	
103	2006->	Activating gear indication	
104	<-2005	Indicates programmed values	
104	2006->	Configuring the number of seats	
105	<-2005	Programming the infotainment control module (ICM)	
105	2006->	Storing the ID number for the occupant weight sensor (OWS)	
106	<-2005	Programming customer parameters	
106	2006->	Checking current values	
107	<-2005	Calibration (cars with DSTC)	
107	2006->	Programming the remote control setting	
108	<-2005	Calibration of the climate control module (CCM)	
108	2006->	Initiazing the window position	
109	<-2005	Programming remote control setting	
109	2006->	Programming soft stop	
110	<-2005	Calibration of position sensor, GDL lamps	
10	2006->	Calibrating the position for Bi-Xenon lamps	
111	<-2005	Calibration of position sensor	
11	2006->	Activating components and functions	
112	<-2005	Resetting counter oil	
112	2006->	Programming the additional and parking heater	

A	Special Function		
ID	year range	Description	
13	<-2005	Reading off VIN LEARNED	
13	2006->	Identifying the Damper Motor Module (DMM)	
14	<-2005	Programming a new control module	
14	2006->	Reading off the programmed parameters in the climate control module (CCM)	
15	<-2005	Programming the cruise control	
15	2006->	Compartment fan afterblow, status	
16	<-2005	Programming a new control unit	
16	2006->	Testing all needles and lamps in the dashboard	
.17	<-2005	Positioning of accelerator pedal sensor	
.17	2006->	Programming the audible acknowledgement signal, seat belt reminder	
.18	<-2005	Continuous variable valve timing (CVVT) test	
18	2006->	Display of DSTC message	
.19	<-2005	Activating the DSA warning lamp	
.19	2006->	Activating and reading off sun roof parameter	
20	<-2005	Activating torque reduction	
.20	2006->	Programming the control module	
.21	<-2005	Modify the settings in the combined instrument panel	
.21	2006->	Configuring the number of siren	
.22	<-2005	Programming the outside temperature display	
.22	2006->	Replacing the control module	
.23	<-2005	Programming the trip computer function	
.23	2006->	Reading the programmed values	
.24	<-2005	Programming a new combined instrument panel	
.24	2006->	Read out the stored ID numbers for the tyre pressure sensors	
.25	<-2005	Resetting the mileage, new car	
.25	2006->	Resetting Gearbox fluid change counter Resetting the service reminder lamp(SRL)	
.26	<-2005		
.27	2006-> <-2005	Programming optimising parameters Calibrating the control module	
.27	2006->	Activating/reading out components/functions	
.28	<-2005	Programming the alarm function	
.28	2006->	Configuration of the siren	
.29	<-2005	Programming the remote control function	
.29	2006->	Activating/deactivating Volvo On Call	
.30	<-2005	Resetting the Transmission fluid change counter	
.30	2006->	Service check forVolvo On Call	
31	<-2005	Resetting the adaptation	
31	2006->	Resetting the carphone code	
32	<-2005	Programming the climate control module	
32	2006->	Reading the user information	
33	<-2005	Self-adjustment of damper motor end positions	
33	2006->	Calibrating the system	
34	<-2005	Idling speed adjustment	
34	2006->	Checking the Four-C(Continuouslyly Controlled Chassis Concept)keypad unit	
35	<-2005	Positioning the throttle position sensor	
35	2006->	ETM test	
36	<-2005	Activating self-adjustment	
36	2006->	Extended diagnostic trouble code (DTC)reading	
37	<-2005	Updating the climate control module	
37	2006->	Reading off blocks of diagnostic trouble codes(DTCS)	
38	<-2005	Updating the combined instrument panel for diesel engines	
38	2006->	Reading off the diagnostic operating cycle	
39	<-2005	Reading cause of alarms	
39	2006->	Extended fault-tracing for the diagnostic trouble code(DTC), Engine control module (ECM)	
40	<-2005	Programming and calibration	
40	2006->	Resetting the Transmission fluid change counter	

AU	Special Function			
ID	year range			
141	2006->	Resetting the odometer particle trap		
142	2006->	Checking the additive level		
143	2006->	Refilling the feed hose with additive		
144	2006->	Resetting the tank level gauge		
145	2006->	Programming remote control setting		
146	2006->	Reading off the configuration		
147	2006->	Read out of the number of programmed remote keys		
148	2006->	Utlasning artikel/serienr RFR		
149	2006->	Initializing the window position		
150	<-2005	Installing low beam reduction US/CDN		
150	2006->	Checking the window in the rear door		
151	<-2005	Programming the control module, central electronic module(CEM) US/CDN		
151	2006->	Calibration (cars with DSTC)		
152	<-2005	Programming the combined instrument panel		
152	2006->	Programming the seat temperature		
153	2006->	Reading out detected/expected control modules/sensors		
154	2006->	Calibration of position sensor, GDL lamps		
155	2006->	Programming of global opening/closing of windows		
156	2006->	Programming of rear window wiper when reversing		
157	2006->	Setting clock deviation		
158	2006->	Ignition switch key position		
159	2006->	Read-out of part number remotes receiver and siren		
160	2006->	Position sensor xenon lamp		
161	2006->	Resetting the service reminder indicator (SRI)		
162	2006->	Reading off and programming vehicle mode		
164	2006->	Resetting counter by-passing alcolock		
165	2006->	Indicates programmed values		
166	2006->	Programming the infotainment control module (ICM)		
167	2006->	Programming other settings		
168	2006-> 2006->	Programming the clock		
169 170	2006->	Adaption reset, control valve inlet(throttle) Calibration of position sensor		
		•		
171 172	2006-> 2006->	Calibrating the position sensor for Bi-Xenon lamps		
173	2006->	Finding the predefined service position Unlocking catches		
174	2006->	Calibration of position sensor		
175	2006->	Loading assistance adjustment		
176	2006->	Restart the Convertible Roof Module (CRM)		
177	2006->	Reading off diagnostic data		
178	2006->	Initializing the front seat position		
249	2006->	Activation and service		
250	2006->	resetting the "Transmission fluid change" counter		
0_0001	<-2005	Resetting the service reminder lamp(SRL)		
179	2006->	Quick test of the fuel tank system		
180	2006->	Activating heating coil, FSM		
181	2006->	Filling of fuel system auxiliary heater		
182	2006->	Checking communication and control module		
183	2006->	Activating wipers, front/rear		
184	2006->	Ejection of key		
185	2006->	Operating and initiating the roof hatch		
.86	2006->	Restoring supplemental restraint system		
.87	2006->	Setting day and night mode for the instrumentation		
188	2006->	Checking installation, brake light switch, and brake pedal position switch		
.89	2006->	Readout of current from battery monitoring sensor		
.90	2006->	Readout of information stand-by current		
.91	2006->	Resetting the information to zero on power supply when replacing the battery		

A	Special Function		
ID	year range		
92	2006->	Resetting the information to zero on power supply when replacing the battery monitoring module	
93	2006->	Remote-controlled immobilization	
94	2006->	Automatic start/stop of engine	
95	2006->	Airflow setting in rear passenger compartment	
96	2006->	Action for falling temperature and cold draught in passenger compartment	
.97	2006->	Central lock motors, activating	
.98	2006->	Accumulator draining	
99	2006->	Request for self-test.	
200	2006->	Checking camshaft control, exhaust	
201	2006->	Checking camshaft control, inlet	
02	2006->	Checking the fuel pump (FP)	
03	2006->	Checking and adjusting calculated ethanol content	
04	2006->	Quick test of the function of the additional/parking heater	
05	2006->	Checking the DC/AC converter	
206	2006->	Fuel pump (FP) relay	
207	2006->	Remote controlled immobilising, status	
808	2006->	Remote controlled immobilising, cause	
209	2006->	Checking MOST communication	
210	2006->	Checking the oil level	
11	2006->	Adjusting calculated oil level/oil quality	
12	2006->	Read-out of causes of 10 latest occurrences of blocked autostop of engine	
13	2006->	Readout of number of occurrences of system requested autostart of engine	
14	2006->	Read-out of number of occurrences of blocked autostop of engine	
15	2006->	Adaptation of neutral position sensor	
16	2006->	Checking AUX-panel	
17	2006->	Adaption of oil level sensor	
18	2006->	Adaption of camshafts	
19	2006->	Resetting the clutch pedal counter	
20	2006->	Display of oil check	
21	2006->	Checking door handles	
22	2006->	Service calibration, Parking Aid Camera	
23	2006->	Camera activation, Parking Aid Camera	
24	2006->	Checking active grill shutter	
25	2006->	Aktivering av turboreglerventil (VNT-regulator)	
26	2006->	Adaption turbo system	
27	2006->	Reading out permanent diagnostic trouble codes (USA/CDN)	
28	2006->	Quick test of fuel tank system (USA/CDN)	
29	2006->	Resetting the oil quality counter	
30	2006->	Activation brake vacuum pump	
31	2006->	Checking current soot quantity and combustion of soot in particle filter	
32	2006->	Resetting counter for oil quality	
33	2006->	Resetting counter for soot amount in diesel particulate filter	
34	2006->	Resetting adaptations for the EGR valve	
35	2006->	Resetting adaptations for the throttle	
36	2006->	Resetting adaptations for turbocharger control	
37	2006->	Resetting adaptations for air flow measurement	
38	2006->	Resetting adaptations for the fuel system (high pressure side)	
39	2006->	Resetting adaptations for the injectors	
40	2006->	IUMPR read out (USA/CDN)	
41	2006->	Resetting information about current consumption	
42	2006->	Initiation of the TCS switch by the tunnel console	
43	2006->	Initial adaptation	
44	2006->	Initiation of tailgate's position, Power Operated Tailgate Module (POT)	
45	2006->	Reading off the result from a ring break diagnostic	
46	2006->	Programming the gear shift indicator	
47	2006->	Activation of heater	

-Autol		4 o l	
	Autei		Special Function
	ID	year range	Description
248	8	2006->	Read-out of part number for Remote Receiver Module (RRX) and siren (SCM)